

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>El Paso Natural Gas Company</b>	8. Farm or Lease Name <b>Cornell</b>
3. Address of Operator <b>Box 990, Farmington, New Mexico - 87401</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>C</b> , <b>920</b> FEET FROM THE <b>North</b> LINE AND <b>1720</b> FEET FROM THE <b>West</b> LINE, SECTION <b>14</b> TOWNSHIP <b>29N</b> RANGE <b>12W</b> NMPM.	10. Field and Pool, or Wildcat <b>Fulcher Kutz P. C.</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>5628' GL</b>	12. County <b>San Juan</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Kill well and spot a 25 sack cement plug on bottom (25 sacks will fill from total depth to 1416').

Pull tubing, then determine free point of 5 1/2" casing by stretch, shoot off casing above free point and spot a 30 sack cement plug on casing stub by displacing cement down the freed casing (30 sacks will fill 105').

Pull 5 1/2" casing and place a 25 sack cement plug at the base of the surface casing.

Place a 10 sack cement plug at the surface, erect a dry hole marker and clean the location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Don Read</u>	TITLE <u>Petroleum Engineer</u>	DATE <u>8-26-69</u>
APPROVED BY <u>Ernest Chavez</u>	TITLE <u>Sup Dist III</u>	DATE <u>8-27-69</u>
CONDITIONS OF APPROVAL, IF ANY:		

