

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Pioneer Production Corp.	8. Farm or Lease Name Farmington Com
3. Address of Operator P. O. Box 234, Farmington, New Mexico 87401	9. Well No. 1
4. Location of Well UNIT LETTER P 700 FEET FROM THE South LINE AND 790 FEET FROM THE East LINE, SECTION 11 TOWNSHIP 29N RANGE 13W NMPM.	10. Field and Pool, or Wildcat Basin Dakota
15. Elevation (Show whether DF, RT, GR, etc.) 5330' GL - 5342' RKB	12. County San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:


SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Repair Casing Leak*	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to repair casing leak as follows:

1. Pull 1-1/4" tubing and set B.P. at 4500'.
2. Pick up 2-3/8" tubing and packer and find hole in 4-1/2" casing.
3. Squeeze hole in casing.
4. Drill out cement and bridge plug and clean out to PBTD 5945'.
5. Re-run 1-1/4" tubing with packer and swab well in.



\*This job has been discussed with Mr. A. R. Kendrick.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by

SIGNED Jim L. Jacobs TITLE Agent DATE 10-15-73

Original Signed by A. R. Kendrick

APPROVED BY Jim L. Jacobs PETROLEUM ENGINEER DIST. NO. 3 DATE OCT 23 1973

CONDITIONS OF APPROVAL, IF ANY: