

N. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	3

NEW MEXICO OIL CONSERVATION COMMISSION

Form 1-101
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input type="checkbox"/> GAS <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator El Paso Natural Gas Company	3. Address of Operator PO Box 990, Farmington, NM 87401	4. Location of Well UNIT LETTER K 1650 FEET FROM THE South LINE AND 1650 FEET FROM West LINE, SECTION 3 TOWNSHIP 29N RANGE 11W	5. Elevation (Show whether DL, RT, GR, etc.) 5688'GR	6. Indicate Type of Lease Lease <input checked="" type="checkbox"/>	7. Well Represent Name Oswell	8. Lease No. 1	9. Field and Well, or Well Unit Aztec Pictured Cliffs	10. County San Juan
--	--	--	---	---	--	----------------------------------	-------------------	--	------------------------

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
OTHER <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is to be permanently plugged due to its being non-productive.
It is intended to permanently plug and abandon the well in the following manner:

Circulate the hole and spot a 20 sk. cement plug across the Pictured Cliffs formation to fill the open hole section and into the production casing.

Perforate squeeze holes at the base of the Ojo Alamo (765'). Spot a 45 sk. cement plug across the perforations and pressure displace 20 sks. of cement into the perforations.

Perforate squeeze holes 200' below the base of the surface casing, and spot a 45 sk. cement plug across perforations. Pressure displace 20 sks. cement into perforations.

Place a 10 sk. cement plug at surface. Install dry hole marker and clean up location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
SIGNED <i>W. H. Lawrence</i>	TITLE Chief Div. Drilling Engr. DATE December 16, 1976
APPROVED BY <i>AR Kendrick</i>	TITLE DATE
CONDITIONS OF APPROVAL, IF ANY:	