

State of New Mexico  
Energy, Minerals and Natural Resources Department  
Oil Conservation Division

Sundry Notices and Reports on Wells

<b>1. Type of Well</b> GAS	<b>API # (assigned by OCD)</b> 30-045-09505 <b>5. Lease Number</b> B-10938-30 <b>6. State Oil&amp;Gas Lease #</b>  <b>7. Lease Name/Unit Name</b>  Stanolind Gas Com <b>8. Well No.</b> #1 <b>9. Pool Name or Wildcat</b> Blanco MV <b>10. Elevation:</b>
<b>2. Name of Operator</b> <b><i>BURLINGTON RESOURCES</i></b>	
<b>3. Address &amp; Phone No. of Operator</b> PO Box 4289, Farmington, NM 87499 (505) 326-9700	
<b>4. Location of Well, Footage, Sec., T, R, M</b> 1640' FNL, 1730' FEL, Sec. 16, T-30-N, R-8-W	

Type of Submission	Type of Action	
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input checked="" type="checkbox"/> Other -repair tubing	

**13. Describe Proposed or Completed Operations**  
It is intended to repair the tubing on the subject well according to the attached procedure.

**RECEIVED**  
JAN - 2 1998  
**OIL CON. DIV.**  
DIST. 3

SIGNATURE *Johnny Robinson* (MEL6) Regulatory Affairs December 31, 1997

(This space for State Use)  
Approved by *Johnny Robinson* Title DEPUTY OIL & GAS INSPECTOR, DIST. #3 Date JAN - 2 1998

**Stanolind Gas Com #1**  
**Mesaverde**  
**1640' FNL 1730' FEL**  
**Unit G, Section 16, T-30-N, R-08-W**  
**Latitude / Longitude: 36° 48.83' / 107° 40.58'**  
**DPNO: 49333A**  
**Tubing Repair Procedure**

1. Hold safety meeting. Comply with all NMOCD, BLM and Burlington safety and environmental regulations. Test rig anchors and build blow pit prior to moving in rig. **Notify BROG Regulatory (Peggy Bradfield 326-9727) and the appropriate Regulatory Agency prior to pumping any cement job. If an unplanned cement job is required, approval is required before the job can be pumped. If verbal approval is obtained, document approval in DIMS/WIMS.** Allow as much time as possible prior to pump time in case the Agency decides to witness the cement job.
2. MOL and RU workover rig. Obtain and record all wellhead pressures. NU relief line. Blow well down and kill with 2% KCL water if necessary. NU BOP with stripping head. Test and record operation of BOP rams. Have wellhead and valves serviced as necessary. Test secondary seal and replace/install as necessary.
3. Release donut, pick up additional joints of tubing and tag bottom. (Record depth.) TOOH with tubing. Visually inspect tubing for corrosion and replace any bad joints. Check tubing for scale build up and notify Operations Engineer.
4. If casing requires clean out, TIH with bit and bit sub and CO to PBTD prior to running casing scraper. Roundtrip casing scraper and bit to below perforations. (Do not clean out with casing scraper.) PU above perforations and flow the well naturally, making short trips for clean up when necessary. TOOH.
5. TIH with 2-3/8" tubing with an expendable check on bottom and a seating nipple one joint off bottom. Rabbit all tubing. CO to PBTD.
6. Land tubing near 4900'. ND BOP and NU wellhead. Pump off expendable check. Obtain final pitot gauge up the tubing. If well will not flow on it's own, make swab run to seating nipple. If a swab run is not necessary, run a broach on slickline to ensure that the tubing is clear. RD and MOL. Return well to production.

Recommended: MEL Lutey  
Operations Engineer

Approved: \_\_\_\_\_  
Drilling Superintendent

Mary Ellen Lutey  
Office - (599-4052)  
Home - (325-9387)  
Pager - (324-2671)

MEL/mel