

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
SUNDRY NOTICES AND REPORT ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT" - for such proposals.

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

5. Lease Designation and Serial No.  
SF-078580-A

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Moore X 8

9. API Well No.

3004527337

10. Field and Pool, or Exploratory Area

Basin Fruitland Coal

11. County or Parish, State

San Juan, New Mexico

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Attention:

Amoco Production Company

Patty Haefele

3. Address and Telephone No.

P.O. Box 800, Denver, Colorado 80201

(303) 830-4988

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1395' FNL & 1490' FEL

Section 4

T30N

R8W

Unit G

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other Clean out

☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log Form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Amoco Production Company requests permission to clean out this open hole well per the attached procedure.

RECEIVED  
OCT 23 1996

OIL CON. DIV  
DIST. 3

OCT 15 11 24 AM '96  
OIL CON. DIV  
DIST. 3

14. I hereby certify that the foregoing is true and correct

Signed Patty Haefele Title Staff Assistant Date 10/10/96

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

APPROVED

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious, or fraudulent statement or representations as to any matter within its jurisdiction.

\* See Instructions on Reverse Side

NMOCD

OCT 17 1996  
Chip Harada  
for DISTRICT MANAGER

# SJOET Well Work Procedure

Moore A 8

Version: #1  
Date: October 10, 1996  
Budget: Expense/Well Repair  
Repair Type: Cleanout

---

## Objectives:

1. TOOH with existing 4 1/2" tubing and LD.
  2. TIH with work string to cleanout well to TD.
  3. Stabilize open hole, slightly surging well if necessary, and flowtest.
  4. TOOH with work string and TIH with 5 1/2" IJ liner.
  5. TIH with 2 7/8" tubing and flowback.
  6. Change tubing head and casing valves to full opening.
- 

## Pertinent Information:

Location:	1395' FNL x 1490' FEL; 04-T30N, R08W G	Horizon:	FT
County:	San Juan	API #:	30-045-27337
State:	New Mexico	Engr:	R. DeHerrera
Lease:	S F - 078580 - A	Phone:	H-(303)439-7893
Well Flac:	703043		W-(303)830-4946

---

## Economic Information:

APC WI:	50%	Prod. Before Repair:	3300 MCFD
Estimated Cost:	\$95,000	Anticipated Prod.:	4300 MCFD
Payout:	4 Months	Prod. Before Repair	
Max Cost -12 Mo. P.O.	\$283,198	Anticipated Prod.:	
PV15:			
Max Cost PV15:			

**Note:** Economics will be run on all projects that have a payout exceeding ONE year.

---

## Formation Tops: (Estimated formation tops)

Nacimiento:		MesaVerde:	
Ojo Alamo:		Point Lookout:	
Kirtland Shale:		Mancos Shale:	
Fruitland:	2917'	Gallup:	
Pictured Cliffs:		Graneros:	
Lewis Shale:		Dakota:	
Cliff House		Morrison:	

---

## Bradenhead Test Information:

Test Date:	Tubing:	Casing:	BH:
------------	---------	---------	-----

Time	BH	CSG	INT	CSG
5 min				
10 min				
15 min				

---

Comments:

**HIGH VOLUME WELL--DO NOT PROCEED UNTIL YOU ARE CERTAIN THAT ALL PRECAUTIONS HAVE BEEN TAKEN. CALL ME AT NUMBERS LISTED BELOW IF IN DOUBT.**

1. MIRURT complete with 3.500" drill pipe, 4.750" drill collars and air package.
2. ND tree, rig up BOP's w/cavitation capability complete with venturis on blooie lines. Test BOE. Set pump-through plug in 2.25" "F" nipple at 2826'. With additional joints of 4 1/2" tubing, tag fill depth. TOO H with 4 1/2" tubing, laying it down. NOTE: SHOULD IT BECOME APPARENT THAT YOU CAN NOT SAFELY PULL THE TUBING WITHOUT ASSISTANCE FROM A SNUBBING UNIT; CALL ONE OUT AND RIG UP. Change pipe rams to permit running the 3.500" drill pipe.
3. Pick up a 6.250" mill tooth bit, 3.500" drill pipe, and 4.750" drill collars and clean out fill to total depth (3113') using air and foam. Rotate and reciprocate on bottom until hole is clean. POOH with drill pipe so bottom of tubing is above 7" casing shoe at 2872'.
4. Flow test well up both tubing and casing for 1 hour through 3/4" choke and record pressures every 10 minutes. Shut well in and wait for 4 hours, record pressures every 10 minutes for first hour then every hour following.
5. TIH with tubing and check to determine amount of fill and how difficult it is to clean up. Repeat clean out, flow test, and shut in if necessary and stabilize hole as quickly as possible to allow running liner. (If running liner, underream well to 9.250"-9.500" after initial clean out and flow test. Perform at least one additional clean out and flow test following underream procedure). Once hole is stabilized, proceed to next step. Slight surging of the well may be necessary to stabilize open hole.

If running liner:

- a1. Run a blank 5.500" flush joint liner from TD to approx. 100-150' inside of 7" casing. Install a tri-cone bit on bottom of liner with a float immediately above bit and a Baker Model SLR-P liner hanger packer. Trip in hole and hang liner -- drill to bottom with power swivel if necessary.
- a2. RU wireline and RIH with perforating guns to perforate overbalanced and correlate to mud log dated 06/15/89 and perforate liner at following depths:

Coal Seam	Perforation Depths	JSPF	Number of Shots
Ignacio	2926' to 2946'	4 JSPF	80
Cotton wood	3010' to 3032'	4 JSPF	88
Cahn	3074' to 3108'	4 JSPF	136
TOTAL # OF SHOTS			304

6. Lay down drill string, change pipe rams as necessary to run the 2 7/8" tubing string. Pick up a 2 7/8" Closed End Half Mule shoe, 10' perforated sub, profile nipple and 2 7/8" tubing. Install profile nipple with retrievable plug in place and run in with the 2 7/8" tubing. Land tubing at 3060'. Profile nipple needs to be at the bottom of the tubing just above the perforated sub assembly.
  7. ND BOE, NU tree and RDMORT. Tie well back into surface equipment, retrieve plug and bring well on line slowly in an attempt to minimize any cavitation effect. Turn over to production.
- Dependent on speed of hole stabilization, I estimate this procedure to require approximately 5 days and to cost approximately \$95,000.

**Tubing Head Replacement**

This can be completed any time during the workover. Many of the high rate fruitland coal wells are produced through the tubing string and the tubing/casing annulus. The 7 1/16" 3000# x 11" 3000# tubing heads on the wells were outfitted with flanged 2 1/8" casing valves. The threaded outlet in the head is 1 1/2" in diameter. We need an additional head with the outlets full opening and the ability to accomodate full opening casing valves. FMC is aware of our plans and is scrambling to accomodate this request.

Orig. Comp. 8/89

TD= 3113'

Page 3 of 2

*If problems are encountered, please contact:*

*Robert DeHerrera*

*(W) (303)830-4946*

*(H) (303)439-7893*