DISTRIBUTION	Supersedes Old
	C-102 and C-103
SANTA FE NEW MEXICO OIL CONSERVATION COMMISSION	Effective 1-1-65
FILE /	Eg. Indicate Turn of Lance
U.S.G.S.	5a. Indicate Type of Lease
LAND OFFICE	State X Fee
OPERATOR /	5. State Oil & Gas Lease No.
	E-505-6
SUNDRY NOTICES AND REPORTS ON WELLS	
SUNDRY NOTICES AND REPORTS ON WELLS  (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
OIL GAS V	7. Unit Agreement Name Northeast Blanco Uni
	No. 1, Sec. 929 8. Farm or Lease Name
Name of Operator	Northeast Blanco Uni
Blackwood & Nichols Company	9. Well No.
Address of Operator	
P. O. Box 1237, Durango, Colorado 81301	22 10. Field and Pool, or Wildcat
Location of Well	_
UNIT LETTER G . 1710 FEET FROM THE N LINE AND 1970 FEET FROM	Blanco Mesaverde
THE E LINE, SECTION 36 TOWNSHIP 31N RANGE 7W NMPM.	
The the section township none name	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
6212' GL	Rio Arriba
Check Appropriate Box To Indicate Nature of Notice, Report or Oth	
NOTICE OF INTENTION TO: SUBSEQUENT	REPORT OF:
	_
ERFORM REMEDIAL WORK PLUG AND ABANDON X REMEDIAL WORK	ALTERING CASING
EMPORARILY ABANDON COMMENCE DRILLING OPNS.	PLUG AND ABANDONMENT
ULL OR ALTER CASING CHANGE PLANS CASING TEST AND CEMENT JOB	
OTHER	
OTHER	
	estimated date of starting any propose
17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including work) SEE RULE 1103.	estimated date of starting any propose
	) with 175 sacks cemen cement with 50 sacks with 50 sacks cement,
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemen cement with 50 sacks with 50 sacks cement,
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement,
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surmandenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement,
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement,
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement,
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement to 100' inside and outside. Spot 20 sacks cement plug in 7" casing at sur	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement,
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement value and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.  See attached diagram	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surm Bradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.  See attached diagram  8.1 hereby certify that the information above is true and complete to the best of my knowledge and belief.	with 175 sacks cemer cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; rement, 100' inside and outside. Perforate 7" casing at 750', cement v. 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surradenhead (between 7" and 10-3/4" casing) with 25 sacks cement.  See attached diagram	) with 175 sacks cemer cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surgedenhead (between 7" and 10-3/4" casing) with 25 sacks cement.  See attached diagram  8.1 hereby certify that the information above is true and complete to the best of my knowledge and belief.	with 175 sacks cement cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; rement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surgardenhead (between 7" and 10-3/4" casing) with 25 sacks cement.  See attached diagram  8. Thereby certify that the information above is true and complete to the best of my knowledge and belief.  Thereby certify that the information above is true and complete to the best of my knowledge and belief.  District Manager	with 175 sacks cement cement with 50 sacks with 50 sacks cement, face and squeeze
Set 7" retainer at 4850', squeeze Mesaverde perforations (5063' - 5560 Spot 35 sacks cement plug, 3150' - 3250'. Perforate 7" csg. at 2400'; cement, 100' inside and outside. Perforate 7" casing at 750', cement 100' inside and outside. Spot 20 sacks cement plug in 7" casing at surrespondented (between 7" and 10-3/4" casing) with 25 sacks cement.  See attached diagram  8.1 hereby certify that the information above is true and complete to the best of my knowledge and belief.	with 175 sacks cemer cement with 50 sacks with 50 sacks cement, face and squeeze

## NEBU NO. 22 1710' F/NL - 1970' F/EL Sec. 36-31N-7W Rio Arriba County, New Mexico Elevation 6209' GL Plug and Abandon

