

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	3

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Beta Development Co.		8. Farm or Lease Name Martin 34
3. Address of Operator 125 Petroleum Club Plaza, Farmington, New Mexico		9. Well No. 2
4. Location of Well UNIT LETTER 0 990 FEET FROM THE South LINE AND 1850 FEET FROM THE East LINE, SECTION 34 TOWNSHIP 30N RANGE 11W NMPM.		10. Field and Pool, or Wildcat Basin Dakota
15. Elevation (Show whether DF, RT, GR, etc.) 5760' G.L.		12. County San Juan

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐


ALTERING CASING ☐
PLUG AND ABANDONMENT ☐
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to repair well as follows:

Rig up workover unit, circulate all mud and shale out of well w/fresh water 1% Calcium Chloride, CO to T.D. Pull 1-1/2" tbg out of well, GIH w/3-7/8" bit on 2-3/8" tbg, ream out any tight places in csg. CO to T.D. Circ. hole clean. POH, run packer on 2-3/8" tbg w/2-seal assembly w/perforated nipple in between seals, bull plug on bottom w/stop ring. Set packer, pull tbg up until stop ring catches at bottom of packer. This will have bottom seal assembly inside of Model "P" packer. Pump in cement, displace w/water, over-flush w/2-bbls, slack tbg off until top assembly sets down on packer. Swab well in. Release rig. After well has cleaned up, re-acidize w/500 gals 15% reg. mud acid.

This will be a tubeless completion.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by:

D. E. BAXTER

SIGNED

TITLE

Superintendent

DATE

Feb. 10, 1969

APPROVED BY

TITLE

DATE

2-11-69

CONDITIONS OF APPROVAL, IF ANY: