



STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT
 OIL CONSERVATION DIVISION
 AZTEC DISTRICT OFFICE

BRUCE KING
 GOVERNOR
 LARRY KEHOE
 SECRETARY

1000 RIO BRAZOS ROAD
 AZTEC, NEW MEXICO 87410
 (505) 334-6178

September 1, 1982

Southland Royalty Company
 P. O. Drawer 570
 Farmington, NM 87401

Re: Plugging reports

Gentlemen:

The attached Form C-103, Notice of Intention to Plug and Abandon your Well Name and Number, has been approved as amended, with the following conditions:

1. All plugs shall be of Class A, B, or C neat cement may be accelerated by up to 3% CaCl.
2. All plugs are to be separated by gel mud of minimum nine pounds per gallon.
3. This office must be notified a minimum of 24 hours before plugging operations are commenced.

The subsequent report of plugging cannot be approved until the following requirements have been met:

1. All pits have been filled and leveled.
2. A steel marker at least 4" in diameter and approximately 4' above ground level has been set in cement. The well name and number, and the well location by unit letter, section, township, and range shall be permanently welded, stamped, or engraved into the metal of the marker.
3. The location has been cleared and cleaned.
4. The deadman wires have been removed or cut off 4' below ground level.
5. All information required by Rule 1105 has been filed.

The subsequent notice of plugging must state that the above work has been done and that the site is ready for inspection.

Yours truly,

Jeff A. Edmister

Jeff A. Edmister,
 Deputy Oil & Gas Inspector


JAE:dh

Enclosures

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SOUTHLAND ROYALTY COMPANY hereby proposes to Plug and Abandon this well as follows:

- 1) MIRU
- 2) POOH with 1" tubing. PU 2-3/8" workstring.
- 3) Spot 55 sacks of cement from 1605' to 1450'.
- 4) Determine free point of 5-1/2" casing and shoot off.
- 5) Spot 30 sacks of cement on top of cut off joint.
- 6) Spot 40 sacks of cement at 400' to cover Ojo Alamo.
- 7) Spot 35 sacks of cement at 80' and circulate to the surface.
- 8) Cut off surface and production casing 4' below surface.
- 9) Clean up location.



3) Spot 30 sacks of cement at 80' and circulate to the surface.