



**NEW MEXICO ENERGY, MINERALS
& NATURAL RESOURCES DEPARTMENT**

OIL CONSERVATION DIVISION
AZTEC DISTRICT OFFICE
1808 RIO BRAZOS ROAD
AZTEC, NEW MEXICO 87410
(505) 334-8178 Fax (505) 334-8170

GARY E. JOHNSON
GOVERNOR

JENNIFER A. SALISBURY
CABINET SECRETARY

June 18, 1997

Rand Carroll
Oil Conservation Division Attorney
2040 S Pacheco
Santa Fe NM 87505

RE: BMNS Company, Waggoner #2, C-32-30N-12W, 30-045-09077

Dear Rand:

The above-mentioned well was brought to our attention by Mr. Drinen the landowner. According to Mr. Drinen the well hasn't been produced since the 1960's. The well file shows that the well was plugged in 1949. I looked in our bond file and couldn't find any record of a bond. After an inspection we determined that the well was not plugged. The well doesn't have a waterflow but is in the city limits and will have to be plugged as an orphan well. Due to the location the well should be plugged as soon as possible unless you have other wells with a higher priority.

This well doesn't fall under an emergency so I would like to obtain bids to plug the well. I have enclosed copies of the well file and an approved plugging procedure. Please notify me of your schedule and when we can start asking for bids.

Sincerely,

Johnny Robinson
Deputy O&G Inspector

JR/sh

cc: well file

attachments

J.M.N.S. COMPANY

PROPERTY NAME
WAGGONERWELL NO.
2DATE
06-17-97LOCATION ULSTR)
C-32-30N-12WFOOTAGE
660 FNL & 2320 FWLAPI NO.
30-045-09077

POOL


ELEVATION
5457'

Formation	Tops	Casing Record
PICTURED CLIFF	1547'	5 1/2" @ 1534'
FRUITLAND	1077'	O.H. @ 1623'
WATER SANDS	16'-48' & 552'-556'	

10-13-47 DRILLED A 8" HOLE TO 1623'
SET 5 1/2 CSG. @ 1534' CEMENTED WITH 50 SXS. CEMENT
TOP OF CEMENT APPX. 1257'

PLUGGING PROCEDURE


1. ND WH. NU BOP & TOOH WITH PRODUCTION EQUIPMENT.
2. TIH WITH TBG. TO APPX. 1584' & SPOT A 40 SX. PLUG & TAG @ 1484'
3. TIH WITH WIRELINE & PERF 4 SHOTS @ 1127'.
4. TIH WITH RETAINER TO APPX. 1077' & SET. PUMP 40SXS. THROUGH RET. & SPOT 6 SXS. ON RET.
5. TEST CSG.
6. GIH WITH WIRELINE AND PERF. 4 SHOTS AT 100'.
7. ESTABLISH CIRC. TO THE SURFACE & BULLHEAD CEMENT INSIDE AND OUTSIDE TO THE SURFACE.
8. IF UNABLE TO CIRC. PERF AT 30' AND CIRC.
9. CUT ANCHORS, RESTORE LOCATION AND INSTALL DRYHOLE MARKER.




Current Wellbore

30-12

Sec 29



Sec 32



2320

1990