

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No. NM 01445	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company		8. Farm or Lease Name Bruington
3. Address of Operator P. O. Box 289, Farmington, New Mexico		9. Well No. 2
4. Location of Well UNIT LETTER <u>K</u> <u>1650</u> FEET FROM THE <u>south</u> LINE AND <u>1650</u> FEET FROM THE <u>west</u> LINE, SECTION <u>29</u> TOWNSHIP <u>30N</u> RANGE <u>11W</u> NMPM.		10. Field and Pool, or Wildcat Aztec Pictured Cliffs
15. Elevation (Show whether DF, RT, GR, etc.) 5785' GL		12. County San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

RECOMMENDED PROCEDURE TO PLUG & ABANDON:

- (1) Move on location and rig up. Circulate the hole.
- (2) Pull 1" tubing.
- (3) Pick up 2 3/8" work string. Spot a cement plug from 2000' to 2131 with 15 sx of cement (17.7 cu. ft.)
- (4) Perforate squeeze hole at 800'. Spot a 52 sx (61.4 cu. ft.) cement plug from 600 to 800'. Pressure displace 29 sx (34.2 cu. ft.) of cement across the Ojo Alamo formation.
- (5) Pull out of the hole with the work string.
- (6) Perforate squeeze holes at 180'. Circulate 70 sx (82.6 cu. ft.) cement plug from the surface to 180' and back to the surface out the bradenhead.
- (7) Cut off wellhead. Install dry hole marker. Clean location.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Senior Production

Engineer

SIGNED Loren W Fethergill

TITLE

DATE 6-25-81

APPROVED BY Original Signed by FRANK T. CHAVEZ

TITLE

SUPERVISOR DISTRICT # 3

DATE

JUN 26 1981

CONDITIONS OF APPROVAL, IF ANY: