

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

| | |
|---|---|
| 1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER | 5. LEASE DESIGNATION AND SERIAL NO. SF 078138 |
| 2. NAME OF OPERATOR El Paso Natural Gas Company | 6. IF INDIAN, ALLOTTEE OR TRIBE NAME |
| 3. ADDRESS OF OPERATOR P. O. Box 289 Farmington, New Mexico 87401 | 7. UNIT AGREEMENT NAME |
| 4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990'N 1650'W Sec. 29, T30N, R11W | 8. FARM OR LEASE NAME Morris A |
| | 9. WELL NO. #2 |
| | 10. FIELD AND POOL, OR WILDCAT Aztec PC |
| | 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA NW 29-30N-11W |
| 14. PERMIT NO. | 12. COUNTY OR PARISH San Juan |
| 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 5773 DF | 13. STATE NM |

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐

ALTERING CASING ☐



ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Procedure to Plug and Abandon:

Pull 1" tubing and replace with 2" work string. Spot cement plug in open hole from 1950' to TD with 30 sxs. Pull up above Ojo Alamo and perforate squeeze holes at 740'. Squeeze with 30 sxs cement leaving 100' cement in casing. Pull out of hole. Perforate squeeze holes at 132'. Pressure displace 40 sxs cement into formation and up to surface. Set dry hole marker.



18. I hereby certify that the foregoing is true and correct

SIGNED John J. Tellerman

TITLE Production Engr.

DATE 4-19-79

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

*See Instructions on Reverse Side

NMOCC