

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☒ other ☐
2. NAME OF OPERATOR
El Paso Natural Gas Company
3. ADDRESS OF OPERATOR
P. O. Box 289, Farmington, N. M. 87401
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 990'S, 1450'W, Sec. 20-30-11
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

- TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☒
(other) ☐

SUBSEQUENT REPORT OF:

- ☐
☐
☐
☐
☐
☐
☐
☐

5. LEASE
SF 078138
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Morris A
9. WELL NO.
1
10. FIELD OR WILDCAT NAME
Aztec P.C.
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
SW 20-30-11
12. COUNTY OR PARISH
San Juan
13. STATE
New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
5777' GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Procedure to Plug and Abandon:

Pull 1" tbg. and replace with a 2" work string. Spot a cement plug in the open hole section from 2000' to TD of 2159' with 22 sx (26 cu. ft.) of cement. Pull out of hole and find free point of the csg. and shoot off. If the cut off point is below the Ojo Alamo, spot a 125' cement plug with 38 sx. (45 cu. ft.) of cmt. across the csg. stub. Spot a 200' cmt. across the Ojo Alamo (600 to 800') with 57 sx (67 cu. ft.) of cement.

If the cut off point is above the Ojo Alamo formation, perforate squeeze holes @ 750'. Spot a 57 sx (67 cu. ft.) cmt. plug across the squeeze holes and pressure displace cmt. into formation leaving a cmt. plug inside csg. from 600' to 800'. Cut off csg. above the Ojo Alamo formation and recover. Spot a 125' cmt. plug across the csg. stub with 38 sx. (45 cu. ft.) of cmt. Spot a cmt. plug inside the surface pipe with 50 sx (59 cu. ft.) of cmt. and install a dry hole marker.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Loren W. Fathergill TITLE Production Engineer DATE 5-31-79

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: