

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
	1
	2
OFFICE	
	2

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-104  
Effective 1-1-55

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement No.
8. Farm or Lease No.
<b>Moya Goode</b>
9. Well No.
<b>1</b>
10. Field and Pool or Wildcat
<b>P. C.</b>
12. County
<b>San Juan</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.

1. <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER
2. Name of Operator
<b>John J. Moya</b>
3. Address of Operator
<b>P. O. Box 1641 Bloomfield, N.M. 87413</b>
4. Location of Well
UNIT LETTER <b>P</b> . <b>990</b> FEET FROM THE <b>S. L.</b> LINE AND <b>1320</b> FEET FROM
<b>E. L.</b> LINE, SECTION <b>18</b> TOWNSHIP <b>30N</b> RANGE <b>11W</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated cost of work) SEE RULE 1103.

Set a plug from TD 1958' to 1756' using 25 sacks. Attempt to salvage casing, if casing is pulled from below 630', set a plug from 630' to 530' using 40 sacks. Shut down 6 hours minimum with accelerated cement and 12 hours with neat cement. Tag cement plug, if top of plug is below 550' replug to 530'. If plug is above 550' go to set a plug from 200' to 100' using 40 sacks. Set marker in surface casing; or if casing not pulled from below 630' or 200' respectively, set plugs as follows:  
Perforate at 630' and set a 100' plug inside and outside the 5 1/2" casing using 40 sacks, squeezing 25 sacks through the perforations.  
Perforate at 200' and set a 100' plug inside and outside of 5 1/2" casing using 40 sacks, squeezing 25 sacks through the perforations.  
Set dry hole marker, remove all junk from location, clean and restore location to pre-existing conditions.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jack Huff TITLE Agent DATE 10-1-77

APPROVED BY M. E. Mayfield TITLE DEPUTY COMMISSIONER DATE 10-1-77  
CONDITIONS OF APPROVAL, IF ANY: