

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER Plug	5. LEASE DESIGNATION AND SERIAL NO. SF 080212
2. NAME OF OPERATOR Hebco Oil	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR 4381 Boy Scout Lane El Paso TX	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FNL 1980' FEL	8. FARM OR LEASE NAME Malco Copple
14. PERMIT NO.	9. WELL NO. #6
15. ELEVATIONS (Show whether DP, RT, GR, etc.) 5415 Gr.	10. FIELD AND POOL, OR WILDCAT Verde Gallup
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 5 T30N R15W
	12. COUNTY OR PARISH San Jaun
	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON*

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR WELL

CHANGE PLANS

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We plan to plug and abandon well as follows:

1. Spot cement plug from 3462' to 3084' (across slotted liner and 50' above Gallup inside $5\frac{1}{2}$ " casing).
2. Fill hole with 9.2 ppg mud.
3. Spot 100' cement plug from 1689' to 1589' inside $5\frac{1}{2}$ " casing (Pt. Lookout).
4. Find free point of $5\frac{1}{2}$ " casing, cut and pull casing.
5. Place 100' cement plug 50' in and 50' out of casing stub.
6. Set 100' cement plug from 184' to 84' across surface casing shoe.
7. Install dry hole marker. plug at 50'

RECEIVED

MAR 17 1986

BUREAU OF LAND MANAGEMENT
FARMINGTON RESOURCE AREA

RECEIVED

MAR 20 1986

OIL CON. DIV.
DIST. 3

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

NMOCC