

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-015
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to
a different reservoir,
Use "APPLICATION FOR PERMIT--" for such proposals

1. ☐ Oil Well ☒ Gas Well ☐ Other

2. Phillips Petroleum Company

3. 5525 Hwy. 64, NBU 3004, Farmington, NM 87401 (505) 599-3454

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1650' FNL & 790' FNL
Section 8, T-31-N, R-7-W

5. Lease Designation and Serial Number

SF-078996

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

San Juan 32-7 Unit

8. Well Name and No.

San Juan 32-7 Unit # 5

9. API Well No.

30-045-10934

10. Field and Pool, or Exploratory Area

Blanco Mesaverde

11. County or Parish, State

San Juan, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☐ Notice of Intent

☒ Subsequent Report

☐ Final Abandonment Notice

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

TYPE OF ACTION

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-off

☐ Conversion to Injection

☐ Dispose Water

(Note Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimate date of starting any proposed work. If well is directionally drilled, give subsurface locations and true vertical depths for all markers and zones pertinent to this work.)

9/29/94

MIRU A-Plus Well Service Rig #4. Rig up BOP. POOH w/71 jts 1-1/4" tubing. Tubing parted. RIH w/fishing tools on 2-3/8" tubing. Latch onto fish. Run 1" bars on wireline. Tried several times to fish without success. Got permission from BLM to stop fishing. RIH & set cement retainer at 3810' (top of fish @ 3842'). Load hole w/packer fluid. Sting into retainer.

Plug #1: Squeeze 111 sxs below retainer, spot 10 sxs on top to 3757'. POOH. Perf. 4 holes @ 3478'. Perf 4 holes @ 2988'. RIH and set cement retainer @ 3406'. Plug #2: Squeeze 85 sxs below retainer, spot 116 sxs on top to 2787'. Pump Plug #3 (50 sxs) from 2447' to 2180' POOH. Perf 4 holes @ 952'. RIH & set retainer @ 916'. Plug #4: Squeeze 45 sxs below retainer, spot 12 sxs on top to 852'. POOH. Perf 4 holes @ 223'. Pump Plug #5 (123 sxs), circulate good cement out bradenhead. WOC. ND BOP. Dig out wellhead & cut wellhead off. Inst. P&A marker. Top casing off with 20 sxs. RDMO A-Plug rig #4.

Changes in approved procedure were verbally approved by Steve Mason.

14. I hereby certify that the foregoing is true and correct.

Signed Ed Hasely Ed Hasely Title Environmental/Regulatory Engineer Date 10-20-94

(This space for Federal or State office use)

Approved by _____
Conditions of approval, if any:

Title _____

Date _____

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.