

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-4-135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input type="checkbox"/> Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other	7. If Unit or CA, Agreement Designation N/A
2. Name of Operator Amax Oil & Gas, Inc.	8. Well Name and No. Humble N. Kirtland #1
3. Address and Telephone No. P. O. Box 42806, Houston, Texas 77042-2806 (713) 978-7700	9. API Well No. 300451312300SI
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 1725' FNL, 880 FEL Sec. 13 - T30N - R14W	10. Field and Pool, or Exploratory Area Basin Dakota
	11. County or Parish, State San Juan, New Mexico

CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

2/26/92: MIRU. Pump 20 BW down tbg. ND wellhead & NU BOP. POOH & tally 172' ts. 2-3/8" tbg, 5413'. PU 4-1/2" csg scraper & RIH to 3462' - unable to go deeper. Pull 1 stand & SDFN.

2/27/92: POOH & LD scraper. RIH to 5413' - unable to go deeper. Plug #1 from 5387' to 4866' with 32 sxs Class B cement. POOH to 4500' & rev. circ. hole. Mix mud. RIH & tag cement @ 4793', spot 9.0 ppg from 4793' to 3300'. POOH w/tbg. & SDFN.

2/28/92: Perf. @ 3300'. RIH & set CR @ 3240', test tbg. Plug #2 from 3300' to 3100' with 71 sxs cement, 55 sxs outside & 11 above CR. Mix & spot 9.0 mud from 3052' to 1655'. POOH. Perf @ 1655'. RIH & set CR @ 1604'. Plug #3 from 1655' to 1000' with 216 sxs, 167 outside & 45 above. POOH w/setting tool. SDFN.

3/2/92: RIH & tag cmt @ 950'. Mix 9.0 mud & spot from 950' to 293'. POOH & LD tbg. Press. test csg to 500#, OK. Perf @ 293'. Establish circ. out bradenhead. Plug #4 from 293' to surface with 80 sxs Class B cmt, circ. good cmt to surface. ND BOP & cut off wellhead. Install P&A marker. RD. Move off location.

APPROVED

14. I hereby certify that the foregoing is true and correct

Signed Carl Strubbe

Title District Engineer

Date 3/18/92
MAR 24 1992

(This space for Federal or State office use)

Approved by _____
Conditions of approval, if any:

Title _____

AREA MANAGER