

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

**DISTRICT I**  
P.O. Box 1980, Hobbs, NM 88240  
**DISTRICT II**  
P.O. Drawer DD, Artesia, NM 88210  
**DISTRICT III**  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. <b>30-045-21182</b>
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name
8. Well No. <b>CAMPBELL #1</b>
9. Pool name or Wildcat <b>AZTEC P.C.</b>

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER:	
2. Name of Operator <b>ROBERT L. BAYLESS</b>	
3. Address of Operator <b>P.O. BOX 168 FARMINGTON, NM 87499</b>	
4. Well Location Unit Letter <b>A</b> : <b>1190</b> Feet from the <b>NORTH</b> Line and <b>805</b> Feet from The <b>EAST</b> Line Section <b>30</b> Township <b>30N</b> Range <b>11W</b> NMPM <b>SAN JUAN</b> County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) <b>5571 GR</b>	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO :		SUBSEQUENT REPORT OF :	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Robert L. Bayless plugged and abandoned this well on July 18, 2002. The procedure is attached.



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tom McCarthy TITLE ENGINEER DATE 8/6/02

TYPE OR PRINT NAME Tom McCarthy TELEPHONE NO. (505) 326-2659

(This space for State Use) **ORIGINAL SIGNED BY E. VILLANUEVA** **DEPUTY OIL & GAS INSPECTOR, DIST. #5** **AUG - 8 2002**  
APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY:

**Robert L. Bayless**

**Plug and Abandon Report**

Campbell No. 1

1190' FNL & 805' FEL, Section 30, T30N, R11W

San Juan County, NM

7/12/2002: Move in and rig up JC Well Service. Trip in and tag PBD at 2094' KB. Trip out with tubing and tally 64 joints 2 3/8", 1999.5'. Eighteen joints were bad. Trip in and set cement retainer at 1942'.

7/15/2002: Haul cement to location. Nipple up BOP.

7/16/2002: Sting out of retainer. Circulate well. Sting in to retainer. Mix and pump 18 sxs cement. Pump 10 sxs cement below retainer. Sting out of retainer. Started displacement and cement pump quit working after pumping 1.75 BBLs. Pulled string wet. Trip in with 30 joints tubing. OCD on location.

7/17/2002: Trip in to top of retainer. Mix 8 sxs cement and set balanced plug. Trip out tubing. Rig up to perforate. Perforate 2 holes at 700'. Attempted to pump in to perfs but could not. Perforate 2 holes at 600'. Attempted to pump in to holes again but could not. Trip in with tubing to 750', and set 21 sxs balanced plug. Trip out with tubing. OCD on location.

7/18/2002: Trip in with sand line and tag plug at 460'. Rig up to perforate and perforate 2 holes at 150'. Could not pump in to squeeze holes. Trip in tubing to 210' and pump 18 sxs cement back to surface. Trip out tubing. OCD on location. Nipple down BOP. Rig down and move equipment off location.

7/19/2002: Cut off casing and wellhead and install marker. Cut off and cap flowline. Backfill workover pit. Dig out and cut off anchors. Load and haul out tubing and well equipment.

El Paso has removed the meter run. The location is still in use by El Paso for a meter servicing a well operated by another party.