

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

**DISTRICT I**  
P.O. Box 1980, Hobbs, NM 88240

**DISTRICT II**  
P.O. Drawer DD, Artesia, NM 88210

**DISTRICT III**  
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.

30-045-22442

3. Indicate Type of Lease

STATE ☐

FREE ☒

6. State Oil & Gas Lease No.

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

Yager

1. Type of Well:

OIL  
WELL ☐

GAS  
WELL ☒

OTHER

2. Name of Operator

Hallwood Petroleum, Inc.

3. Address of Operator

P.O. Box 378111, Denver, CO 80237

8. Well No.

3

9. Pool name or Wildcat

Los Pinos (Pictured Cliffs)

4. Well Location

Unit Letter N : 800 Feet From The South Line and 1,850 Feet From The West Line

Section 3 Township 31N Range 7W NMPM San Juan County

10. Elevation (Show whether LF, RKB, RT, GR, etc.)

6,597' KB & 6,586' GL

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☒

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Hallwood Petroleum, Inc. plugged and abandoned this  
well per the attached Plugging Summary.

**RECEIVED**  
JUN 20 1994

**OIL CON. DIV.**  
**DIST. 3**

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Kevin E. O'Connell*

TITLE Drlg. & Prod. Manager

DATE 6/16/94

(303)

TYPE OR PRINT NAME

Kevin E. O'Connell

TELEPHONE NO. 850-630

(This space for State Use)

APPROVED BY

*Johnny Robinson*

TITLE Oil & Gas Inspector

DATE 6-30-94

CONDITIONS OF APPROVAL, IF ANY:

PLUGGING SUMMARY  
YAGER #3  
SAN JUAN COUNTY, NEW MEXICO

For plug and abandonment of your Yager #3 (Ft/PC), well located/in SW, Sec. 3, T31N, R7W, San Juan County, NM.

- 5-16-94 Safety Meeting. Drive rig to location. Spot rig. Check pressures on well: Pictured Cliffs tubing 1150 psi, Fruitland tubing and casing 1150 psi. Too windy to rig up. SDFN.
- 5-17-94 Safety Meeting. RU rig. RU blow down lines. Open up well and blow down casing and Fruitland tubing. Pump 30 bbls water down tubing to kill Pictured Cliffs. ND wellhead. NU BOP. Change over for 1-1/2" tubing. POH and LD 100 jts of 1-1/2" tubing. Change over for 2-3/8" tubing. PU 2-3/8" tubing; unable to work seal assembly free from packer. Establish rate into Pictured Cliffs perfs 2 bpm at 300#. Plug #1 with 24 sxs Class B cement from 3380' to packer at 3318' over PC perfs. Shut in well. SDFN.
- 5-18-94 Safety Meeting. Open up well. Blow down casing. RU wireline. RIH down tubing and tag top of cement at 3273'. POH and RU 1-13/16" cutter. RIH with wireline and jet cut tubing at 3120'. POH with wireline. Plug #2 with 175 sxs Class B cement from 3120' to 2212' over Fruitland perfs and above Ojo Alamo. POH and tally tubing. WOC. RIH with wireline and tag top of cement at 2238'. POH with wireline. Pressure test casing to 500#; OK. Perforate 4 holes at 840'. Establish rate into Nacimiento squeeze holes 2-1/2" bpm at 300#. Establish circulation out bradenhead with 6 bbls water. Plug #3 with 73 sxs cement from 840' to 650', squeezed 37 sxs cement outside casing and left 36 sxs inside. Shut in well. SDFN.
- 5-19-94 Safety Meeting. Open up well. RU wireline. RIH and tag top of cement at 657'. Perforate 4 squeeze holes at 300'. Establish circulation out bradenhead with 3 bbls water. Plug #4 with 127 sxs Class B cement from 300' to surface, circulated good cement out bradenhead. Shut in well and WOC. Dig out wellhead. Open up well ND BOP. Cut wellhead off. Install P&A marker with 20 sxs Class B cement. Rig down and move off location.