Form 3160-5 (June 1990)

Approved by

Conditions of approval, if any:

or representations as to any matter within its jurisdiction.

## UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

**FORM APPROVED Budget Bureau No. 1004-0135** 

Expires: March 31, 1993

5. Lease Designation and Serial No. SUNDRY NOTICES AND REPORT ON WELLS SF-078387-A Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use "APPLICATION FOR PERMIT" - for such proposals. 6. If Indian, Allottee or Tribe Name 7. If Unit or CA, Agreement Designation 1. Type of Well 8. Well Name and No. Gas Well Well Other Kernaghan B 5 2. Name of Operator Attention: 9. API Well No. **Amoco Production Company** Patty Haefele 3004527338 3. Address and Telephone No. 10. Field and Pool, or Exploratory Area P.O. Box 800, Denver, Colorado 80201 (303) 830-4988 **Basin Fruitland Coal** 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 11. County or Parish, State 1210' FNL & 1115' FEL Section 28 **T31N R8W** Unit A San Juan, New Mexico CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA 12. TYPE OF SUBMISSION TYPE OF ACTION ☐ Abandonment Change of Plans Notice of Intent ☐ Recompletion New Construction Plugging Back Non-Routine Fracturing Casing Repair Water Shut-off Subsequent Report **Altering Casing** Conversion to Injection Other Clean out ☐ Dispose Water Final Abandonment Notice (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log Form.) 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) Amoco Production Company requests permission to clean out this open hole well per the attached procedure. CH. COM. DIV. 14. I hereby certify that the foregoing is true and correct Signed Staff Assistant 10/10/96 (This space for Federal or State office use)

\* See Instructions on Reverse Side

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the

/S/ Duane W. Spences

false, fictitious, or fraudulent statement

## **SJOET Well Work Procedure**

# C E	October 10, 1996 Expense/Well Repair			
vork strir open hol th work s	ng to cleanout well to 1 le, slightly surging well string and TIH with 2 7	D. FD. if necessary, a /8" tubing and f	and flowtest.	
210' FNI an Juan ew Mexi F-07838	L x 1115' FEL; 28-T31 ico	N, R08W	Horizon: API #: Engr: Phone:	FT 30-045-27338 R. DeHerrera H-(303)439-7893 W-(303)830-4946
it: Mo. P.O. 5:	50% \$75,000 3 Months . \$276,602	Anticipate Prod. Bef Anticipate	ed Prod.: ore Repair ed Prod.:	6250 MCFD 7250 MCFD eeding ONE year.
2998		MesaVerde: Point Lookoเ		
	th existire vork string open hoo the work string open hoo the work subing he work string open hoo the work string open ho	#1 October 10, 1996 Expense/Well Repair Cleanout  th existing 4 1/2" tubing and LE work string to cleanout well to 1 open hole, slightly surging well th work string and TIH with 2 7 ubing head and casing valves  rmation: 210' FNL x 1115' FEL; 28-T31 an Juan lew Mexico 1F-078387-A 03038  ormation: 50% st: \$75,000 3 Months Mo. P.O. \$276,602  5: nomics will be run on all pro- ps: (Estimated formation tops)	#1 October 10, 1996 Expense/Well Repair Cleanout  th existing 4 1/2" tubing and LD. work string to cleanout well to TD. open hole, slightly surging well if necessary, a th work string and TIH with 2 7/8" tubing and f ubing head and casing valves to full opening.  rmation: 210' FNL x 1115' FEL; 28-T31N, R08W ian Juan lew Mexico iF-078387-A 03038  ormation: 50% Prod. Bef st: \$75,000 Anticipate 3 Months Prod. Bef Mo. P.O. \$276,602 Anticipate 5: nomics will be run on all projects that have ps: (Estimated formation tops)  MesaVerde: Point Lookou Mancos Shal Gallup: Graneros: Dakota:	#1 October 10, 1996 Expense/Well Repair Cleanout  th existing 4 1/2" tubing and LD. work string to cleanout well to TD. open hole, slightly surging well if necessary, and flowtest. th work string and TIH with 2 7/8" tubing and flowback. ubing head and casing valves to full opening.  rmation: 210' FNL x 1115' FEL; 28-T31N, R08W API #: lew Mexico Engr: F-078387-A O3038  Prod. Before Repair: Anticipated Prod.: 3 Months Prod. Before Repair Mo. P.O. \$276,602 Anticipated Prod.: 5: nomics will be run on all projects that have a payout excerps: (Estimated formation tops)  MesaVerde: Point Lookout: Mancos Shale: Gallup: Graneros: Dakota:

Tubing: Test Date:

Casing:

BH:

Time	вн	CSG	INT	CSG
5 min				
10 min				
15 min				

Comments:

Orig. Comp. 7/89 TD= 3186 Page 2 of 2

## HIGH VOLUME WELL--DO NOT PROCEED UNTIL YOU ARE CERTAIN THAT ALL PRECAUTIONS HAVE BEEN TAKEN. CALL ME AT NUMBERS LISTED BELOW IF IN DOUBT.

- 1. MIRURT complete with 3.500" drill pipe, 4.750" drill collars and air package.
- 2. ND tree, rig up BOP's w/cavitation capability complete with venturis on blooic lines. Test BOE. Sct pump-through plug in 2.75" "f' nipple at 2927'. With additional joints of 4 1/2" tubing, tag fill depth. TOOH with 4 1/2" tubing, laying it down. NOTE: SHOULD IT BECOME APPARENT THAT YOU CAN NOT SAFELY PULL THE TUBING WITHOUT ASSISTANCE FROM A SNUBBING UNIT; CALL ONE OUT AND RIG UP. Change pipe rams to permit running the 3.500" drill pipe.
- 3. Pick up a 6.250" mill tooth bit, 3.500" drill pipe, and 4.750" drill collars and clean out fill to total depth (3186') using air and foam. Rotate and reciprocate on bottom until hole is clean. POOH with drill pipe so bottom of tubing is above 7" casing shoe at 2997'.
- 4. Flow test well up both tubing and casing for 1 hour through 3/4" choke and record pressures every 10 minutes. Shut well in and wait for 4 hours, record pressures every 10 minutes for first hour then every hour following.
- 5. TIH with tubing and check to determine amount of fill and how difficult it is to clean up. Repeat clean out, flow test, and shut in if necessary and stabilize hole as quickly as possible to allow running tubing. Once hole is stabilized, proceed to next step. Slight surging of the well may be necessary to stabilize open hole.
- 6. Lay down drill string, change pipe rams as necessary to run the 2 7/8" tubing string. Pick up a 2 7/8" Closed End Half Mule shoe, 10' perforated sub, profile nipple and 2 7/8" tubing. Install profile nipple with retrievable plug in place and run in with the 2 7/8" tubing. Land tubing at 3090'. Profile nipple needs to be at the bottom of the tubing just above the perforated sub assembly.
- 7. ND BOE, NU tree and RDMORT. Tie well back into surface equipment, retrieve plug and bring well on line slowly in an attempt to minimize any cavitation effect. Turn over to production

Dependent on speed of hole stabilization, I estimate this procedure to require approximately 5 days and to cost approximately \$75,000.

## **Tubing Head Replacement**

This can be completed any time during the workover. Many of the high rate fruitland coal wells are produced through the tubing string and the tubing/casing annulus. The 7 1/16" 3000# x 11" 3000# tubing heads on the wells were outfitted with flanged 2 1/8" casing valves. The threaded outlet in the head is 1 1/2" in diameter. We need an additional head with the outlets full opening and the ability to accommodate full opening casing valves. FMC is aware of our plans and is scrambling to accommodate this request.

If problems are encountered, please contact:

Robert DeHerrera (W) (303)830-4946 (H) (303)439-7893