UNITED STATES

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

Sundry Notices and Reports on Wells	1:02
	5. Lease Number SF-078144
1. Type of Well GAS	6. If Indian, All. or Tribe Name
	Unit Agreement Nam
2. Name of Operator	000
RESOURCES OIL & GAS COMPANY	and all
les os co	8. Well Name & Number
3. Address & Phone No. of Operator	Lloyd #2A S. API Well No.
PO Box 4289, Farmington, NM 87499 (505) 326-9700.	30-045-29531
4. Location of Well, Footage, Sec., T, R, M	10. Field and Pool
915'FNL, 1485'FWL, Sec.24, T-30-N, R-11-W, NMPM	WC. 30NIIW 24 Chacr
	Blanco Mesaverde 11. County and State
	San Juan Co, NM
12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPO Type of Submission Type of Action	ORT, OTHER DATA
1/90 01 040=======	inge of Plans
X Recompletion New	/ Construction
<u> </u>	n-Routine Fracturing
· · · · · · · · · · · · · · · · ·	er Shut off nversion to Injection
Final Abandonment Altering Casing Cor Other -	iversion to injection
13. Describe Proposed or Completed Operations	
It is intended to recomplete the subject well in the (Thacra formation
according to the attached procedure and wellbore dia	agram.
according to the doubled positions	
14. I hereby certify that the foregoing is true and corre	ct.
Signed Search (ACC (MQ) Title Regulatory Admin	istrator Date 3/2/00
Signed (MQ) Title Regulatory Admin	TLW
(This space for Federal or State Office use)) 188A
APPROVED BY /s/ Charlie Beecham ^{Title}	Date
CONDITION OF APPROVAL, if any:	ny department or agency of the
Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to a United States any false, fictitious or fraudulent statements or representations as to any matter w	ithin its jurisdiction.

District I 20 Box 1980. Hopps. NM 88241-1980

State of New Mexico Energy, Minerals & Natural Resources Department

Form C-102 Revised February 21, 1994 Instructions on back

Submit to Appropriate District Office State Lease - 4 Copies Fee Lease - 3 Copies

OIL CONSERVATION DIVISION

District III 1000 Rio Brazos Rd., Aztec, NM 87410

District II PO Drawer OD, Antesia, NM 88211-0719

PO Box 2088 Santa Fe. NM 87504-2088

R' : 🖸 AMENDED REPORT

District IV PO Box 2088. Santa Fe. NM 87504-2088


WELL LOCATION AND ACREAGE DEDICATION PLAT

'API Number	Pool Code Pool Name		
30-045-29531	72319/	Blanco Mesaverde/WC:30N	
'Property Code 7269		•Well Number	
'OGRID No.		Operator Name URCES OIL & GAS COMPANY	*Elevation 6146

¹⁰ Surface Location

					JG1 1 JCC 1				
UL or lot no.	Section	Township	Range	Lot Idn	Feet from the	North/South line	Feet from the	East/West line	County
С	24	30N	11W		915	North	1485	West	SAN JUAN
		11 [Bottom	Hole L	ocation I	f Different			
UL or lot no.	Section	TOWNSTA	Range	Lot Idn	Feet from the	Namth/South line	Feet from the	East/West line	County
¹² Dedicated Acres		13 Jount on Ir	nfall ¹⁴ Con	eplidation Code	¹⁵ Onder No.				

NO ALLOWABLE WILL BE ASSIGNED TO THIS COMPLETION UNTIL ALL INTERESTS HAVE BEEN CONSOLIDATED OR A NON-STANDARD UNIT HAS BEEN APPROVED BY THE DIVISION



Chacra Recompletion Procedure Unit C, Section 24, T-30N, R-11 W

Lat: 36° 48.13' Long: 107° 56.76'

This well was originally drilled in 1998 and is currently completed in the Menefee and Point Lookout. It is intended to recomplete the Chacra (Lewis Shale) and commingle with the existing production. The Chacra will be sand fracture stimulated in two stages using 100,000 lbs 20/40 sand and 75Q 20 lb linear gel in each stage. Foam will be used to limit fluid damage and aid in the flowback. The flowback choke schedule is to be used to ensure that the proppant remains in the fractures.

- > Comply with all BLM, NMOCD, and BR rules and regulations.
- > Hold safety meetings.
- > Place fire safety equipment in strategic locations.
- > Inspect location and test rig anchors.
- Dig flowback pit or set flowback tank.
- > Set and fill 3-400 BBL Frac tanks w/ 2% KCl water. Test and filter if necessary.

Equipment Needed:

- (3) Frac Tanks with 2% KCI water
- (2) 4-1/2" CIBP
- (1) 4-1/2" RBP
- (1) 4-1/2" Packer

PROCEDURE:

- MIRU. Record and report SI pressures on tubing, casing, and bradenhead. Lay blowdown line and blow well down.
 Kill well with 2% KCI water. ND WH, NU BOP. Test and record operation of rams. NU blooie line and 2-7/8" relief line. Redress production wellhead as needed.
- 2. TOOH w/ 2-3/8" 4.7# J-55 tubing set at 5014' (SN @ 4982'). Visually inspect tubing, note and report any corrosion and/or scale** in/on tubing. Replace bad joints as needed.
 - ** If tubing is scaled up, contact the production engineer so a scale analysis can be run to determine if an acid treatment is needed.
- 3. RU wireline. Run 4-1/2" gauge ring to 4120'. If ring tags up before 4120', TIH with 3-7/8" Bit, 4-1/2" 10.5# casing scraper on 2-3/8" tubing and CO to 5232'. TOOH. RIH with 4-1/2" CIBP and wireline set CIBP @ ± 4100'. Load Hole w/ 2% KCI water. Pressure Test Casing to 3000 psi.
- 4. Correlate to CBL/CCL/GR log and perforate the Lower Chacra as follows using Scallop HSC guns loaded with TAG-4000-311T 23 gm, .42" diameter, 22.2" penetration charges at 1 SPF in the following intervals from bottom up:

4048-38, 4013-03, 3970-60, 3932-22, 3854-44, 3772-62

RD wireline.

5. TIH with 4-1/2" RBP, on/off tool and 4-1/2" packer on 2-3/8" tubing.

Set RBP at RBP setting depth. PUH ± 10 ft and set Packer. RU stimulation company and pressure test RBP and lines to 3800 psi. Release packer, and reset packer at Packer Setting Depth. Breakdown perforations and establish an injection rate between 8 and 10 BPM with 333 gals of Acetic Acid + 5% NH4Cl **. Breakdown to the Max pressure of 3800 psi. Release packer and RBP. Repeat for the remaining intervals.

** All Acid to contain the following additives/ 1000 gal:

1000 gal 10% Acetic Acid
2 gal MSA II corrosion inhibitor
5% NH₄CL clay control

Chacra Recompletion Procedure
Unit C, Section 24, T-30N, R-11 W
at: 36° 48 13' Long: 107° 56 76'

Lat: 36° 48.13' Long: 107° 56.76'

RBP Setting Depth	Packer Setting Depth	Perforation Intervals
4090	398 0	4003-13, 4038-48
3990	3870	3922-32, 3960-70
3910	3700	3762-72, 3844-54

- 6. TOOH w/ RBP, Packer, and 2-3/8" tubing.
- 7. Pressure Test surface lines to 4000 psi. Fracture stimulate Lower Chacra with 100,000 lbs 20/40 sand in 75Q foam w/ 20 lb linear gel at a rate of 35 BPM in 0.5 to 3.0 ppg stages. Tag sand with 3 radioactive isotopes. Maximum Surface Treating Pressure is 3000 psi. At 35 BPM friction pressure is approximately 570 psi. Slow rate during flush. Flush to 50' above top perf with 75Q foam.
- 8. Record ISIP, 5, 10 and 15 shut-in pressure. Shut-in frac valve. RD stimulation company. Install flowback line above frac valve. Lay flowback line to dual-choke manifold and pit. Begin flowback after stimulation company has rigged down from frac valve. Open well to pit on accordance with flowback schedule listed in the table below. Do not shut well in during flowback. When schedule dictates a larger choke size, open ball valve upstream of adjustable choke and open adjustable choke on manifold to pre-determined size listed in table and begin flowing through adjustable choke. Close ball valve upstream of positive flow bean and change out flow bean to next larger size in table. Open ball valve upstream of positive flow bean and begin flowing. Close ball valve upstream of adjustable choke and close adjustable choke.

10/64" Choke	Approximately 2 hrs.
12/64" Choke	Approximately 2 hrs.
14/64" Choke	Approximately 2 hrs.
16/64" Choke	Approximately 3 hrs.
18/64" Choke	Approximately 3 hrs.
20/64" Choke	Approximately 3 hrs.
22/64" Choke	Approximately 3 hrs.
24/64" Choke	Approximately 3 hrs.
32/64" Choke	Approximately 3 hrs.

NOTE: Follow this schedule to utilize a 24+ hour flowback. If well begins to slug or make large amounts of sand to surface, drop to next lower choke size. If well begins to taper off in liquid production (mostly N_2), change to next larger choke size before time schedule dictates.

- 9. RU wireline. RIH w/ 4-1/2" CIBP and wireline set CIBP @ ± 3740'. Pressure test CIBP and casing to 3000 psi.
- 10. Correlate to CBL/CCL/GR and perforate the Upper Chacra as follows using Scallop HSC guns loaded with TAG-4000-311T 23 gm, .42" diameter, 22.2" penetration charges at 1 SPF in the following intervals from bottom up:

3670-60, 3633-23, 3570-60, 3535-25, 3469-59, 3424-14

RD wireline.

11. TIH with 4-1/2" RBP, on/off tool and 4-1/2" packer on 2-3/8" tubing.

Set RBP at RBP setting depth. PUH ± 10 ft and set Packer. RU stimulation company and pressure test RBP and lines to 3800 psi. Release packer, and reset packer at Packer Setting Depth. Breakdown perforations and establish an injection rate between 8 and 10 BPM with 333 gals of Acetic Acid + 5% NH4Cl **. Breakdown to the Max pressure of 3800 psi. Release packer and RBP. Repeat for the remaining intervals.

Chacra Recompletion Procedure Unit C, Section 24, T-30N, R-11 W Lat: 36° 48.13' Long: 107° 56.76'

** All Acid to contain the following additives/ 1000 gat:

1000 gal	10%	Acetic Acid
-		· · · · · · · · · ·
2 g a l	MSA II	corrosion inhibitor
5%	NH₄CL	clay control

RBP Setting Depth	Packer Setting Depth	Perforation Intervals
3730	3580	3623-33, 3660-70
3610	3480	3525-35, 3560-70
3510	3350	3414-24, 3459-69

- 12. TOOH w/ RBP, Packer, and 2-3/8" tubing and stand back.
- 13. Pressure Test surface lines to 4000 psi. Fracture stimulate Upper Chacra with 100,000 lbs 20/40 sand in 75Q foam w/ 20 lb linear gel at a rate of 35 BPM in 0.5 to 3.0 ppg stages. Tag sand with 3 radioactive isotopes. Maximum Surface Treating Pressure is 3000 psi. At 35 BPM friction pressure is approximately 450 psi. Slow rate during flush. Flush to 50' above top perf with 75Q foam.
- 14. Record ISIP, 5, 10 and 15 shut-in pressure. Shut-in frac valve. RD stimulation company. Install flowback line above frac valve. Lay flowback line to dual-choke manifold and pit. Begin flowback after stimulation company has rigged down from frac valve. Open well to pit on accordance with flowback schedule listed in the table below. Do not shut well in during flowback. When schedule dictates a larger choke size, open ball valve upstream of adjustable choke and open adjustable choke on manifold to pre-determined size listed in table and begin flowing through adjustable choke. Close ball valve upstream of positive flow bean and change out flow bean to next larger size in table. Open ball valve upstream of positive flow bean and begin flowing. Close ball valve upstream of adjustable choke and close adjustable choke.

10/64" Choke	Approximately 2 hrs.
12/64" Choke	Approximately 2 hrs.
14/64" Choke	Approximately 2 hrs.
16/64" Choke	Approximately 3 hrs.
18/64" Choke	Approximately 3 hrs.
20/64" Choke	Approximately 3 hrs.
22/64" Choke	Approximately 3 hrs.
24/64" Choke	Approximately 3 hrs.
32/64" Choke	Approximately 3 hrs.

NOTE: Follow this schedule to utilize a 24+ hour flowback. If well begins to slug or make large amounts of sand to surface, drop to next lower choke size. If well begins to taper off in liquid production (mostly N_2), change to next larger choke size before time schedule dictates.

- 15. TIH w/ 3-7/8" bit on 2-3/8" tubing and CO to CIBP @ 3740'. Monitor gas and water returns. When sand and water allow (less than 5 BPH and trace sand), take a Upper Chacra pitot gauge. DO CIBP @ 3740' with a minimum of 12 BPH mist rate.
- 16. CO to CIBP @ 4100'. Monitor gas and water returns. When sand and water allow (less than 5 BPH and trace sand), take a complete Chacra pitot gauge. DO CIBP @ 4100' with a minimum of 12 BPH mist rate.
- 17. Continue to CO to PBTD with air. Blow well at PBTD and monitor water rates. If needed continue to blow well for clean up. When water rates are below 5 BPH and there is no sand production, TOOH.

Chacra Recompletion Procedure Unit C, Section 24, T-30N, R-11 W Lat: 36° 48.13' Long: 107° 56.76'

18.	TIH with an expendable check, one 2-3/8" joint, seating nipple, and remaining production tubing. Broach tubing v	vhile
	running in hole. CO with air/mist to PBTD again, if necessary. Obtain final pitot gauge. Land tubing at ± 5070'.	ND
	BOP. NU WH. Pump off expendable check. RDMO. Contact Production Operations for well tie-in.	

19. RU Pro-Technics. Run After Frac Log across Chacra (4200' - 3300'). RD Pro-Technics.

Approved: _

Contact:

Michele Quisel 324-6162 (WORK)

326-8196(PAGER)

564-9097(HOME)

Vendors:

Wireline:

Schlumberger

325-5006

RA Tagging:

Pro-Technics

326-7133

915' FNL, 1485' FWL Unit C Sec.24, T-30 R-11W San Juan County, New Mexico

KB 6158

GL 6146

Lat: 36o 48.13'

Long: 107o 56.76'

