

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF 078128

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Turner

9. WELL NO.

2 (OWO)

10. FIELD AND POOL, OR WILDCAT

Blanco M. V.

11. SEC., T., B., M., OR BLK. AND SURVEY OR AREA

**Sec. 13, T-30-N, R-10-W
N.M.P.M.**

12. COUNTY OR PARISH 13. STATE

San Juan

New Mexico

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR

El Paso Natural Gas Company

3. ADDRESS OF OPERATOR

Box 990, Farmington, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.)
At surface

1650'N, 1650'E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6531' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON**

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Due to casing failure & non-production it is intended to repair this well in the following manner:

If tubing can be pulled -

Clean out to 5590' and set top drillable bridge plug at approximately 5295'.

Locate leak & perf and squeeze w/100 sks. cement.

Drill bridge plug & clean out to 5590'.

Run full string of 4 1/2" casing & cement bringing cement up into 7" casing.

5. Perf. & frac Mesa Verde and complete well.

If tubing cannot be pulled -

Cut tubing off approximately 50' below 7" casing shoe & pull.



Set cement retainer at approximately 5295' & squeeze open hole.

Locate leak & perf & squeeze w/100 sks. cement.

Drill retainer, set whipstock & drill to 5590'.

Run full string of 4 1/2" casing & cement bringing cement up into 7" casing.

Perf & frac Mesa Verde & complete well.



18. I hereby certify that the foregoing is true and correct

SIGNED **ORIGINAL SIGNED E. S. OBERLY**

TITLE **Petroleum Engineer**

DATE **6-3-64**

(This space for Federal or State office use)

APPROVED BY _____

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY:

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.