

RECEIVED

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY
GRAND JUNCTION, CO

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-0 for such proposals.

1. ☐ Oil Well ☐ Gas Well ☐ Other ☐ Infection

2. NAME OF OPERATOR ARCO Oil and Gas Co., a Division of Atlantic Richfield Company

3. ADDRESS OF OPERATOR 707 - 17th Street, P.O. Box 5540, Denver, Colo. 80217

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.) Unit J,
AT SURFACE: 2080' FSL & 2030' FEL, Sec. 34
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF	<input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)	<input type="checkbox"/>	<input type="checkbox"/>

5. LEASE 14-20-604-1951

6. INDIAN ALLOTTEE OR TRIBE NAME Ute Mtn.

7. UNIT AGREEMENT NAME Horseshoe Gallup Unit

8. FARM OR LEASE NAME Horseshoe Gallup Unit

9. WELL NO. 203

10. FIELD OR WILDCAT NAME Horseshoe Gallup

11. SEC., T., R., W. OR BLK. AND SURVEY OR AREA Sec. 34-31N-16W

12. COUNTY OR PARISH 13. STATE San Juan New Mexico

14. API NO. None Assigned

15. ELEVATIONS (SHOW OF, KDB, AND WD) 5415' GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This notice supercedes our Sundry Notices dated August 31, 1982, on the subject well. 4/11-1-82

ARCO now proposes to plug and abandon this well, as per the attached revised P & A Procedure.

(This is in compliance with the requirements as set forth in a memorandum dated September 30, 1981, and a subsequent letter of April 26, 1982, both from the State of New Mexico, Energy and Minerals Department, Oil Conservation Division (copies attached to our August 31, 1982 Sundry Notice).)

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Stephen Rose TITLE Dist. Prod. Supt. DATE December 30
S. C. ROSE November 1, 1982

APPROVED BY Original Signed - Scott L. Ellis (This space for Federal or State office use)
CONDITIONS OF APPROVAL IF ANY: for JOHN L. PRICE
District Supervisor

RECEIVED

JAN 17 1983

OIL CON. DIV.

*See Instructions on Reverse Side

HORSESHOE GALLUP UNIT INJECTION WELLS
PLUGGING AND ABANDONMENT PROCEDURE
(REVISED)

1. MIRU.
 2. Release packer and pull tubing and packer out of hole.
 3. RIH with tbg open-ended to below the bottom perforation and pump sufficient cement to cover top perforation by 50' inside the casing.
 4. POH w/tbg. GIH w/wireline and shoot enough holes in production string opposite 150' above top perforation to allow cement squeezing of zone. (This may be necessary since the original cement job may not have covered the Gallup formation by 50'). Squeeze sufficient cement to place a 100' plug outside the casing. Also, leave a 100' plug inside the casing. If unable to squeeze plug outside the casing, leave a 100' plug inside the casing.
 5. POH w/tbg. GIH w/wireline and shoot enough holes in production casing opposite a point 50' below the surface casing shoe to allow squeezing cement.
 6. RIH w/tbg open-ended and perform a braden-head squeeze of the perforations. Use sufficient cement for a 100' column behind the casing and a 100' plug inside the casing.
 7. POH, cut casing one foot below ground level, place a 30' cement plug inside casing, weld on a blind flange, weld a dry hole marker on the blind flange, fill hole and move off.
 8. Rehabilitate location and access road using stipulations supplied by the surface management agency.
- NOTE: BOP's will not be needed in most cases because expected reservoir pressure of the Gallup in the area of abandonment is very low. (Estimated at less than 250 - 300 psi bottom-hole.) If pressure does exist on any of the subject wells, bleed it off, install BOP's if needed, and commence with above procedure.

JAN 1988
OIL CON. DIV.
DIST. 3

LIST OF WELLS TO BE PLUGGED AND ABANDONED

TABLE I

Horseshoe Gallup Unit
Federal Lease No. 14-08-001-8200
San Juan County, New Mexico.

List of Wells

1. No. 106 1	21. No. 215 D	41. No. 223 D
2. No. 108 2	22. No. 162 D	42. No. 225 D
3. No. 103 A	23. No. 164 D	(State) 43. No. 227 D
4. No. 105 A	24. No. 163 D	44. No. 229 D
5. No. 113 A	25. No. 171 D	45. No. 238 D
6. No. 126 G	26. No. 173 D	(State) 46. No. 240 D
7. No. 130 C	27. No. 175 D	47. No. 248 D
8. No. 132 C	28. No. 180 D	48. No. 250 D
9. No. 135 C	29. No. 182 D	49. No. 259 D
10. No. 137 C	30. No. 184 D	50. No. 261 C
11. No. 139 C	31. No. 186 D	51. No. 263 C
12. No. 141 C	32. No. 192 D	52. No. 269 C
13. No. 143 D	33. No. 194 D	53. No. 274 C
14. No. 145 D	34. No. 196 D	54. No. 275 C
15. No. 148 D	35. No. 201 D	55. No. 73 A
16. No. 150 D	36. No. 203 D	56. No. 199 D
17. No. 152 D	37. No. 205 D	57. No. 211 D
18. No. 154 D	38. No. 207 D	
19. No. 156 D	39. No. 213 D	
20. No. 160 D	40. No. 217 D	