

**PAYNE FEDERAL #8 FRTC
P & A Procedure
K Sec 21 T32N R10W
San Juan County, New Mexico**

1. Comply with all NMOCD, BLM, & MOI rules and regulations. Test rig anchors & MI blow pit. MOL and RU completion rig. NU BOP and stripping head. Test operation of rams. Install 2-3/8" relief line. Blow well down.
2. TOH w/ 103 jts 2-7/8" tbg and visually inspect.
3. Run 5-1/2" csg scrapper on 2-7/8" tbg to 2700'. Do not exceed 2700' to reduce the chance of getting stuck below the bottom of the 5-1/2" liner which is set @ 2735'. TOH.
4. TIH w/ cmt retainer, set @ 2488'; pressure test tbg to 1500#. Establish rate into perforations. Plug #1 from 3054' to 2488' w/ 182 sxs Class B cmt (100% excess over the productive interval and 50% excess in the csg). Squeeze 177 sxs cmt under CR and spot 5 sxs above.
5. TOH to 2430' and spot 24 bbls 8.4# 40 vis mud to 1430'. TOH to 1430'
6. Plug #2 from 1430' to 1295' w/ 23 sxs Class B cmt (50% excess). TOH to 1220'. Spot 20 bbls 8.4# 40 vis mud to 400'. TOH to 400'.
7. Plug #3 from 400' to surface w/ approximately 46 sxs Class B cmt. Circ cmt to surface. TOH. LD tbg.
8. Cut off wellhead below surface casing flange and install dry hole marker to BLM specs. Release rig.
9. Restore location to BLM specs.

Approve: JB FRASER
J. B. Fraser

N. D. Rogers
N. D. Rogers

TJM:tjm