Submit 3 Copies to Appropriate District Office	State of New Energy, Minerals and Natura			Form C-103 Revised 1-1-89
DISTRICT I P.O. Box 1980, Hobbs, NM 88240			WELL API NO.	
DISTRICT II P.O. Drawer DD, Antesia, NM 88210  Santa Fe, New Mexico 87504-2088			5. Indicate Type of	Lease
DISTRICT III 1000 Rio Brazos Rd., Aziec, NM 87410			6. State Oil & Gas	STATE FEE XX
SUNDRY NOTICES AND REPORTS ON WELLS  ( DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  (FORM C-101) FOR SUCH PROPOSALS.)  1. Type of Well:  OIL  WELL  ONL  WELL  OTHER			7. Lease Name or V	Unit Agreement Name
2. Name of Operator			87 Well No.	
SNYDER OIL CORPORATION  3. Address of Operator P.O. BOX 2038, FARMINGTON, NEW MEXICO 87499			9. Pool name or W BASIN DAK	ildeat OTA/BLANCO MESA VERDE
4. Well Location Unit Letter N: 99	Feet From The S	v: 17	12'	The W Line
20	701	1 71.7	· · · · · · · · · · · · · · · · · · ·	
Section 40	10. Elevation (Show who	Range 13W ether DF, RKB, RT, GR, etc.)	NMPM SAN JU	JAIN County
11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data				
NOTICE OF IN			SSEQUENT RI	
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK		ALTERING CASING
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT				
PULL OR ALTER CASING CASING TEST AND CEN			EMENT JOB	
OTHER: OTHER:				·
12. Describe Proposed or Completed Openwork) SEE RULE 1103.	ations (Clearly state all pertinent detail	ils, and give pertinent dates, incl	uding estimated date of	starting any proposed
Plan to plug and abar	don this well per at	tached procedure.	AUG OIL CO	EIVE   1993 DN. DIV.
Thereby provides that the land Audion shows in	a and complete to the bast of my terminal	ond ballef		
I hereby certify that the information above is to	we and complete to the best of my knowledge	e and bear. District Eng	ineer	DATE 7/30/93
TYPE OR PRINT NAME				TELEPHONE NO.
(This space for State Use)			7.	
Original Signed by CH	ARLES GHOLSON	DEPUTY OIL & GAS II	NSPECTOR, DIST. #	AUG - 2 1993


CONDITIONS OF APPROVAL, IF ANY:

Ripley #1-26 (MV/Dk)
Unit N, Sec. 26, T32N, R13W
San Juan County, New Mexico

## PLUG AND ABANDONMENT PROCEDURE:

- 1. MOL and RUSU. Comply to all NMOCD, BLM and Snyder safety rules and regulations.
- 2. Blow well down; kill with water if necessary. ND wellhead and NU BOP and stripping head; test BOP.
- 3. NU offset spool (?) and POH with 1-1/4" tubing and LD; PU 7" casing scraper and 2" tubing work string; RIH and tag bottom; POH and LD scraper; PU 7" cement retainer and RIH; set at 4200' (above Dakota tubing and Mesaverde perforations); pressure test tubing to 1000#; pump into MV perfs.
- 4. Plug #1 under CR at 4200' to 4725' with 130 sxs Class B cement (20 sxs excess), squeeze 120 sxs below CR then spot 10 sxs on top. POH to 3801'. Circulate hole and pressure test casing to 500.
- 5. Plug #2 from 3801' to 3701' with 29 sxs Class B cement (Mesaverde top at 3751'). POH and LD setting tool.
- 6. Perforate 4 holes at 2190' (50' below PC top); PU 7" cement retainer and RIH; set at 2150'; establish rate into holes.
- 7. Plug #3 from 2190' to 1580' with 230 sxs Class B cement (FT top at 1580'); squeeze 120 sxs outside casing and spot 110 sxs inside casing; POH and LD tubing.
- 8. Perforate 2 holes at 233' and then establish circulation out bradenhead. Plug #4 from 233' to surface with approximately 90 sxs Class B cement, circulate good cement to surface; shut in well and WOC.
- 9. ND BOP and cut off wellhead below ground level and install dry hole marker. RD and MOSU. Restore location.

10-3/4" 32.75# @ 183' Cemented to surface



10-3/4" 32.75# @ 183' Cemented to surface

from 4877' to 7082'

