

STANDARD TIME 11:00
070 11:00 11:00 11:00

- Harrison petroleum*

Type of Action

RECEIVED
MAR 1 9 1957
OIL COM. DIV.
BUREAU

OIL CO. INC.

OIL CO. INC.

Signed William F. Clark Title Contractor Date 3/13/97
William F. Clark, A-Plus Well Service

APPROVED BY /S/ Duane W. Spencer Title _____ Date MAR 18 1997

NAOCOD

A - PLUS WELL SERVICE, INC.

P.O. BOX 1979
FARMINGTON, NM 87499
505-325-2627 • FAX: 505-325-1211

Texas Pacific Oil & Gas Co.,
c/o Joseph E. Seagram & Sons

Navajo #15

410' FSL and 2225' FWL Sec.27 , T-32-N, R-17-W,
San Juan County, NM
BIA 14-20-603-5012

March 12, 1997

Plug & Abandonment Report

Cementing Summary:

Plug #1 with 54 sxs Class B cement inside casing from 1296' to 597' to fill Gallup perforations and over top.

Plug #2 with 55 sxs Class B cement pumped down 4-1/2" casing from 80' to surface, circulate good cement out bradenhead.

Plugging Summary:

Notified BLM on 3-7-97

3-7-97 Road rig to location. Spot rig and equipment on location. SDFD.

3-10-97 Safety Meeting. RU rig and equipment. Open up well, no pressures. PU on rods and unseat pump. LD one rod and PU polish rod. RU hot oil truck. Hot oil tubing and casing with 40 bbls. Seat pump back and pressure test tubing to 500#; held OK. POH and LD 44 5/8" rods, 5 3/4" rods and pump, total 1237'. Break wellhead cap loose. Strip on 4-1/2" x 8-5/8" wellhead. NU BOP and test. RU rig floor and tubing equipment. PU 3 joints 2-3/8" tubing and RIH; tag fill at 1300'. PU to 1296'. Load casing with 3 bbls water and establish circulation. Plug #1 with 54 sxs Class B cement inside casing from 1296' to 597' to fill Gallup perforations and over top. POH and LD tubing, total 1240'. Shut in well and WOC over night. SDFD.

3-11-97 Safety Meeting. Open up well, no pressure. RU A-Plus wireline truck. RIH and tag cement at 728'. Pressure test casing to 300#, held OK. Perforate 2 squeeze holes at 80'. POH and RD wireline truck. Establish circulation down 4-1/2" casing and out 7" annulus with 5 bbls water. Plug #2 with 55 sxs Class B cement pumped down 4-1/2" casing from 80' to surface, circulate good cement out bradenhead. Shut in well and WOC. Open up well and ND BOP. Cut wellhead off, found cement down 20' in 4-1/2" casing and 7" annulus. Mix 20 sxs Class B cement and fill casing and annulus; then install P&A marker. RD rig and equipment; move off location.

J. Sanchez, BLM representative was on location.