

GROUND BED ABANDONMENT

WELL NAME: FIELDS LS 7-A

LOCATION: S34-T32N-R11W

- 1) Weld 6" dia. spool with diverter line to pit
- 2) MIRU
- 3) Wash in hole with 1 1/4" work-string. Circulate out coke breeze. Pull anodes as they come free. Wash hole to 240 ft.
- 4) Pump 80 sx of neat cement w/ 1/4 lb. sk. Flocele. Pull out work string.
- 5) Top off hole with cement, set flexible pipeline marker as PxA marker.
- 6) RDMO

Ground Bed Specifications

TD 240 ft.

Hole Dia. 6³/₄ inches.

Casing Dia. UNKNOWN inches

Casing Length UNKNOWN ft.



JAB.GRA