Desember luxus

### UNITED STATES DEPARTMENT OF THE INTERIOR

Budget Bureau No. 1004-1135

BUREAU OF	LAND MANAGEMENT	OIL CON. DIV.	5 Lease Designation and Serial No.
SUNDRY NOTICES	AND REPORTS ON WEL	LS \DIST. 3	SF-078840
Do not use this form for proposals to dr	ill or to deepen or reentry t R PERMIT—" for such prop	lo a different reservoir.	7 II maian, shorter of Fride Same
SUBMIT IN TRIPLICATE			7. If Unit or CA. Agreement Designation
1. Type of Well Oul Gas Well Other	•		8. Well Name and No.
1. Name of Operator Amoco Production Company	Attn: John Hamp	oton	San Juan 28-7 U 20 9 AM Well No.
P.O. Box 800, Denver, Colorad			30 039 21184 10 Field and Pool, or Exploratory Area
4 Location of Well (Footage, Sec., T. R., M., or Survey D 950' FSL, 1750' FEL SEC.		Longe	Rio New Mexico
CHECK APPROPRIATE BOX	s) TO INDICATE NATUR	E OF NOTICE, REPOR	T, OR OTHER DATA
TYPE OF SUBMISSION		TYPE OF ACTION	
Notice of Intent  Subsequent Report	Abandonment Recompletion Plugging Baci		Change of Plans New Construction Non-Routine Fracturing
Erval Abandonment Nouce	Casing Repair Alternag Casin Other	ng	Water Shut-Off Conversion to Injection  multiple completion on Well Completion of
13 Describe Proposed or Completed Operations (Clearly state a give subsurface locations and measured and true verti	Il pertinent details, and give pertinent date cal depths for all markers and zones per	Recompletion Report at es, including estimated date of starting tinent to this work, if	

Amoco Production Company intends to Plug and Abandon the above subject well. Please see the attached procedures:

If you have any questions please contact Cindy Burton @ 830-5119.


6. I hereby certify that the foregoing is true and corn Signed JOhn J. HON	. 1 1	aff Admin. Supv.	DAIR 9/6/90
(Thus space for Federal or State office use)	/T.M.T.	Kon	Temporal I
Approved by	Title		Date
tle 18 U.S.C. Socoon 1001, makes it a crime for an		especial Control	<del> </del>

#### Plug and Abandonment Procedure San Juan 28-7 Unit 205 180 - T27N - R7W

- 1. MIRUSU. NDWH. NUBOPE. POOH w/ 1 1/4" tubing. (Notify BLM (505) 327-5344 when plugging is to begin).
- 2. RIH over parted casing at 240' w/skirted overshot and 2 7/8" casing back to surface.
- 3. RIH w/ 1 1/4" tbg and retrieve RBP at 3850'.
- 4. RIH w/cement retainer and set at 3800'. Sting into retainer and squeeze Chacra perforations with 10 cu. ft. cement. Pull out of retainer and spot cement from top of retainer to 2300' (50 cu. ft. of cement). POOH w/tbg.
- 5. RIH w/gun and perforate four 1/2" holes at 2100'. POOH w/gun. RIH and set cement retainer at 1950'. Sting into retainer and squeeze with 100 cu. ft. of cement. Pull out of retainer and leave cement plug on top of retainer to 1000' (30 cu. ft.).
- 6. POOH w/tbg. RIH w/gun and perforate four 1/2" holes at 950'. POOH w/gun. RIH and set cement retainer at 800'. Sting into retainer and squeeze with 100 cu. ft. of cement. Pull out of retainer and leave cement plug on top of retainer to 280' (16 cu. ft.).
- 7. POOH w/tbg. POOH w/skirted overshot and 2 7/8" casing. Spot cement plug from 240' to surface (100-150 cu. ft.).
- 8. NDBOPE. Cut off casing and wellhead. Install PxA marker according to BLM and State requirements.
- 9. Turn well over to John Jenson for reclamation.
- 10. Rehabilitate surface according to BLM and State requirements.

Note: Use Class G neat cement.

## SAN JUAN 28-7 UNIT #205



#### UNITED STATES DEPARTMENT OF THE INTERIOR

#### BUREAU OF LAND MANAGEMENT FARMINGTON RESOURCE AREA 1235 LA PLATA HIGHWAY FARMINGTON, NEW MEXICO 87401

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

Well: 205 Sandvan 28-70m

#### CONDITIONS OF APPROVAL

- 1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."
- 2. With the Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 326-6201.
- 3. Blowout prevention equipment is required.
- 4. The following modifications to your plugging program are to be made (when applicable):

Office Hours: 7:45 a.m. to 4:30 p.m.

# GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES FARMINGTON RESOURCE AREA

- 1. Secure prior approval either on a Sundry Notice (Form 3160-5) or verbally from the Fluids Drilling & Production Section at this office before changing the approved plugging program.
- 2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs. The Operator is responsible for providing all measuring devices needed to assure proper measurement of materials being used.
- 3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations. Unattended pits are to be fenced.
- 4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 100 feet in length with 50% excess inside casing or 100% excess when plug is set in open hole or squeezed into perforations. 15.6%/gal slurry weight is to be used when using class B neat cement or when CaCl<sub>2</sub> is used. Use the recommended slurry weight of other type cements when they are used (Class C, Pozzolan etc.).
- 5. Any cement plugs placed when well is not full of fluid, or when well may be taking fluid, (i.e. across perfs-unless bridge plug or retainer is used, across bad csg., or fresh water formations) will be tagged (touched) after cement has set to verify proper location.
  - 5a. Testing The first plug below the surface plug shall generally be tested by either tagging the plug with the working pipe string, or pressuring to a minimum pump (surface) pressure of 1000 psig, with no more than a 10 percent drop during a 15-minute period (cased hole only). If the integrity of any other plug is questioned, it must be tested in the same manner. Also, any cement plug which is the only isolating medium for a fresh water interval or a zone containing a valuable mineral deposit should be tested by tagging with the drill string.
- 6. Mud must be placed between plugs. Plugging mud is to be made up with a minimum of 15 lbs/bbl of sodium bentonite, and a nonfermenting polymer.

  Minimum consistency of plugging mud must be 9 lbs/gal and with a minimum viscosity of 50 sec/qt. Fresh water is to be utilized for mixing mud.
- 7. Following the placement of a cement plug, the withdrawl rate for at least the length of the cement plug shall not exceed 30 ft/min, in order to minimize the contamination of the plug.

- 8. Within 30 days after plugging work is completed, file a Sundry Notice (Subsequent Report of Abandonment, Form 3160-5), in quintuplicate with Area Manager, Bureau of Land Management, 1235 La Plata Highway, Farmington, NM 87401. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 9. All permanently abandoned wells are to be marked with a regulation marker (4" pipe extending 4' above the ground line) containing the information as specified in 43 CFR 3162.6(d). Unless otherwise approved.
- 10. After plugging work is completed the surface is to be rehabilitated in accord with instructions from the Fluids Surface Management Section of the Farmington Resource Area Office.

。 1997年 - Andrew March March March Company (1995年 1985年) - Andrew March Marc

All above are minimum requirements. The period of liability under the bond of record will not be terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.

Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to 43 CFR 3163.1.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.