

6 BLM 1 C.M. Paul 1 File  
UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)

Form approved  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.  
Federal LS. #NM-10172  
C.A. #14-08-0001-7817

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL ☐ GAS ☒ OTHER ☐

2. NAME OF OPERATOR

C.M. Paul

3. ADDRESS OF OPERATOR

P O Box 208, Farmington, NM 87499

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

1450' FNL - 1450' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether OF, RT, CR, CASE AREA)

5815' RKB

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Elliott

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Basin Dakota

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 20 T31N R13W NMPM

12. COUNTY OR PARISH 13. STATE

San Juan

NM

18. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PCCL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any  
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-  
nent to this work.) \*

Request permission to P & A the subject well as follows:

1. Spot bottom cement plug in 5 1/2" casing from 6650' (PBTD) to 6500' across  
Dakota formation (20 cf).

2. Spot 100' cement plug in 5 1/2" casing from <sup>4865</sup>5630' to <sup>4985</sup>5730' (13 cf).

3. Spot 100' cement plug from <sup>3376</sup>3460' to <sup>3376</sup>3560' (13 cf).

4. Spot 100' cement plug in 5 1/2" casing from <sup>1820</sup>1820' to <sup>1720</sup>1920' (13 cf). <sup>index</sup> <sup>cur</sup> 1550-1450 no cement (F.)

5. Spot 100' cement across 8-5/8" casing shoe from <sup>368</sup>240' to <sup>368</sup>340' (13 cf).

6. Spot 100' cement plug to surface (13 cf).

7. Plan to install permanent dry hole monument.

8. Plan to fill all pits.

9. Plan to clean well location of all equipment, pipe, junk and trash.

10. Plan to restore surface.

11. Plan to cut off tie-downs.

Note: We do not plan to pull casing.

18. I hereby certify that the foregoing is true and correct

SIGNED

Sherman E. Dugan

TITLE Geologist

DATE

3-5-87

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

MAR 11 1987

CONDITIONS OF APPROVAL, IF ANY:

AREA MANAGER

\*See Instructions on Reverse Side

NMOC

and willfully to make to any department or agency of the