

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-20987
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-7897
7. Lease Name or Unit Agreement Name State "P"
8. Well No. 8
9. Pool name or Wildcat Lovington Paddock
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3809' GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL GAS WELL OTHER

2. Name of Operator
Texaco Exploration and Production Inc.

3. Address of Operator
P.O. Box 730 Hobbs, New Mexico 88240

4. Well Location
Unit Letter F : 1980 Feet From The North Line and 1980 Feet From The West Line
Section 32 Township 16S Range 37E NMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Notify OCD 24 hours prior to commencement of plugging operations.
- MIRUPU. Pull rods. Install BOP. Pull tubing.
- Set 5 1/2" CIBP @ ±6000'. TIH on work string. Dump 35' cement (Class "C" w/ 2% CaCl₂, 6.3 g/sack, 14.8 ppg, 1.32 ft³/sack.) plug (4 sxs) on CIBP (PBTD 5965'). WOC 2-3 hours. Tag plug. Load hole with mud.
- Pull up hole. Set 250' cement plug (25 sxs) from 3370' to 3120'.
- Pull up hole. Set 250' cement plug (25 sxs) from 2087' to 1837'.
- TIH with perforating gun and shoot squeeze holes at ± 420'.
- Squeeze 5 1/2" annulus with 117 sxs by pumping down the casing.
- Cut off wellhead. Install hole marker. Clean location.

Depths measured from KB.

100' PLUG AT TOP OF SA.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE M.C. Duncan TITLE Engineer's Assistant DATE 9-16-91

TYPE OR PRINT NAME M.C. Duncan TELEPHONE NO. 393-7191

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

SEP 19 1991

CONDITIONS OF APPROVAL, IF ANY: