

NO. OF COPIES RECEIVED	6
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR:	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. K 3030	
7. Unit Agreement Name	
8. Farm or Lease Name Montieth State A	
9. Well No. 1	
10. Field and Pool, or Wildcat Lovington NE Penn	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE \*\*APPLICATION FOR PERMIT - \*\* (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Energy Reserves Group, Inc.
3. Address of Operator P. O. Box 2437, Midland, Texas 79701
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1995</u> FEET FROM THE <u>West</u> LINE, SECTION <u>19</u> TOWNSHIP <u>16-S</u> RANGE <u>37-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3842 - GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE: RULE 1103.

Propose to plug and abandon well as follows:

1. Load hole w/9.5# mud
2. Set CIBP in 5½" csg at 11,100' & cap w/35' cement.
3. Shoot off csg at indicated free point.
4. Lay down recovered csg.
5. Spot 100' cmt plugs at following depth:
  - a. Top of 5½" csg stub.
  - b. Top of Wolfcamp at 8808.
  - c. Top of Abo at 8300.
  - d. Top of Glorieta at 6268.
  - e. At 8-5/8" csg shoe at 4340.
6. Shoot off 8-5/8" csg at indicated free point.
7. Spot 100' cmt plug at 8-5/8" csg stub and at base of 11-3/4" surface casing.\*
8. Cut off 11-3/4" csg 3' below surface & spot 10 sxs plug in top of 11-3/4" csg.
9. Weld plate on top of 11-3/4" csg.
10. Erect pipe marker & fill cellar.

\* Also 100' plug at top & base of salt if not left behind pipe.

*Engineer 7/1/77*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *M. J. Sandidge* TITLE District Engineer DATE 7/1/76

APPROVED BY *John Runyan* TITLE Geologist DATE JUL 3 1976

CONDITIONS OF APPROVAL, IF ANY: