

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

1a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT..." (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name N. HOBBS (G/SA) UNIT
2. Name of Operator SHELL OIL COMPANY	8. Farm or Lease Name SECTION 30
3. Address of Operator P. O. BOX 991, HOUSTON, TX 77001	9. Well No. 411
4. Location of Well UNIT LETTER <u>A</u> <u>330</u> FEET FROM THE <u>NORTH</u> LINE AND <u>330</u> FEET FROM THE <u>EAST</u> LINE, SECTION <u>30</u> TOWNSHIP <u>18-S</u> RANGE <u>38-E</u> N.M.P.M.	10. Field and Pool, or Wildcat HOBBS (G/SA)
15. Elevation (Show whether DF, RT, GR, etc.) 3659' DF	12. County LEA

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
OTHER <u>DEEPEN, WATER SHUT-OFF & RUN LINER</u> <input checked="" type="checkbox"/>		OTHER _____ <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Plug back from TD to 4158' with 20-40 sand. Set 6-5/8" cement retainer @ 4000'+. Squeeze Zone I (4042' - 4170') with 1500 gals flochek and 75 sx Class "C" 50/50 poz mix cement w/ 2% CaCl2. WOC 24 hrs.
2. Drill out cement retainer and cement to top of sand @ 4170'. Clean out sand to TD and deepen well to 4310'.
3. Run a CNL/GR/Open hole bow spring caliper from 4310' to 2288'.
4. Run 400'+ 11.34# FJ threaded liner. cement liner with 50/50 Class "C" poz mix cement. WOC 24 hrs.
5. Clean out to top of liner.
6. Perforate and acid treat based on CNL/GR log evaluation.
7. Install production equipment and return well to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

A. J. Fore for A. J. FORE TITLE SUPERVISOR REG. & PERMITTING DATE OCTOBER 12, 1983

ORIGINAL SIGNED BY EDDIE SEAY
OIL & GAS INSPECTOR

OCT 14 1983

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED
OCT 13 1983
Q.C.D.
HOBBS OFFICE