

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form O-103  
Revised 10-1-75

NO. OF COPIES DESIRED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

3a. Indicate Type of Lease  
State  Fee

3. State Oil & Gas Lease No.  
NME 8563

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO SEARCH OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM O-101) FOR SUCH PROPOSALS.

1. OIL WELL  GAS WELL  OTHER  Salt Water Disposal

2. Name of Operator  
Consolidated Oil & Gas, Inc.

3. Address of Operator  
1860 Lincoln St. Denver, Co. 80295

4. Location of Well  
UNIT LETTER P 330 FEET FROM THE South LINE AND 330 FEET FROM  
THE East LINE, SECTION 8 TOWNSHIP 17S RANGE 38E RMPM.

5. Elevation (Show whether OF, RT, GR, etc.)  
3784' KB 3773' GR

7. Unit Agreement Name

8. Part of Lease Name  
Midway State

9. Well No.  
1

10. Field and Pool, or Widened  
Midway Abo

12. County  
Lea

4. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER <input type="checkbox"/>			

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) RU completion rig. PU 2-7/8" tubing and trip in with cement retainer. Set retainer at 6000'±.
- 2) Pump 75 sx CL "C" cement and cap retainer with 2 sxs. Trip out with tubing.
- 3) Perforate 8-5/8" intermediate casing at 500'. Squeeze 50 sxs.
- 4) Cut off surface casing 3' below ground level and spot 15 sxs surface plug. Set dry hole marker

*no access since top*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. T. Stogney, Jr. TITLE Operations Mgr. DATE 4-17-85

ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT 1 SUPERVISOR

APR 22 1985