

MUD PROGRAM

<u>DEPTH INTERVAL</u> <u>TOP-TO</u>	<u>WEIGHT</u> <u>LBS/CAL</u>	<u>TYPE</u>	<u>OIL %</u>	<u>PH</u>	<u>WATER LOSS</u> <u>(CC)</u>	<u>VIS. (sec.)</u>	<u>YIELD</u> <u>POINT</u>	<u>THINNING</u> <u>AGENTS</u>	<u>WATER LOSS</u> <u>AGENTS</u>
-1600'	8.5-9.0	Spud	--	9.0+	--	--	--	--	--
600'-6900'	9.0-10.0	Salt Water Gel	--	9.0-10.0	10-12+	35-40	--	--	--

MARKS

- 1) Below 1600', drill w/saturated brine to keep hole enlargement to a minimum
- 2) Add gelling agent as required to carry cuttings
- 3) Pressure surges should be kept to a minimum below 1600'
- 4) Condition mud to reduce water loss 100' above Blinebry marker