

6. SET RBP @ 7030'. SET PKR @ 6689'. ACIDIZE 5 1/2" CSG PERFS 6724'-7025' (DRINKARD) W/4000 GALS 15% NEFE ACID IN 4-STAGES USING 300-500# ROCK SALT BETWEEN STAGES (TOTAL 1100# ROCK SALT). FLUSH W/9# BRINE.
7. RESET RBP @ 6689' AND PKR @ 6346'. ACIDIZE 5 1/2" CSG PERFS 6378'-6638' (DRINKARD) W/4000 GALS 15% NEFE ACID IN 4-STAGES USING 300# ROCK SALT BETWEEN STAGES. FLUSH W/9# BRINE.
8. RESET RBP @ 6350' & PKR @ 6102'. ACIDIZE 5 1/2" CSG PERFS 6145'-6331' (TUBB PAY) W/4500 GALS 15% NEFE ACID IN 5-STAGES USING 300-500# ROCK SALT BETWEEN STAGES (TOTAL 1400# ROCK SALT).
9. RESET RBP @ 6102' & PKR @ 5551'. ACIDIZE 5 1/2" CSG PERFS 5597'-6058' (BLINEBRY PAY) W/3000 GALS 15% NEFE ACID IN 4-STAGES USING 300# ROCK SALT BETWEEN STAGES. FLUSH W/150 BBL FRESH WATER.
10. INSTALL PUMPING EQUIPMENT. ON 24 HR POTENTIAL TEST ENDING 8-26-84, WELL PUMPED 39 BO AND 96 BW.

RECEIVED

SEP 12 1984

G.C.B.
HOBBS OFFICE