

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Mineral and Natural Resources Department

Form C-103
Revised 1-1-89

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.
30-025-09402

5. Indicate Type of Lease
STATE FEE

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

State A AC 1

1. Type of Well:
OIL WELL GAS WELL OTHER

8. Well No.
24

2. Name of Operator
Clayton Williams Energy, Inc.

9. Pool name or Wildcat
Jalmat Tansill Yates (Pro Gas) Rvrs

3. Address of Operator
Six Desta Drive, Suite 3000 Midland, Texas 79705

4. Well Location
Unit Letter N : 990 Feet From The South Line and 1650 Feet From The West Line
Section 24 Township 23S Range 36E NMPM Lea County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3354 DF

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

| | |
|--|---|
| NOTICE OF INTENTION TO: | SUBSEQUENT REPORT OF: |
| PERFORM REMEDIAL WORK <input type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> |
| OTHER: <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| | CASING TEST AND CEMENT JOB <input type="checkbox"/> |
| | OTHER: <input type="checkbox"/> |

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
Will begin work upon OCD approval

- 1) POOH w/2-3/8" tubing and packer.
- 2) Set CIBP @ ± 2800'. Dump 35' of cement on CIBP.
- 3) Load hole w/10ppg Gelled brine from CIBP to surface.
- 4) Perforate the 8-5/8" casing @ ± 275'.
- 5) Circulate cement down the 8-5/8" casing and up the 8-5/8 / 12-1/2" annulus to surface. (165 sx Class "C" cement)
- 6) Cut the 8-5/8" and 12-1/2" casing 3' below GL. Install P & A marker. Cut and remove deadmen. Clear location of all junk.

Plug and Abandon Wellbore

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Robin S. McCarley TITLE Production Analyst DATE 12/06/94
TYPE OR PRINT NAME Robin S. McCarley TELEPHONE NO. 682-6324

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE DEC 08 1994
CONDITIONS OF APPROVAL, IF ANY: