

Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-20267
5. Indicate Type of Lease STATE [] FEE [x]
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Pearman BKP
8. Well Number 1
9. OGRID Number 7377
10. Pool name or Wildcat Lakewood; Morrow
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3299'GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)
1. Type of Well: Oil Well [] Gas Well [x] Other
2. Name of Operator EOG Resources, Inc.
3. Address of Operator 104 South Fourth Street, Artesia, NM 88210
4. Well Location Unit Letter K : 1980 feet from the South line and 1980 feet from the West line Section 32 Township 19S Range 26E NMPM Eddy County

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK [] PLUG AND ABANDON [x]
TEMPORARILY ABANDON [] CHANGE PLANS []
PULL OR ALTER CASING [] MULTIPLE COMPL []
DOWNHOLE COMMINGLE []
CLOSED-LOOP SYSTEM []
OTHER: []
SUBSEQUENT REPORT OF:
REMEDIAL WORK [] ALTERING CASING []
COMMENCE DRILLING OPNS. [] P AND A []
CASING/CEMENT JOB []
OTHER: []
Notify OCD 24 hrs. prior to any work done

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG Resources, Inc. plans to plug and abandon this well as follows:

- 1. MIRU all safety equipment as needed. NU BOP. POOH with production equipment.
2. Set a CIBP at 9480' with 35' Class "H" cement on top to 9445'. WOC and tag.
3. Set a 2nd CIBP at 7112' with 241' Class "H" cement on top to 6871'. This will cover Penn and Wolfcamp. WOC and tag.
4. Spot a 25 sx Class "C" cement plug from 3871'-3741' as a spacer plug.
5. Perforate at 2623'. Spot a 25 sx Class "C" cement plug from 2623'-2503'. This will cover 8-5/8" casing shoe. WOC and tag.
6. Spot a 25 sx Class "C" cement plug from 1160'-1050'. This will cover San Andres.
7. Perforate at 415'. Spot a 25 sx Class "C" cement plug from 415'-170'. This will cover the 13-3/8" casing shoe. WOC and tag.
8. Spot a 10 sx Class "C" cement plug from 100' up to surface. Back fill as needed.
9. Cut off wellhead and weld on dry hole marker. Clean location as per regulated.

Wellbore schematics attached

Spud Date: []

Rig Release Date: []

****SEE ATTACHED COA's****

MUST BE PLUGGED BY 1/8/2022

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Specialist DATE January 7, 2021

Type or print name Tina Huerta E-mail address: tina.huerta@eogresources.com PHONE: 575-748-4168
For State Use Only

APPROVED BY: [] TITLE Staff Manager DATE 1/8/2021
Conditions of Approval (if any):

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
8. Produced water **will not** be used during any part of the plugging operation.
9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
11. Class 'C' cement will be used above 7500 feet.
12. Class 'H' cement will be used below 7500 feet.
13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

Pearman BKP #1		Sec-TWN-RNG: 32-19S-26E	API: 30-015-20267						
COMMENTS		FOOTAGES: 1980' FSL & 1980' FWL	GL: 3299 KB: 3317						
CASING DETAIL									
#	HOLE SIZE	SIZE	WGHT	GRADE	Top	Bottom	Sx Cmt	Circ/TOC	TOC by
A	17 1/2	13 3/8	48#	H40	0	365	300	Circ	
B	12 1/4 to 1980	8 5/8	24#	K-55	0				1'ed w/280
		8 5/8	24#	K-55	0	2 563	840	Surf	
C	7 7/8	5 1/2	15.5# & 17#	J55 & HCP110	0	9804	1550	Circ	
FORMATION TOPS									
FORMATION	TOP	FORMATION	TOP						
Grayburn	675								
San Andres	1105								
Bone Springs	2023								
Wolfcamp	6951								
Penn	7258								
Strawn	8328								
Atoka	9150								
Morrow	9412								
Perforation Detail									
Formation	Top	Bottom	Treatment	Notes					
A	Morrow	9530	9604	Acidized w/1500g 7 1/2% IC HCL w/250 SS. Frac w/CO2 From frac. 651					
B	Penn	7162	7172	Acidized w/5000g 20% Ferriohel IC acid. spz w/500 ss 11 cm.					
ADDITIONAL DETAIL									
DC work 7/3/18 installed Frac Pack. Programmed radio & hooked up the 8 Dip transmitters. installed telemetry equipment. Changed plate from 4x1.5 to 2.4x0.875									
Tubing Detail									
Joints	Description	Length	OD	ID	Grade	Top	Btm (FKB)		
285		2.875	9348	2.875	2.307	L-80	0	9348	
	2								
Prepared by: DC									
PBD: 9759 MD		12/17/20							
TD: 9804 MD									

Pearman BKP #1		Sec-TWN-RNG: 32-19S-26E	API: 30-015-20267									
COMMENTS		FOOTAGES: 1980' FSL & 1980' FWL	GL: 3299									
			KB: 3317									
Plug 7		CASING DETAIL										
		#	HOLE SIZE	SIZE	WGHT	GRADE	Top	Bottom	Sx Crs	Circ/TOC	TOC by	
		A	17 1/2	13 3/8	48#	H40	0	365	300	Circ		
		B	12 1/4 to 1980	8 5/8	24#	K-55	0					
				11" to 2670	8 5/8	24#	K-55	0	2 563	940	Surf	1"ed w/260 sx
		C	7 7/8	5 1/2	15.5# & 17#	J55 & HCP11Q	0	9804	1550	Circ		
Plug 6		FORMATION TOPS										
		FORMATION	TOP	FORMATION	TOP							
		Grayburn	675									
		San Andres	1105									
		Bone Springs	2023									
		Wolfcamp	6951									
		Penn	7258									
		Strawn	8328									
		Atoka	9150									
		Morrow	9412									
Plug 5		Perforation Detail										
		Formation	Top	Bottom	Treatment	Notes						
	A	Morrow	9530	9604	Acidized w/1500g 7 1/2% IC HCL w/250 BS, Frac w/CO2 Foam frac, 651 bolts fluid, 141 tons CO2							
	B	Penn	7162	7172	Acidized w/5000g 20% Formtek IC acid, sqz w/500 ea ft cm							
Plug 4		ADDITIONAL DETAIL										
		DC work 7/13/18 installed Frac Pack. Programmed radio & hooked up the 8 Dip transmitters. Installed telemetry equipment. Changed plate from 4x1.5 to a 4x0.875.										
Plug 3		Tubing Detail										
		Joints	Description	Length	OD	ID	Grade	Top	Btm (FKB)			
		285		9348	2.875	2.307	L-80	0	9348			
				2								
Plug 2		Plugs										
		#	SX	Length (ft)	Bottom	Top	Class	DESCRIPTION				
		1	4	35	9480	9445	H	CIBP @ 9480' w/ 35' of cement dump baled on top. WOC & Tap.				
		2	27	241	7112	6871	H	CIBP @ 7112' with 241' of cement on top covering the Penn and Wolfcamp. WOC & Tap.				
		3	25	130	3871	3741	C	150' cement plug from 3871' - 3741' as a spacer plug.				
		4	25	120	2623	2503	C	120' cement plug from 2623' - 2503' covering the 8.625" csq shoe. WOC & Tap.				
		5	25	110	1160	1050	C	110' cement plug from 1160' - 1050' covering the San Andres.				
		6	25	245	415	170	C	100' cement plug from 415' - 170' covering the 13.375" csq shoe. WOC & Tap.				
		7	10	100	100	0	C	100' cement plug from 100' to surface. Back fill as needed.				
Plug 1		Perf A										
		Perf B										
		Perf C										
		PBTD: 9759 MD										
		TD: 9804 MD										
		Prepared by: DC										
			12/17/20									

District I
 1625 N. French Dr., Hobbs, NM 88240
 Phone:(575) 393-6161 Fax:(575) 393-0720

District II
 811 S. First St., Artesia, NM 88210
 Phone:(575) 748-1283 Fax:(575) 748-9720

District III
 1000 Rio Brazos Rd., Aztec, NM 87410
 Phone:(505) 334-6178 Fax:(505) 334-6170

District IV
 1220 S. St Francis Dr., Santa Fe, NM 87505
 Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 14114

CONDITIONS OF APPROVAL

Operator: EOG RESOURCES INC P.O. Box 2267 Midland, TX79702			OGRID: 7377	Action Number: 14114	Action Type: C-103F
OCD Reviewer gcoordero		Condition COA's attached to file			