## Sundry Print Report

U.S. Department of the Interior BUREAU OF LAND MANAGEMENT

COM

Well Name: ALACRAN HILLS 11 FED Well Location: T21S / R27E / SEC 11 / County or Parish/State: EDDY /

Well Status: Producing Gas Well

SWNW /

Well Number: 1 Type of Well: CONVENTIONAL GAS Allottee or Tribe Name:

WELL

Lease Number: NMNM14768B Unit or CA Name: 1 ESPERANZA 11 Unit or CA Number:

STATE COM

NMNM107707

Operator: MEWBOURNE OIL

COMPANY

Accepted for record – NMOCD gc 10/18/2021

## **Notice of Intent**

**US Well Number: 3001532674** 

**Sundry ID:** 2629647

Type of Submission: Notice of Intent

Type of Action: Plug and Abandonment

Date Sundry Submitted: 08/18/2021 Time Sundry Submitted: 04:13

Date proposed operation will begin: 09/30/2021

**Procedure Description:** MOC requests permission to permanently plug & abandon the subject well. See attached wellbore schematic & operational procedure.

## **Surface Disturbance**

Is any additional surface disturbance proposed?: No

## **NOI Attachments**

#### **Procedure Description**

Alacran\_Hills\_11\_Fed\_Com\_1\_20210909081744.pdf

Alacran\_Hills\_11\_Fed\_Com\_1\_Final\_WBS\_20210823130621.pdf

 $A lacran\_Hills\_Plugging\_Procedure\_20210823130610.doc$ 

County or Parish/State: Page 2 of eived by OCD: 10/14/2021 12:47:13 PM Well Name: ALACRAN HILLS 11 FED Well Location: T21S / R27E / SEC 11 /

COM SWNW /

Well Number: 1 Type of Well: CONVENTIONAL GAS Allottee or Tribe Name:

WELL

Lease Number: NMNM14768B Unit or CA Name: 1 ESPERANZA 11 **Unit or CA Number:** 

STATE COM NMNM107707

**US Well Number: 3001532674** Well Status: Producing Gas Well Operator: MEWBOURNE OIL

**COMPANY** 

## **Conditions of Approval**

## **Specialist Review**

Alacran\_Hills\_11\_Fed\_Com\_1\_Sundry\_ID\_2629647\_P\_A\_20210925094928.pdf

## **Operator Certification**

I certify that the foregoing is true and correct. Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction. Electronic submission of Sundry Notices through this system satisfies regulations requiring a submission of Form 3160-5 or a Sundry Notice.

**Operator Electronic Signature: BRADLEY BISHOP** Signed on: SEP 09, 2021 08:18 AM

Name: MEWBOURNE OIL COMPANY

Title: Regulatory

Street Address: PO Box 5270

State: NM City: Hobbs

Phone: (575) 393-5905

Email address: bbishop@mewbourne.com

## **Field Representative**

Representative Name: Klay Kirkes

Street Address: PO Box 5270

City: Hobbs State: NM **Zip:** 88260

Phone: (575)390-6706

Email address: kkirkes@mewbourne.com

## **BLM Point of Contact**

**BLM POC Name: LONG VO BLM POC Title:** Petroleum Engineer

BLM POC Email Address: LVO@BLM.GOV **BLM POC Phone:** 5752345972

**Disposition:** Approved Disposition Date: 09/25/2021

Signature: Long Vo

## Merribourne Oil Company

#### **COMPLETION PROCEDURE**

Submitted By: K. Kirkes

 Wellname: Alacran Hills 11 Fed Com #1

 Location: 1450' FNL & 660' FWL Sec 11, T21S, R27E Eddy Co, NM

 Date: 6/14/21

 Csg Set: 11770'
 Surf Csg: 13 %" 48# H40

 Csg Size: 5 ½" 17# HCP110 & L80
 Set @: 423'

 Perfs: 11323' - 11594'
 Tbg: 2 ½" 6.5# P110 w/SN

 Inter Csg: 9 5%" 40# K55 & N80
 Tbg set @: 11406'

Well has a HIC & is ready to be plugged & abandoned.

#### **Procedure:**

- 1) MIRU BCM turnkey plugging crew.
- 2) ND tree, NU BOP.
- 3) POOH w/tbg.


**Set @**: 2663'

- 4) RIH w/5 1/2" CIBP & set @ 11275'. Top perf @ 11323', top Morrow @ 11273'.
- 5) Circulate 140 bbls 9.0# MLF
- 6) Spot 25 sks Class H neat cmt (225' ±) on top of CIBP.
- 7) WOC 4 hrs & tag plug @ 11175' or higher.
- 8) LD pipe to 9180' (WFCP top @ 9128').
- 9) Spot 25 sks Class H neat cmt (225' ±).
- 10)WOC 4 hrs & tag plug @ 9078' or higher.
- 11)LD pipe to 7970' (TOC @ 7920').
- 12)Spot 25 sks Class H neat cmt (225' ±).
- 13)WOC 4 hrs & tag plug @ 7870' or higher.
- 14)POOH w/tbq
- 15) RIH w/wireline & perforate 5  $\frac{1}{2}$ " csg @ 5335' (top BSPG @ 5285'). Circ MLF out 5  $\frac{1}{2}$ " annulus to surface.
- 16)RIH w/tbg & pkr to 5000'. Set pkr & set balanced plug squeezed through the perfs w/55 sks Class C neat cmt (190' ±).
- 17)WOC 4 hrs & tag plug @ 5235' or higher.
- 18)POOH w/tbg.
- 19)RIH w/wireline & perforate 5 ½" csg @ 2986' (top Delaware @ 2936').
- 20)RIH w/tbg & pkr to 2625'. Set pkr & set balanced plug squeezed through the perfs w/55 sks Class C neat cmt (190' ±).
- 21)WOC 4 hrs & tag plug @ 2886' or higher.
- 22)POOH w/tbg.
- 23)RIH w/wireline & perforate 5 1/2" csg @ 2713' (9 5/8" shoe @ 2663').
- 24) Attempt to squeeze formation under 9 % shoe.
- 25)RIH w/tbg & pkr to 2400'. Set pkr & set balanced plug squeezed through the perfs w/55 sks Class C neat cmt (190' ±).
- 26)WOC 4 hrs & tag plug @ 2613' or above.
- 27)POOH w/tbg.
- 28)RIH w/wireline & perforate 5 1/2" csg @ 473' (13 3/8" shoe @ 423').
- 29)RIH w/tbg & pkr to 175'. Set pkr & set balanced plug squeezed through the perfs w/55 sks Class C neat cmt (150' ±)
- 30)WOC 4 hrs & tag plug @ 373' or above.
- 31)POOH w/tbg.
- 32)RIH w/wireline & perforate 5 1/2" csg @ 200'.
- 33) Circulate approximately 90 sks Class C neat cmt to surface.
- 34) WOC & confirm that wellbore remains full.
- 35) Cut off WH & install dry hole marker. Cut off anchors & clean location.

Alacran Hills 11 Fed Com #1

## Received by OCD: 10/14/2021 12:47:13 PM Alacran Hills 11 Fed Com #1 WBS


1450' FNL & 660' FWL, Sec. 11 - T21S - R27E - Eddy Co, NM API 30-015-32674



OIL COMPANY

## Alacran Hills 11 Fed Com #1 Final WBS

1450' FNL & 660' FWL, Sec. 11 - T21S - R27E - Eddy Co, NM API 30-015-32674



## IMERALBOURING ON COMPANY

#### **COMPLETION PROCEDURE**

30-015- 32674

Submitted By: K. Kirkes

Wellname: Alacran Hills 11 Fed Com #1

Location: 1450' FNL & 660' FWL

Sec 11, T21S, R27E

Eddy Co, NM

**Date:** 6/14/21

Csg Set: 11770' **Surf Csg:** 13 %" 48# H40

Csg Size: 5 ½" 17# HCP110 & L80 Set @: 423'

**Perfs**: 11323' – 11594' **Tbg:** 2 %" 6.5# P110 w/SN

Inter Csg: 9 5/8" 40# K55 & N80 Tbg set @: 11406'

**Set @:** 2663'

Well has a HIC & is ready to be plugged & abandoned.

#### Procedure:

- 1) MIRU BCM turnkey plugging crew.
- 2) ND tree, NU BOP.
- 3) POOH w/tbg.
- 4) RIH w/5 1/2" CIBP & set @ 11275'. Top perf @ 11323', top Morrow @ 11273'.
- 5) Circulate 140 bbls 9.0# MLF
- 6) Spot 25 sks Class H neat cmt (225' ±) on top of CIBP.
- (Pressure test CIBP) 7) WOC 4 hrs & tag plug @ 11175' or higher. 1110
- 8) LD pipe to 9180' (WFCP top @ 9128'). 9180'
- 9) Spot 25 sks Class H neat cmt (225' ±).
- 10)WOC 4 hrs & tag plug @ 9078 or higher. **2986**
- 11)LD pipe to 7970' (TOC @ 7920').
- 12) Spot 25 sks Class H neat cmt (225' ±).
- 13)WOC 4 hrs & tag plug @ 7870' or higher.
- 14)POOH w/tba
- 15)RIH w/wireline & perforate 5 1/2" csg @ 5335' (top BSPG @ 5285'). Circ MLF out 5 ½" annulus to surface.
- 16)RIH w/tbg & pkr to 5000'. Set pkr & set balanced plug squeezed through the perfs w/55 sks Class C neat cmt (190' ±).
- 17)WOC 4 hrs & tag plug @ 5235' or higher. 5182
- 18)POOH w/tba.
- 19)RIH w/wireline & perforate 5 1/2" csg @ 2986' (top Delaware @ 2936').
- 20)RIH w/tbg & pkr to 2625'. Set pkr & set balanced plug squeezed through the perfs w/55 sks Class C neat cmt (190' ±). 115 SX
- 21)WOC 4 hrs & tag plug @ 2886 or higher.

2613

Alacran Hills 11 Fed Com #1

## INTERNATIONALIMAE ON COMPOUNTS

34) WOC & confirm that wellbore remains full.

## **COMPLETION PROCEDURE**


22)POOH w/tbg.
23)RIH w/wireline & perforate 5 ½" csg @ 2713' (9 5%" shoe @ 2663').
24)Attempt to squeeze formation under 9 %" shoe.
25)RIH w/tbg & pkr to 2400'. Set pkr & set balanced plug squeezed through the perfs w/55 sks Class C neat cmt (190' ±).
26)WOC 4 hrs & tag plug @ 2613' or above.
27)POOH w/tbg.
28)RIH w/wireline & perforate 5 ½" csg @ 473' (13 %" shoe @ 423').
29)RIH w/tbg & pkr to 1767. Set pkr & set balanced plug squeezed through the perfs w/55 sks Class C neat cmt (150' ±)
30)WOC 4 hrs & tag plug @ 373' or above.
31)POOH w/tbg.
32)RIH w/wireline & perforate 5 ½" csg @ 200'.
33)Circulate approximately 90 sks Class C neat cmt to surface.

35) Cut off WH & install dry hole marker. Cut off anchors & clean location.


Alacran Hills 11 Fed Com #1

## Received by OCD: 10/14/2021 12:47:13 PM Alacran Hills 11 Fed Com #1 Final WBS

1450' FNL & 660' FWL, Sec. 11 - T21S - R27E - Eddy Co, NM API 30-015-32674



1450' FNL & 660' FWL, Sec. 11 - T21S - R27E - Eddy Co, NM API 30-015-32674



## BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

## Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90<sup>th</sup> day provide this office, prior to the 90<sup>th</sup> day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10<sup>th</sup> day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.

Received by OCD: 10/14/2021 F2:47:13 PM

# United States Department of the Interior

## BURBAU OF LAND MANAGEMENT Carlsbad Field Office

620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/mm



In Raply Refer To: 1310

# Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not beingauent During the life of the development all disturbed areas not needed for active support of production operations should undergo "inferim" reclamation in order to minimize the emport of production operations submit minergo minerum reciamentom in order to minimize the shortest of development on other resources and uses. At final abandonment, well locations, broduction taggiffes, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration. including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the distribunce. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives

To achieve these objectives, remove any and all comminants, sorap/wash, equipment, pipelines and powerlines (Contact service companies, allowing plenty of time to have the risers and power lines and poles removed prior to reclamation, don't wait till the last day and try to get them to remove infrastructure). Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point, If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- 1. The Application for Permit to Drill or Reenter (APD, Form 3160-3). Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands.

  Oil and Gas operators must plan for reclamation both interim and final up front in the APD. Oil and Gas operators must plan for reclamation, both interim and final, up from in the APD
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonnent, Sundry Notices and Reports on Wells (Form 3160-5). Intelim reclamation is to be completed within 6 months of well completion, and final reclamation
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the
- Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and provide you approved Sundry Notice, you are free to proceed with reclamation as you approved APD. If you

have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation Equipment to ensure the location to very superior of the location of the loc Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify Work was completed as per approved plans.

- The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- fig. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection-
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved. releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Supervisory Petroleum Engineering Tech 575-234-5909 (Office), 575-361-2648 (Cell) Arthur Arias

Environmental Protection Specialist 575-234-6230

Crisha Morgan Environmental Protection Specialist

Melissa Hom Environmental Protection Specialist 575-234-5951

Kelsey Wade Environmental Protection Specialist

Trishia Bad Bear, Hobbs Field Station Natural Resource Specialist 575-393-3612

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 56036

#### **CONDITIONS**

Operator:		OGRID:		
	MEWBOURNE OIL CO	14744		
	P.O. Box 5270	Action Number:		
	Hobbs, NM 88241	56036		
		Action Type:		
		[C-103] NOI Plug & Abandon (C-103F)		

#### CONDITIONS

Created By	Condition	Condition Date
gcordero	None	10/18/2021