
office	State of New M			Form C-103	
1625 N. French Dr., Hobbs, NM 88240	., Hobbs, NM 88240			Revised July 18, 2013	
811 S. First St., Artesia, NM 88210 OIL C	CONSERVATION		30-025-37260 5. Indicate Type of Lea	se	
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Fra		STATE 🖂	FEE	
<u>District IV</u> – (505) 476-3460 220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 8	6. State Oil & Gas Leas VO-5521	se No.		
87505 SUNDRY NOTICES AND R DO NOT USE THIS FORM FOR PROPOSALS TO DRIL DIFFERENT RESERVOIR. USE "APPLICATION FOR P	Strait BLJ State Com				
PROPOSALS.)  Type of Well: Oil Well Gas Well			8. Well Number 4		
2. Name of Operator EOG Resources, Inc.			9. OGRID Number 7377		
3. Address of Operator			10. Pool name or Wildcat X-4 Ranch; Morrow/X-4 Ranch; Atoka		
. 04 South Fourth Street, Artesia, NM 88210			X-4 Ranch; Morrow/X-	4 Ranch; Atoka	
Unit Letter J : 1650 feet	from the South	line and	1650 feet from the	East line	
	nship 10S Ra ion (Show whether DF	ange 34E	NMPM Lea	County	
11. Elevan	*	3'GR	.)		
12. Check Appropriate	e Box to Indicate N	Nature of Notice	, Report or Other Data		
NOTICE OF INTENTION PERFORM REMEDIAL WORK  PLUG AND TEMPORARILY ABANDON  CHANGE I PULL OR ALTER CASING  MULTIPLE	DABANDON ⊠ PLANS □	REMEDIAL WOR	RILLING OPNS.□ P AN	RING CASING	
DOWNHOLE COMMINGLE  CLOSED-LOOP SYSTEM	COMPL	CASING/CEMEN	NI JOB		
OTHER:  13. Describe proposed or completed operation		OTHER:	. 4		
of starting any proposed work). SEE RU proposed completion or recompletion.					
EOG Resources, Inc. plans to plug and abandon this	well as follows:				
<ol> <li>MIRU all safety equipment as needed. NU BOI</li> <li>Set a CIBP at 11,909'. Pressure test. Spot 25 sx perfs and Atoka top.</li> <li>Spot a 25 sx Class "H" cement plug from 9142'</li> <li>Spot a 25 sx Class "H" cement plug from 7792'</li> <li>Spot a 25 sx Class "C" cement plug from 5553'</li> <li>Perforate at 4275'. Attempt injection rate. Spot</li> </ol>	Class "H" cement on to '-8811'. This will cover '-7461'. This will cover '-5175'. This will cover	op of CIBP to 11,578' Wolfcamp top. Abo top. Glorieta top.	Ü	·	
San Andres top.  7. Perforate at 2803'. Attempt injection rate. Sque  8. Perforate at 2046'. Attempt injection rate. Sque  9. Perforate at 473'. Attempt injection rate. Sque  10. Perforate at 100'. Attempt injection/circulation.  11. Cut off wellhead and install dry hole marker. C	eze with 41 sx Class "C ze with 32 sx Class "C" . Squeeze with 32 sx Cla	" cement from 2046'- cement from 473'-37 ass "C" cement from 1	1915'. WOC and tag. This will co	ll cover Rustler top. over casing shoe.	
Vellbore schematics attached LPC Area Below	ground marker send	pics before backfi	lling hole		
oud Date:	Rig Release D	SEE ATTA OF APPRO	CHED CONDITIONS		
			as and haliaf		
nereby certify that the information above is true	and complete to the b	est of my knowled	ge and bener.		
	•	egulatory Specialis		, 2022	
nereby certify that the information above is true  GNATURE TINA HUEVTA  Tina Huerta  or State Use Only	TITLE <u>R</u>	•	t DATE February 11	<u>, 2022</u> <u>_575-748-4168</u>	

Received by OCD: 2/11/2022 11:02:36 AM

A PICE SIZE SIZE WOHT GRACE TO Bottom Sk Cint CHOTOC TOC Method A 1711/22 133/8 46 10 423 1220 Cinc Charled B 12214 95/8 36 0 4228 1725 Cinc Charled B 12214 10 5/8 36 0 12700 395/8 3700 Cinc Charled B 12214 10 5/8 36 0 12700 395/8 3700 Cinc Charled B 12214 10 5/8 36 0 12700 395/8 3700 Cinc Charled B 12214 10 12700 A 12214 10 10 10 12700 A 12214 10 10 10 12700 A 12214 10 10 12700 A 12214 10 10 10 12700 A 12214 10 10	Strait B	LJ State	Com 4	Current	Sec	c-TWN-RNG FOOTAGES	: 21-10S-3 : 1650' FSI	4E L & 1650' FEL			30-025 4203	-37260		
# MOLE SIZE   SIZE   WORTH   GRADE   Top   Bottom   Co-07CO   TOC Method   A   17/12   13/38   48   0   422   420   Cro   B   12/14   9.58   36   0   422   420   Cro   C   8.344   4.1/2   11.6   0   12/700   3595   3700   Calc   C   8.344   4.1/2   11.6   0   12/700   3595   3700   Calc   C   8.344   4.1/2   11.6   0   12/700   3595   3700   Calc   C   8.345   11.6   0   12/700   3595   3700   Calc   C   8.346   4.1/2   11.6   0   12/700   3595   3700   Calc   C   8.347   1.0   0   0   0   0   0   0   C   8.348   2733   Addres   11834   C   10/10   10/10   10/10   10/10   C														
A 17 1/12 13.3/8 48 0 0 423 420 Circ   B 12 1/4 9 0/80 30 0 0 42,70 5 Circ   C 8.3/4 4 1/2 11.6 0 12,700 3585 3700 Calc   C 8.3/4 4 1/2 11.6 0 12,700 3585 3700 Calc   FORMATION TOPS   FORMATION TOPS   FORMATION TOPS   Guester 1996   Wofstamp 9 9000   1 38n Andrea 40/41   Morrow   12,000   1 38n Andrea 40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 38n Andrea   40/41   Morrow   12,000   1 4 4 1/2   11.6								_			1			1
## 12 114   9.58   38   0. 4.225   1725   Circ   C 8.344   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.344   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.344   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.344   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.344   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.345   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3595   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3955   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3955   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3955   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3955   3700   3955   3700   Calc   C 8.346   4.112   11.6   0. 12.700   3955   3700   3955   C 8.346   4.112   11.6   0. 12.700   3955   3700   3955   3700   3955   3700   3955   3700   3955   3700   3955   3700   3955   C 8.346   4.112   11.6   11.6   11.6   11.6   11.6   11.6   11.6									GRADE					TOC Method
C 8 3/4 4 1/2 11.6 0 12.700 3955 3700 Calc  C 8 3/4 4 1/2 11.6 0 12.700 3955 3700 Calc  FORMATION TOPS  FORMATION TOPS  FORMATION TOPS  Rustler 1996 Worksamp 9 5002 11.0000 11.0000 11.0000 11.000 11.000 11.000 11.000 11											_			
FORMATION TOPS   Formation   Top   Formation   Top   Worksamp   Sog2   Worksamp   Sog3   Worksamp   So		Α												
Formation   Top   Formation					С	8 3/4	4 1/2	11.6		0	12,700	3585	3700	Calc
Formation   Top   Formation						<u> </u>	<u> </u>	<u> </u>					<u> </u>	
Formation   Top   Formation					FORM	ATION TOPS								
Ruster   1996   Wuffcamp   5002							Formation	Тор			Formatio	n	Тор	
Valee   2758   Aloka   11634   15032	TOC @ 3700 Calc													2
San Andres	_						1						1	
			1											
TUBING DETAIL   #   Joints   Description   Length   OD   ID   Grade   Wt (lbft):   Top (flKB):   Blm (flKB):		В												
# Joints Description Length OD ID Grade Wi (fb/ft): Top (ft/KB): Blm (ft/KB):    2.38 tbg 8. pkr @ 11900							Abo	7742						
# Joints Description Length OD ID Grade Wi (fb/ft): Top (ft/KB): Blm (ft/KB):    2.38 tbg 8. pkr @ 11900														
2 3/8 tbg & pkr @ 11900					TUBIN	G DETAIL	1	T					T	1
Perforation Detail   Formation   Top   Bottom   Treatment   2100 gals 71/2% Morrow acid. Frac wi4/2000 gals 40# purgel-111 and 40Q foam wi4/0000# 20/40 Versaprop   Prepared by: NF 2/8/22   PBTD: 12,617 MD					#	Joints			OD	ID	Grade	Wt (lb/ft):	Top (ftKB):	Btm (ftKB):
Formation   Top   Bottom   Treatment							2 3/8 tbg & p	kr @ 11900						
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment						T			ı		1			
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment														
Formation   Top   Bottom   Treatment						1					ļ	1		1
Formation   Top   Bottom   Treatment						+	1	-			<del>                                     </del>		1	+
Formation   Top   Bottom   Treatment						1					-			+
Formation   Top   Bottom   Treatment														
Morrow Perfs 11959-12085  A Morrow 11,959 12,085 2100 gals 7 1/2% Morrow acid. Frac w/42000 gals 40# purgel- 111 and 40Q foam w/40000# 20/40 Versaprop  Prepared by: NF 2/8/22  PBTD: 12,617 MD					Perfor	ation Detail	cion Detail							
Morrow Perfs 11959-12085  C  Prepared by: NF 2/8/22  PBTD: 12,617 MD														
Morrow Perfs 11959-12085  C  Prepared by: NF 2/8/22  PBTD: 12,617 MD					Α	Morrow	11,959	12,085						als 40# purgel-
Prepared by: NF 2/8/22  PBTD: 12,617 MD	Morrow Parfs 11050 12005									ıııan	u 40Q IOAI	11 W/4UUUU	# 20/40 versaprop	
Prepared by: NF 2/8/22 PBTD: 12,617 MD	WOITOW Pelis 11303-12005						+							
Prepared by: NF 2/8/22 PBTD: 12,617 MD						+	+	1						
Prepared by: NF 2/8/22 PBTD: 12,617 MD						1								
PBTD: 12,617 MD		С					1				ļ			
PBTD: 12,617 MD						1						1		
PBTD: 12,617 MD						Prens	ared by: NE 2/8	122						
		PRTD	: 12.617 МГ	)		гтера	110 u by. 141 2/0/							

Received by OCD: 2/11/2022 11:02:36 AM



# CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

# Company representative will be on location during plugging procedures.

- **1.** A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- **2.** Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- **3.** Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- **5.** A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can +be released.
- **6.** If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- **8.** Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- **10.** All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- **13.** A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- **14.** All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.
- **16.** When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- **18.** A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.

**21.** If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing.

# DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

# SPECIAL CASES ----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

## SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

# **State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505**

COMMENTS

Action 80982

## **COMMENTS**

Operator:	OGRID:
EOG RESOURCES INC	7377
P.O. Box 2267	Action Number:
Midland, TX 79702 80982	
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

#### COMMENTS

Created B	Comment	Comment Date
plmartir	ez DATA ENTRY PM	3/14/2022

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720 District II

811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720 District III

1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 80982

# **CONDITIONS**

Operator:	OGRID:
EOG RESOURCES INC	7377
P.O. Box 2267	Action Number:
Midland, TX 79702	80982
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

### CONDITIONS

Created By	Condition	Condition Date
kfortner	See attached conditions of approval	3/11/2022