

Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.
30-015-20350
5. Indicate Type of Lease
STATE [X] FEE [ ]
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)
1. Type of Well: Oil Well [ ] Gas Well [X] Other [ ]
2. Name of Operator
OXY USA INC.
3. Address of Operator
PO BOX 4294, HOUSTON, TX 77210
4. Well Location
Unit Letter P : 990 feet from the SOUTH line and 660 feet from the EAST line
Section 2 Township 23S Range 26E NMPM County EDDY
11. Elevation (Show whether DR, RKB, RT, GR, etc.)

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK [ ] PLUG AND ABANDON [ ]
TEMPORARILY ABANDON [X] CHANGE PLANS [ ]
PULL OR ALTER CASING [ ] MULTIPLE COMPL [ ]
DOWNHOLE COMMINGLE [ ]
CLOSED-LOOP SYSTEM [ ]
OTHER: [ ]
SUBSEQUENT REPORT OF:
REMEDIAL WORK [ ] ALTERING CASING [ ]
COMMENCE DRILLING OPNS. [ ] P AND A [ ]
CASING/CEMENT JOB [ ]
OTHER: [ ]

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

OXY RIGGED UP ON THE SUBJECT WELL FOR A DIFFERENT JOB SCOPE AND DISCOVERED BRADENHEAD PRESSURE ON THE WELL. SQUEEZE HOLES WERE SHOT, BUT WE COULD NOT ESTABLISH A RATE INTO THE SQUEEZE HOLES. OXY PLANS TO PUMP A BRADENHEAD SQUEEZE JOB TO RESOLVE THE BRADENHEAD PRESSURE AND THEN TEMPORARILY ABANDON THE WELLBORE.

THIS SUNDRY IS FILED PER OCD GUIDANCE. A DEEPER MORROW PLUG WILL BE SET IN ADDITION TO THE SHALLOWER, STRAWN PLUG.

THE CURRENT WELLBORE, PROPOSED WELLBORE, AND TA PROCEDURE ARE ATTACHED.

Spud Date:

[Empty box for Spud Date]

Rig Release Date:

TA status may be granted after a successful MIT test is performed. Contact the OCD to schedule the test so it may be witnessed.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE STEPHEN JANACEK TITLE REGULATORY ENGINEER DATE 6/15/23

Type or print name STEPHEN JANACEK E-mail address: STEPHEN\_JANACEK@OXY.COM PHONE: 713-493-1986

For State Use Only

APPROVED BY: [Signature] TITLE Staff Manager DATE 6/15/23

Conditions of Approval (if any):



### Humble Grace

API # 30-015-20350

Completed June 1971

P 990 FSL 660 FEL T23S R26E

Eddy County, TX

Current Wellbore 6/14/23

Squeeze perms at 4900'. Unable to establish rate.


6/6/2023- Pump bradenhead cement job to resolve bradenhead flow. No gas flow or pressure on bradenhead.


6/8/2023- Ran CBL from surface to 5940'. Good cement bond from 1300'-5940'.

1973 Strawn Perfs: 10544'-10590'

11/5/1999- Set CIBP? at 10658' by Bold Energy.

1973 Morrow Perforations: 11680'-11690'





### Humble Grace

API # 30-015-20350


Completed June 1971

P 990 FSL 660 FEL T23S R26E

Eddy County, TX

Proposed Wellbore

Squeeze perms at 4900'. Unable to establish rate.



## TA Job Procedure- Refile per OCD Request

Humble Grace Com #001

30-015-20350

6/15/2023

### Note

This NOI is filed while the workover rig is on location. The current wellbore diagram has been updated to show the Strawn perms not shown in the previous submission. Also, the proposed wellbore diagram has been updated to show a deeper plug set above the Morrow perms.

### Procedure

1. Continue drilling out.
2. Attempt to retrieve or drill out CIBP or RBP or packer set at 10658'.
3. Continue to get down to 11580' to set CIBP.
4. Set CIBP at 11580'. Leak test CIBP. Dump bail 35 ft cmt. WOC. Tag.
5. Set CIBP at 10444'. Leak test CIBP. Dump bail 35 ft cmt. WOC. Tag.
6. Perform MIT and BHT. Contact OCD 24 hours prior to witness test.

**District I**  
 1625 N. French Dr., Hobbs, NM 88240  
 Phone:(575) 393-6161 Fax:(575) 393-0720

**District II**  
 811 S. First St., Artesia, NM 88210  
 Phone:(575) 748-1283 Fax:(575) 748-9720

**District III**  
 1000 Rio Brazos Rd., Aztec, NM 87410  
 Phone:(505) 334-6178 Fax:(505) 334-6170

**District IV**  
 1220 S. St Francis Dr., Santa Fe, NM 87505  
 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico**  
**Energy, Minerals and Natural Resources**  
**Oil Conservation Division**  
**1220 S. St Francis Dr.**  
**Santa Fe, NM 87505**

CONDITIONS

Action 228703

**CONDITIONS**

Operator: OXY USA INC P.O. Box 4294 Houston, TX 772104294	OGRID: 16696
	Action Number: 228703
	Action Type: [C-103] NOI Temporary Abandonment (C-103I)

**CONDITIONS**

Created By	Condition	Condition Date
gcordero	None	6/15/2023