DECOMEZA South District-Artesia

# State of New Mexico Energy, Minerals and Natural Resources Department Oil Conservation Division Price District Office

BRADENHEAD TEST REPORT API Number <sup>1</sup> Surface Location E/W Line Lot Well Status INJECTOR TA'D WELL PRODUCER SHUT-IN NO INS SWD OIL GAS NO YES YES

## OBSERVED DATA

arragantina taman array ali a Andri Sala Language et il addisa la galla della	(A)Surface	(B)Interm(1)	(C)Interm(2)	(D)Prod Csng	(E)Tubing
Pressure		The second secon			350
Flow Characteristics	The same of the sa		STATE OF THE PARTY		500
Puff	YIN	Y/N/	Y/N/	Y / (N)	CO2 WTR
Steady Flow	YIN	YIN	YIN	YIN	GAS
Surges	Y/(N	Y/1 N	V/ N	YIN	Type of Flaid
Down to nothing	(X/N	XIN	/Y / N	(Y)/ N	Injected for Waterfeed 9
Gas or Oil	YIN	Y/N	/ Y / N	Y / (X)	applies.
Water	Y (N)	Y/N	Y/N	YN	

Remarks - Please state for each string (A,B,C,D,E) pertinent information regarding bleed down or continuous build up if applies.

Signature:		OIL CONSERVATION DIVISION		
Printed name:		Entered into RBDMS		
Title		Re-test		
E-mail Address:				
Date:	Phone:			
	Witness: William Witness: Witness: William William Witness: William William Witness: Willia	The section of the se		

INSTRUCTIONS ON BACK OF THIS FORM

## PERFORMING BRADENHEAD TEST

General Procedure for Bradenhead Test

Identify:

All valves prior to testing

Gauges:

Install on each casing string to record pressure.

Assure:

That all valves are in good working condition and closed at least 24 hours prior

to testing.

Open:

Each valve (Bradenhead, intermediate and casing valves) is to be opened

separately.

Check Gauges:

Record pressure on each gauge and casing string on BHT form. Open

valves to atmosphere and record results on BHT form.

Designate what applies to the result of opening the valves for each string:

Blow or Puff
Bled down to Nothing
Steady Flow
Oil or Gas
Water
Yes or No
Yes or No
Yes or No
Yes or No

Start: Injection or SWD pump so tubing pressure can be read.

In case of pressure:

1. Record pressure reading on gauge.

2. Bleed and note time elapsed to bleed down.

3. Leave valve open for additional observation.

4. Note any fluids expelled.

In absence of Pressure:

1. Leave valve open for additional observation.

2. Note types of fluids expelled.

3. Note if fluids persist throughout test.

Note: Tubing pressure on injection or SWD wells.

Test will be signed by person performing test with a contact phone number.

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

District II 811 S. First St., Artesia, NM 88210 Phone:(575) 748-1283 Fax:(575) 748-9720

District III 1000 Rio Brazos Rd., Aztec, NM 87410 Phone:(505) 334-6178 Fax:(505) 334-6170

1220 S. St Francis Dr., Santa Fe, NM 87505 Phone:(505) 476-3470 Fax:(505) 476-3462

**State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division** 1220 S. St Francis Dr. **Santa Fe, NM 87505** 

CONDITIONS

Action 289052

### **CONDITIONS**

Operator:	OGRID:
BXP Operating, LLC	329487
11757 KATY FREEWAY HOUSTON, TX 77079	Action Number: 289052
	Action Type: [UF-BHT] Bradenhead Test (BRADENHEAD TEST)

#### CONDITIONS

Created By		Condition Date
kfortner	None	12/4/2023