

Well Name: INDIAN	Well Location: T30N / R16W / SEC 2 / NESE / 36.841995 / -108.485733	County or Parish/State: SAN JUAN / NM
Well Number: 3	Type of Well: OIL WELL	Allottee or Tribe Name: EASTERN NAVAJO
Lease Number: N00C14205342	Unit or CA Name:	Unit or CA Number:
US Well Number: 300452159500S1	Operator: SITTA R E	

Notice of Intent

Sundry ID: 2791658

Type of Submission: Notice of Intent	Type of Action: Plug and Abandonment
Date Sundry Submitted: 05/21/2024	Time Sundry Submitted: 09:12
Date proposed operation will begin: 06/01/2024	

Procedure Description: The Bureau of Land Management Farmington Field Office (BLM FFO) and Federal Indian Minerals Office (FIMO) requested the New Mexico Oil Conservation Division (NM OCD) to plug the well as part of their program. See attached email conversation. Aztec Well Servicing will be the contractor, the procedure is attached. The general plugging requirements for the BLM FFO were provided. The BLM FFO requested to be contacted at least 24 hours before the plugging operations commence so that the work can be witnessed. Phone number 505 564-7750. Work is proposed to be completed by June 30, 2024.

Surface Disturbance

Is any additional surface disturbance proposed?: No

Oral Submission

Oral Notification Date:	May 16, 2024	Oral Notification Time:	12:00 AM
Contacted By:	Kenneth Rennick	Contact's Email:	krennick@blm.gov

NOI Attachments

Procedure Description

- General_Requirement_PxA_20240521091202.pdf
- PA_procedure_for_Indian_003_20240521090553.pdf
- NOOC14205342_et_al_Email_Conversation_05162024_20240521090531.pdf

Received by OCD: 5/22/2024 1:40:08 PM

Well Name: INDIAN

Well Location: T30N / R16W / SEC 2 / NESE / 36.841995 / -108.485733

County or Parish/State: SAN JUAN / NM

Well Number: 3

Type of Well: OIL WELL

Allottee or Tribe Name: EASTERN NAVAJO

Lease Number: N00C14205342

Unit or CA Name:

Unit or CA Number:

US Well Number: 300452159500S1

Operator: SITTA R E

BLM Point of Contact

BLM POC Name: KENNETH G RENNICK

BLM POC Title: Petroleum Engineer

BLM POC Phone: 5055647742

BLM POC Email Address: krennick@blm.gov

Disposition: Approved

Disposition Date: 05/21/2024

Signature: Kenneth Rennick



NMOCD
Plug & Abandon Procedure
 May 13, 2024

Well:	Indian #003	API:	30-045-21595
Location:	2310' FSL & 330' FEL	Field:	Gallup
Sec,T, R:	Sec 02 30N-16W	Elevation:	GL: 5540'
Cnty/State:	San Juan, New Mexico	By:	Aztec Well Servicing
Lat/Long:	36.842186, -108.4864197		

Objective:

Permanently plug & abandon the well from 1807' containing 2 cement plugs.

Note:

All cement volumes use 100% excess outside casing and 50' excess inside pipe. Stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures. All cement will be ASTM Class G neat yield or equivalent. If casing pressure tests tagging plugs will not be required.

Prior to Rig:

1. Notify NMOCD and BLM
2. Note: verify all cement volumes based on actual slurry to be pumped.
3. See attached COA's from NMOCD and BLM.

Procedure:


1. MIRU well servicing rig and cement equipment.
2. Check casing, tubing, and BH pressures.
3. Removed existing piping on casing valve. RU blow lines from casing valves and begin blowing down casing pressure. Kill well as necessary. Ensure well is dead or on a vacuum.
4. LD rods on tubing float.
5. ND wellhead and NU BOP. Function test BOP. RU floor and 2-3/8" handling tools.
6. LD production tubing.
7. PU and tally work string and RIH with casing scraper to 1450'.
8. TOOH and LD casing scraper.
9. TIH with 4-1/2" CICR and set @ 1434'.
10. Roll the hole with fresh water and pressure test casing to 500 psi. If casing does not test, then spot or tag subsequent plugs as appropriate. WOC to be determined upon pressure test.
11. TOOH and rig up WL and run CBL from 1434' to surface. RD WL.
12. TIH to CICR.
13. **Plug #1, 1654' – 1300' (Gallup Top: 1542')** Mix & pump 48 sxs of class G cement and squeeze 33 sxs below CICR and spot 14 sxs on top of CICR to cover the Gallup top. Pull up and reverse circulate tubing clean.
14. WOC then tag plug to confirm TOC.



NMOCD
Plug & Abandon Procedure
 May 13, 2024

Well:	Indian #003	API:	30-045-21595
Location:	2310' FSL & 330' FEL	Field:	Gallup
Sec,T, R:	Sec 02 30N-16W	Elevation:	GL: 5540'
Cnty/State:	San Juan, New Mexico		
Lat/Long:	36.842186, -108.4864197	By:	Aztec Well Servicing

15. LD remaining tubing.
16. RU WL and perforate @ 400'. Pump fresh water and establish an injection rate. RD WL.
17. **Plug #2, 400' – surface (Mancos Top: 350' Surface Shoe: 100')** Mix & pump 132 sxs Class G cement and pump down 4-1/2" casing and back up BH until good cement returns to surface to cover the Mancos top, and the surface shoe. Top off as necessary.
18. NP BOP, cut off wellhead below surface casing flange per regulation. Top off w/cement if needed. Install P&A marker with cement to comply with regulations. RD and MOL. Restore location per BLM stipulations.



Re: [EXTERNAL] BLM Farmington NM -- Request to Plug Allottee Wells

Rennick, Kenneth G <krennick@blm.gov>

Fri 5/17/2024 11:32 AM

To: Griswold, Jim, EMNRD <Jim.Griswold@emnrd.nm.gov>

Cc: Kade, Matthew H <mkade@blm.gov>; Lucero, Virgil S <vlucero@blm.gov>; Haque, Mustafa H <mhaque@blm.gov>; Wenman, Christopher P <cwenman@blm.gov>; Quintana, Hubert H <hquintana@blm.gov>; Runnels, Micah C <Micah.Runnels@bia.gov>; Jaquez, Laverna A <laverna.jaquez@bia.gov>; Klein, Ross H <rklein@blm.gov>; Combs, Nathan D <ncombs@blm.gov>; Halliburton, Darin L <dhallibu@blm.gov>; Gibson, Michael J <mjgibson@blm.gov>; Bryson, Tye A <TBryson@blm.gov>; Joe, Maureen A <mjoe@blm.gov>; Kade, Matthew H <mkade@blm.gov>; Decker, Mark A <mdecker@blm.gov>; Rios, Jose E <jrios@blm.gov>

 5 attachments (607 KB)

General_Requirement_PxA.pdf; P&A procedure for N Dzis Pah #002.pdf; P&A procedure for Na Dzis Pah #001.pdf; P&A procedure for State Senate #002.pdf; P&A procedure for Indian #003.pdf;

Thank you, Jim.

The BLM finds the procedures appropriate. Aztec Well Servicing should be familiar with our general requirements. But please ensure that they are aware. The requirement document is attach.

And please have them call us at 505 564-7750 at least 24 hours before the plugging operations commence. We will send a field inspector to witness operations.

And finally note there may be minor road work needed to move the rig, and other equipment, in. That may push the start/ finish date back.

Let us know if you have additional questions.

Kenneth Rennick

Kenneth (Kenny) Rennick

Petroleum Engineer

Bureau of Land Management
Farmington Field Office
6251 College Blvd
Farmington, NM 87402

Email: krennick@blm.gov

Mobile & Text: 505.497.0019

From: Griswold, Jim, EMNRD <Jim.Griswold@emnrd.nm.gov>

Sent: Friday, May 17, 2024 10:47 AM

To: Rennick, Kenneth G <krennick@blm.gov>

Subject: RE: [EXTERNAL] BLM Farmington NM -- Request to Plug Allottee Wells

Kenneth,

Attached you will find plugging procedures for the four wells in question prepared by Aztec Well Servicing (our chosen plugging contractor). Could you please review them. If you have any changes, please let me know. We are trying to get Aztec into the field and done before the end of the state's fiscal year, June 30th. Thanks.

OCD also intends to measure methane emissions from all four wells before plugging, and to remove/salvage and unused infrastructure.

Jim Griswold

Oil Conservation Division
5200 Oakland NE, Suite A
Albuquerque, New Mexico 87113
505.660.1067

From: Rennick, Kenneth G <krennick@blm.gov>

Sent: Thursday, May 16, 2024 2:22 PM

To: Powell, Brandon, EMNRD <Brandon.Powell@emnrd.nm.gov>; Griswold, Jim, EMNRD <Jim.Griswold@emnrd.nm.gov>

Cc: Kade, Matthew H <mkade@blm.gov>; Lucero, Virgil S <vlucero@blm.gov>; Haque, Mustafa H <mhaque@blm.gov>; Wenman, Christopher P <cwenman@blm.gov>; Quintana, Hubert H <hquintana@blm.gov>; Runnels, Micah C <Micah.Runnels@bia.gov>; Jaquez, Laverna A <laverna.jaquez@bia.gov>; Klein, Ross H <rklein@blm.gov>; Combs, Nathan D <ncombs@blm.gov>; Halliburton, Darin L <dhallibu@blm.gov>; Gibson, Michael J <mjgibson@blm.gov>; Bryson, Tye A <TBryson@blm.gov>; Joe, Maureen A <mjoe@blm.gov>; Mankiewicz, David J <dmankiew@blm.gov>; Decker, Mark A <mdecker@blm.gov>

Subject: [EXTERNAL] BLM Farmington NM -- Request to Plug Allottee Wells

CAUTION: This email originated outside of our organization. Exercise caution prior to clicking on links or opening attachments.

Per the direction of BLM New Mexico State Office, the BLM Farmington Field Office and the Federal Indian Mineral Office (FIMO) does request NM OCD to plug the below four listed allottee wells. We also request that the associated equipment be removed and reclamation be completed.

Please provide a confirmation of the estimate when plugging work will be completed. And if applicable, the removal of equipment and reclamation.

Reviewing equipment associated to the four wells, there should not be a significant salvage value to compensate for the removal. If there is, the BLM and FIMO will not object NM OCD keeping the remaining money to apply for the plugging and reclamation cost of the four wells.

Feel free to let us know if there is need for additional clarifications.

Kenneth Rennick

List of Wells:

Well Name	Well Number	US Well Number
INDIAN	3	30-045-21595
STATE SENATE	2	30-045-09889
NA DZIS PAH	1	30-045-09949
NA DZIS PAH	2	30-045-10016

Kenneth (Kenny) Rennick

Petroleum Engineer

Bureau of Land Management
Farmington Field Office
6251 College Blvd
Farmington, NM 87402

Email: krennick@blm.gov

Mobile & Text: 505.497.0019



NMOCD
Plug & Abandon Procedure
 May 13, 2024

Well:	Indian #003	API:	30-045-21595
Location:	2310' FSL & 330' FEL	Field:	Gallup
Sec,T, R:	Sec 02 30N-16W	Elevation:	GL: 5540'
Cnty/State:	San Juan, New Mexico	By:	Aztec Well Servicing
Lat/Long:	36.842186, -108.4864197		

Objective:

Permanently plug & abandon the well from 1807' containing 2 cement plugs.

Note:

All cement volumes use 100% excess outside casing and 50' excess inside pipe. Stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures. All cement will be ASTM Class G neat 15.8ppg, 1.15ft³/ft yield, 5.0gal/sk or equivalent. If casing pressure tests tagging plugs will not be required.

Prior to Rig:

1. Notify NMOCD and BLM
2. Note: verify all cement volumes based on actual slurry to be pumped.
3. See attached COA's from NMOCD and BLM.

Procedure:


1. MIRU well servicing rig and cement equipment.
2. Check casing, tubing, and BH pressures.
3. Removed existing piping on casing valve. RU blow lines from casing valves and begin blowing down casing pressure. Kill well as necessary. Ensure well is dead or on a vacuum.
4. LD rods on tubing float.
5. ND wellhead and NU BOP. Function test BOP. RU floor and 2-3/8" handling tools.
6. LD production tubing.
7. PU and tally work string and RIH with casing scraper to 1450'.
8. TOOH and LD casing scraper.
9. TIH with 4-1/2" CICR and set @ 1434'.
10. Roll the hole with fresh water and pressure test casing to 500 psi. If casing does not test, then spot or tag subsequent plugs as appropriate. WOC to be determined upon pressure test.
11. TOOH and rig up WL and run CBL from 1434' to surface. RD WL.
12. TIH to CICR.
13. **Plug #1, 1654' – 1300' (Gallup Top: 1542')** Mix & pump 48 sxs of class G cement and squeeze 33 sxs below CICR and spot 14 sxs on top of CICR to cover the Gallup top. Pull up and reverse circulate tubing clean.
14. WOC then tag plug to confirm TOC.




NMOCD
Plug & Abandon Procedure
 May 13, 2024

Well:	Indian #003	API:	30-045-21595
Location:	2310' FSL & 330' FEL	Field:	Gallup
Sec,T, R:	Sec 02 30N-16W	Elevation:	GL: 5540'
Cnty/State:	San Juan, New Mexico		
Lat/Long:	36.842186, -108.4864197	By:	Aztec Well Servicing

15. LD remaining tubing.
16. RU WL and perforate @ 400'. Pump fresh water and establish an injection rate. RD WL.
17. **Plug #2, 400' – surface (Mancos Top: 350' Surface Shoe: 100')** Mix & pump 132 sxs Class G cement and pump down 4-1/2" casing and back up BH until good cement returns to surface to cover the Mancos top, and the surface shoe. Top off as necessary.
18. NP BOP, cut off wellhead below surface casing flange per regulation. Top off w/cement if needed. Install P&A marker with cement to comply with regulations. RD and MOL. Restore location per BLM stipulations.





State of New Mexico
Energy, Minerals and Natural Resources Department

Michelle Lujan Grisham
Governor

Sarah Cottrell Propst
Cabinet Secretary

Dylan M. Fuge
Deputy Secretary

Dylan M. Fuge, Division Director (Acting)
Oil Conservation Division



NOTICE

NEW MEXICO PLUG AND ABANDON CONDITIONS OF APPROVAL

Effective January 1, 2024

The New Mexico Oil Conservation Division (“OCD”) is announcing the release of its updated Plugging and Abandoning Conditions of Approval (“COA”). These COAs will bring consistency throughout the state and formalize existing practice in the field that are already being required by OCD and performed by Operators. OCD staff reviewing plans are directed to implement these COA’s are throughout the entire State of New Mexico, except when circumstances warrant modifications or additional requirements as dictated by specific plugging project conditions, which determines are left solely to OCD.

For the most part, these updates simply consolidate current practice to ensure it applied uniformly state-wide. The most significant changes from existing practice are as follows:

- **Logs.**
 - A Cement Bond Log is required to ensure isolation of producing formations, protection of water and correlative rights. A CBL must be run or be on file that can properly evaluate the cement behind the casing.

Note: Logs must be submitted to OCD via OCD permitting. A copy of the log may be emailed to the Compliance Officer Supervisor for faster review times, but email transmittal does not relieve the requirement for an operator to file through OCD permitting.
- **Cement:**
 - A table has been included which indicates the Class of cement and its allowed lower limits. This table is intended to align OCD requirements with applicable API standards and the Haliburton Redbook.
 - We are also standardizing practices with respect to cement waiting times:
 - 4 hours for accelerated (calcium chloride) cement.
 - 6 hours on regular cement.
- **Formations:**

1220 South St. Francis Drive • Santa Fe, New Mexico 87505
Phone (505) 476-3460 • Fax (505) 476-3462 • www.emnrd.nm.gov

- The COAs now include appendices for geological formation tops that shall be plugged.

The updated plugging COAs are attached to this notice. These COAs are effective for plugging operations for any NOI C-103F submitted on or after January 1, 2024, unless OCD determines that a modification or additional COAs are necessary based on specific plugging project conditions.

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division
Standard Plugging Conditions



This document provides OCD's general plugging conditions of approval. It should be noted that the list below may not cover special plugging programs in unique and unusual cases, and OCD expressly reserves the right to impose additional requirements to the extent dictated by project conditions. The OCD also reserves the right to approve deviations from the below conditions if field conditions warrant a change. A C-103F NOI to P&A must be approved prior to plugging operations. Failure to comply with the conditions attached to a plugging approval may result in a violation of 19.15.5.11 NMAC, which may result in enforcement actions, including but not limited to penalties and a requirement that the well be re-plugged as necessary.

1. Notify OCD office at least 24 hours before beginning work and seek prior approval to implementing any changes to the C-103 NOI to PA.
 - North Contact, Monica Kuehling, 505-320-0243, monica.kuehling@emnrd.nm.gov
 - South Contact, Gilbert Cordero, 575-626-0830, gilbert.cordero@emnrd.nm.gov
2. A Cement Bond Log is required to ensure strata isolation of producing formations, protection of water and correlative rights. A CBL must be run or be on file that can be used to properly evaluate the cement behind the casing.

Note: Logs must be submitted to OCD via OCD permitting. A copy of the log may be emailed to OCD inspector for faster review times, but emailing does not relieve the operators obligation to submit through OCD permitting.

3. Once Plugging operations have commenced, the rig must not rig down until the well is fully plugged without OCD approval. If gap in plugging operations exceeds 30 days, the Operator must file a subsequent sundry of work performed and revised NOI for approval on work remaining. At no time shall the rig be removed from location if it will result in waste or contamination of fresh water.
4. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
5. Fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
 - North, water or mud laden fluids
 - South, mud laden fluids
6. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to an OCD permitted disposal facility.
7. Class of cement shall be used in accordance with the below table for depth allowed.

Class	TVD Lower Limit (feet)
Class A/B	6,000
Class I/II	6,000
Class C or III	6,000
Class G and H	8,000
Class D	10,000

Class E	14,000
Class F	16,000

8. After cutting the well head any "top off cement jobs" must remain static for 30 minutes. Any gas bubbles or flow during this 30 minutes shall be reported to the OCD for approval of next steps.
9. Trucking companies being used to haul oilfield waste fluids (Commercial or Private) to a disposal facility shall have an approved OCD C-133 permit.
 - A copy of this permit shall be available in each truck used to haul waste products.
 - It is the responsibility of the Operator and Contractor to verify that this permit is in place prior to performing work.
 - Drivers shall be able to produce a copy upon request of an OCD Compliance Officer.
10. Filing a [C-103] Sub. Plugging (C-103P) will serve as notification that the well has been plugged.
11. A [C-103] Sub. Release After P&A (C-103Q) shall be filed no later than a year after plugging and a site inspection by OCD Compliance officer to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to meet OCD standards before bonding can be released.
12. Produced water or brine-based fluids **may not** be used during any part of plugging operations without **prior OCD approval**.
13. Cementing;
 - All cement plugs will be neat cement and a minimum of 100' in length. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
 - If cement does not exist between or behind the casing strings at recommended formation depths, the casing perforations will be shot at 50' below the formation top and the cement retainer shall be set no more than 50' from the perforations.
 - WOC (Wait on Cement) time will be:
 - 4 hours for accelerated (calcium chloride) cement.
 - 6 hours on regular cement.
 - Operator must tag all cement plugs unless it meets the below condition.
 - The operator has a passing pressure test for the casing annulus and the plug is only an inside plug.
 - If perforations are made operator must tag all plugs using the work string to tag unless given approval to tag with wireline by the correct contact from COA #1 of this document.
 - This includes plugs pumped underneath a cement retainer to ensure retainer seats properly after cement is pumped.
 - Cement can only be bull-headed with specific prior approval.
 - Squeeze pressures are not to exceed the exposed formations frac gradient or the burst pressure of the casing.
14. A cement plug is required to be set from 50' below to 50' above (straddling) formation tops, casing shoes, casing stubs, any attempted casing cut offs, anywhere the casing is perforated, DV tools.
 - Perforation/Formation top plug. (When there is less than 100ft between the top perforation to the formation top.) These plugs are required to be started no greater than

50ft from the top perforation. However, the plug should be set below the formation top or as close to the formation top as possible for the maximum isolation between the formations. The plug is required to be a 100ft cement plug plus excess.

- Perforation Plug when a formation top is not included. These plugs are required to be started within 50ft of the top perforation. The plug is required to be a 100ft cement plug plus excess.
- Cement caps on top of bridge plugs or cement retainers for perforation plugs, that are not straddling a formation top, may be set using a bailer with a minimum of 35' of cement in lieu of the 100' plug. The bridge plug or retainer must be set within 50ft of the perforations.
- Perforations are required below the surface casing shoe if cement does not exist behind the casing, a 30-minute minimum wait time will be required immediately after perforating to determine if gas and/or water flows are present. If flow is present, the well will be shut-in for a minimum of one hour and the pressure recorded. If gas is detected contact the OCD office for directions.

15. No more than 3000 feet is allowed between cement plugs in cased hole and no more than 2000 feet is allowed in open hole.

16. Formation Tops to be isolated with cement plugs, but not limited to are:

- Northwest See Figure A
- South (Artesia) See Figure B
- Potash See Figure C
 - In the R-111-P (Or as subsequently revised) Area a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, woe 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- South (Hobbs) See Figure D1 and D2
- Areas not provided above will need to be reviewed with the OCD on a case by case basis.

17. Markers

- Dry hole marker requirements 19.15.25.10.

The operator shall mark the exact location of plugged and abandoned wells with a steel marker not less than four inches in diameter set in cement and extending at least four feet above mean ground level. The marker must include the below information:

 1. Operator name
 2. Lease name and well number
 3. API number
 4. Unit letter
 5. Section, Township and Range
- AGRICULTURE (Below grade markers)

In Agricultural areas a request can be made for a below ground marker. For a below ground marker the operator must file their request on a C-103 notice of intent, and it must include the following;

 - A) Aerial photo showing the agricultural area
 - B) Request from the landowner for the below ground marker.

C) Subsequent plugging report for a well using a below ground marker must have an updated C-102 signed by a certified surveyor for SHL.

Note: A below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to OCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to OCD. OCD requires a current survey to verify the location of the below ground marker, however OCD will accept a GPS coordinate that were taken with a GPS that has an accuracy of within 15 feet.

18. If work has not commenced within 1 year of the approval of this procedure, the approval is automatically expired. After 1 year a new [C-103] NOI Plugging (C-103F) must be submitted and approved prior to work.

Figure A

North Formations to be isolated with cement plugs are:

- San Jose
- Nacimiento
- Ojo Alamo
- Kirtland
- Fruitland
- Picture Cliffs
- Chacra (if below the Chacra Line)
- Mesa Verde Group
- Mancos
- Gallup
- Basin Dakota (plugged at the top of the Graneros)
- Deeper formations will be reviewed on a case-by-case basis

Figure B

South (Artesia) Formations to be isolated with cement plugs are:

- Fusselman
- Montoya
- Devonian
- Morrow
- Strawn
- Atoka
- Permo-Penn
- Wolfcamp
- Bone Springs
- Delaware , in certain areas where the Delaware is subdivided into;
 - 1. Bell Canyon
 - 2. Cherry Canyon
 - 3. Brushy Canyon
- Any salt sections
- Abo
- Yeso
- Glorieta
- San Andres
- Greyburg
- Queen
- Yates

Figure C

Potash Area R-111-P

T 18S – R 30E

Sec 10 Unit P. Sec 11 Unit M,N. Sec 13 Unit L,M,N. Sec 14 Unit C -P. Sec 15 Unit A G,H,I,J,K,N,O,P. Sec 22 Unit All
except for M. Sec 23, Sec 24 Unit C,D,E,L, Sec 26 Unit A-G, Sec 27 Unit A,B,C

T 19S – R 29E

Sec 11 Unit P. Sec 12 Unit H-P. Sec 13. Sec 14 Unit A,B,F-P. Sec 15 Unit P. Sec 22 Unit A,B,C,F,G,H,I,J K,N,O,P. Sec 23.
Sec 24. Sec 25 Unit D. Sec 26 Unit A- F. Sec 27 Unit A,B,C,F,G,H.

T 19S – R 30E

Sec 2 Unit K,L,M,N. Sec 3 Unit I,L,M,N,O,P. Sec 4 Unit C,D,E,F,G,I-P. Sec 5 Unit A,B,C,E-P. Sec 6 Unit I,O,P. Sec 7 – Sec
10. Sec 11 Unit D, G—P. Sec 12 Unit A,B,E-P. Sec 13 Unit A-O. Sec 14-Sec 18. Sec 19 Unit A-L, P. Sec 20 – Sec 23. Sec
24 Unit C,D,E,F,L,M,N. Sec 25 Unit D. Sec 26 Unit A-G, I-P. Sec 27, Sec 28, Sec 29 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 32
Unit A,B,G,H,I,J,N,O,P. Sec 33. Sec 34. Sec 35. Sec 36 Unit D,E,F,I-P.

T 19S – R 31E

Sec 7 Unit C,D,E,F,L. Sec 18 Unit C,D,E,F,G,K,L. Sec 31 Unit M. Sec 34 Unit P. Sec 35 Unit M,N,O. Sec 36 Unit O,P.

T 20S – R 29E

Sec 1 Unit H,I,P. Sec 13 Unit E,L,M,N. Sec 14 Unit B-P. Sec 15 Unit A,H,I,J,N,O,P. Sec 22 Unit A,B,C,F,G,H,I,J,O,P. Sec
23. Sec 24 Unit C,D,E,F,G,J-P. Sec 25 Unit A-O. Sec 26. Sec 27 Unit A,B,G,H,I,J,O,P. Sec 34 Unit A,B,G,H. Sec 35 Unit
A-H. Sec 36 Unit B-G.

T 20S – R 30E

Sec 1 – Sec 4. Sec 5 Unit A,B,C,E-P. Sec 6 Unit E,G-P. Sec 7 Unit A-H,I,J,O,P. Sec 8 – 17. Sec 18 Unit A,B,G,H,I,J,O,P.
Sec 19 Unit A,B,G,H,I,J,O,P. Sec 20 – 29. Sec 30 Unit A-L,N,O,P. Sec 31 Unit A,B,G,H,I,P. Sec 32 – Sec 36.

T 20S – R 31E

Sec 1 Unit A,B,C,E-P. Sec 2. Sec 3 Unit A,B,G,H,I,J,O,P. Sec 6 Unit D,E,F,J-P. Sec 7. Sec 8 Unit E-P. Sec 9 Unit E,F,J-P.
Sec 10 Unit A,B,G-P. Sec 11 – Sec 36.

T 21S – R 29E

Sec 1 – Sec 3. Sec 4 Unit L1 – L16,I,J,K,O,P. Sec 5 Unit L1. Sec 10 Unit A,B,H,P. Sec 11 – Sec 14. Sec 15 Unit A,H,I. Sec
23 Unit A,B. Sec 24 Unit A,B,C,D,F,G,H,I,J,O,P. Sec 25 Unit A,O,P. Sec 35 Unit G,H,I,J,K,N,O,P. Sec 36 A,B,C,F – P.

T 21S – R 30E

Sec 1 – Sec 36

T 21S – R 31E

Sec 1 – Sec 36

T 22S – R 28E

Sec 36 Unit A,H,I,P.

T 22S – R 29E

Sec 1. Sec2. Sec 3 Unit I,J,N,O,P. Sec 9 Unit G – P. Sec 10 – Sec 16. Sec 19 Unit H,I,J. Sec 20 – Sec 28. Sec 29 Unit

A,B,C,D,G,H,I,J,O,P. Sec 30 Unit A. Section 31 Unit C – P. Sec 32 – Sec 36

T 22S – R 30E

Sec 1 – Sec 36

T 22S – R 31E

Sec 1 – Sec 11. Sec 12 Unit B,C,D,E,F,L. Sec 13 Unit E,F,K,L,M,N. Sec 14 – Sec 23. Sec 24 Unit C,D,E,F,K,L,M,N. Sec 25

Unit A,B,C,D. Sec 26 Unit A,BC,D,G,H. Sec 27 – Sec 34.

T 23S – R 28E

Sec 1 Unit A

T 23S – R 29E

Sec 1 – Sec 5. Sec 6 Unit A – I, N,O,P. Sec 7 Unit A,B,C,G,H,I,P. Sec 8 Unit A – L, N,O,P. Sec 9 – Sec 16. Sec 17 Unit

A,B,G,H,I,P. Sec 21 – Sec 23. Sec 24 Unit A – N. Sec 25 Unit D,E,L. Sec 26. Sec 27. Sec 28 Unit A – J, N,O,P. Sec 33

Unit A,B,C. Sec 34 Unit A,B,C,D,F,G,H. Sec 35. Sec 36 Unit B,C,D,E,F,G,K,L.

T 23S – R 30E

Sec 1 – Sec 18. Sec 19 Unit A – I,N,O,P. Sec 20, Sec 21. Sec 22 Unit A – N, P. Sec 23, Sec 24, Sec 25. Sec 26 Unit

A,B,F-P. Sec 27 Unit C,D,E,I,N,O,P. Sec 28 Unit A – H, K,L,M,N. Sec 29 Unit A – J, O,P. Sec 30 Unit A,B. Sec 32 A,B. Sec

33 Unit C,D,H,I,O,P. Sec 34, Sec 35, Sec 36.

T 23S – R 31E

Sec 2 Unit D,E,J,O. Sec 3 – Sec 7. Sec 8 Unit A – G, K – N. Sec 9 Unit A,B,C,D. Sec 10 Unit D,P. Sec 11 Unit G,H,I,J,M,N,O,P. Sec 12 Unit E,L,K,M,N. Sec 13 Unit C,D,E,F,G,J,K,L,M,N,O. Sec 14. Sec 15 Unit A,B,E – P.

Sec 16 Unit

I, K – P. Sec 17 Unit B,C,D,E, I – P. Sec 18 – Sec 23. Sec 24 Unit B – G, K,L,M,N. Sec 25 Unit B – G, J,K,L. Sec 26 – Sec

34. Sec 35 Unit C,D,E.

T 24S – R 29E

Sec 2 Unit A, B, C, D. Sec 3 Unit A

T 24S – R 30E

Sec 1 Unit A – H, J – N. Sec 2, Sec 3. Sec 4 Unit A,B,F – K, M,N,O,P. Sec 9 Unit A – L. Sec 10 Unit A – L, O,P. Sec 11.

Sec 12 Unit D,E,L. Sec 14 Unit B – G. Sec 15 Unit A,B,G,H.

T 24S – R 31E

Sec 3 Unit B – G, J – O. Sec 4. Sec 5 Unit A – L, P. Sec 6 Unit A – L. Sec 9 Unit A – J, O, P. Sec 10 Unit B – G, K – N. Sec

35 Unit E – P. Sec 36 Unit E, K, L, M, N.

T 25S – R 31E

Sec 1 Unit C, D, E, F. Sec 2 Unit A – H.

Figure D1 and D2

South (Hobbs) Formations to be isolated with cement plugs are:

The plugging requirements in the Hobbs Area are based on the well location within specific areas of the Area (See Figure D1). The Formations in the Hobbs Area to be isolated with cement plugs are (see Figure D2)

Figure D1 Map




Figure D2 Formation Table

100' Plug to isolate upper and lower fresh water zones (typically 250' to 350')						
Northwest Shelf	Captan Reef Area	Transition Zone	San Simon Channel	South Vacuum Structure	Delaware Basin	Central Basin Platform
Granit Wash (Detrital basement material and fractured pre-Cambrian basement rock)	Siluro-Devonian	Morrow	Siluro-Devonian	Ellenburger	Siluro-Devonian	Granit Wash (Detrital basement material, fractured pre-Cambrian basement rock and fracture Mafic Volcanic intrusives).
Montoya	Mississippian	Atoka	Morrow	McKee	Morrow	Ellenburger
Fusselman	Morrow	Strawn	Wolfcamp	Siluro-Devonian	Atoka	Connell
Woodford	Atoka	Cisco	Abo Reef	Woodford	Strawn	Waddell
Siluro-Devonian	Strawn	Pennsylvanian	Bone Spring	Mississippian	Pennsylvanian	McKee
Chester	Pennsylvanian	Wolfcamp	Delaware	Barnett Shale	Lower Wolfcamp	Simpson Group
Austin	Wolfcamp	Bone Spring	San Andres	Morrow	Upper Wolfcamp	Montoya
Mississippian	Abo Reef, if present	Delaware	Queen	Atoka	Wolfcamp	Fusselman
Morrow	Abo, if present	San Andres	Yates	Strawn	Third Bone Spring Sand (Top of Wolfbone)	Silurian
Atoka	Queen, if present	Grayburg-San Andres	Base of Salt	Canyon	First Bone Spring Sand (Top of Lower Bone Spring)	Devonian
Lower Pennsylvanian	Bone Spring	Queen	Rustler	Pennsylvanian	Bone Spring	Strawn
Cisco-Canyon	Delaware	Seven Rivers		Blinbry	Brushy Canyon	Pennsylvanian
Pennsylvanian	Base Capitan Reef	Yates		Bone Spring	Delaware (Base of Salt)	Wolfcamp
Bough	Seven Rivers	Base of Salt		San Andres	Rustler	Abo
Wolfcamp	Yates	Rustler		Queen		Abo Reef
Abo	Top Capitan Reef			Base of Salt		Drinkard
Abo Reef, if present	Base of Salt			Rustler		Tubb
Yeso (Township 15 South to Township 17 South)	Rustler					Blinbry
Drinkard or Lower Yeso (Township 15 South to Township 17 South)						Paddock
Tubb (Township 15 South to Township 17 South)						Glorieta
Blinbry (Township 15 South to Township 17 South)						San Andres
Paddock (Township 15 South to Township 17 South)						Grayburg
Glorieta						Grayburg-San Andres
San Andres						Queen
Queen (Township 15 South to Township 17 South)						Seven Rivers
Seven Rivers (Township 15 South to Township 17 South)						Yates
Yates (Township 15 South to Township 17 South)						Base of Salt
Base of Salt						Rustler
Rustler						

District I
1625 N. French Dr., Hobbs, NM 88240
Phone:(575) 393-6161 Fax:(575) 393-0720
District II
811 S. First St., Artesia, NM 88210
Phone:(575) 748-1283 Fax:(575) 748-9720
District III
1000 Rio Brazos Rd., Aztec, NM 87410
Phone:(505) 334-6178 Fax:(505) 334-6170
District IV
1220 S. St Francis Dr., Santa Fe, NM 87505
Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 346845

CONDITIONS

Operator: AZTEC WELL SERVICING CO 300 Legion Road Aztec, NM 87410	OGRID: 191362
	Action Number: 346845
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
loren.diede	Notify NMOCD 24 hours prior to beginning P&A operations.	5/22/2024
loren.diede	Submit CBL to NMOCD via Electronic Permitting.	5/22/2024