

Submit 1 Copy To Appropriate District
Office
District I – (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II – (575) 748-1283
811 S. First St., Artesia, NM 88210
District III – (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV – (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-005-10529
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Ridgeway Arizona Oil Corp.		6. State Oil & Gas Lease No.
3. Address of Operator 575 N. Dary Ashford, Suite 210, Houston, TX 77079		7. Lease Name or Unit Agreement Name KM Chaveroo SA
4. Well Location Unit Letter M: 990 feet from the S line and 660 feet from the W line Section 02 Township 08S Range 33E NMPM County Chaves		8. Well Number 111
11. Elevation (Show whether DR, RKB, RT, GR, etc.)		9. OGRID Number 164557
		10. Pool name or Wildcat CHAVEROO;SAN ANDRES

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>			
CLOSED-LOOP SYSTEM <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

NMOCD plans to plug this well in accordance with the attached procedure and any agreed modifications thereto.

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE: Ethan Wakefield

TITLE: Authorized Representative DATE 7/9/24

Type or print name: Ethan Wakefield

E-mail address: e.wakefield@dwsrigs.com

PHONE: 405-343-7736

For State Use Only

APPROVED BY: _____ TITLE _____ DATE _____

Conditions of Approval (if any):

RIDGEWAY ARIZONA OIL CORP.

Plug And Abandonment Procedure

KM CHAVEROO SA UNIT #111

990' FSL & 660' FWL, Section 02, 08S, 33E

Chaves County, NM / API 30-005-10529

LPCH: Yes

1. Hold pre-job safety meeting. Comply with all NMOCD, BLM safety and environmental regulations. Test rig anchors prior to moving in rig if not rigged to base beam.
2. Perform spiral gas check. Check casing, tubing, and Bradenhead pressures.
3. Remove existing piping on casing valve. RU blow lines from casing valves and begin blowing down casing pressure. Perform mandatory 40 bbls well kill. If a different fluid or amount is required kill well as necessary. Ensure well is dead or on a vacuum.
4. ND wellhead and NU BOP. Function test BOP.
5. P/U 5-1/2" bit or casing scraper on 2-3/8" work string and round trip as deep as possible above top perforation at 4,210'.
6. P/U 5-1/2" CR, TIH and set CR at +/- 4,160'. Pressure test tubing to 1000 psi. Sting out of CR. Load hole, and pressure test casing to 800 psi. If casing does not test, then spot or tag subsequent plugs as appropriate. POOH w/ tubing.
7. RU wireline and run CBL with 500 psi on casing from CR at 4,160' to surface to identify TOC. Adjust plugs as necessary for new TOC. Email log copy to

Loren Diede at loren.diede@emnrd.nm.gov and to Gilbert Cordero at gilbert.cordero@emnrd.nm.gov upon completions of logging operations.

8. Rig up to pump cement down tubing. Pump water to establish rate down tubing.
9. Circulate wellbore.

NOTE: All Plugs Include 100% excess outside casing and 50% Excess inside casing

10. Plug 1 (Perforations, 4,160'-3,945', 25 Sacks Type I/II Cement)

Mix 25 sx Type I/II cement and spot a balanced plug inside casing to cover the perforations.

11. Plug 2 (San Andres Formation Top, 3,556'-3,341', 25 Sacks Type I/II Cement)

Mix 25 sx Type I/II cement and spot a balanced plug inside casing to cover the San Andres formation top.

12. Plug 3 (Queen Formation Top, 3,042'-2,827', 25 Sacks Type I/II Cement)

Mix 25 sx Type I/II cement and spot a balanced plug inside casing to cover the Queens formation top.

13. Plug 4 (7 Rivers, Yates, and Base Salt Formation Tops, 2,556'-2,125', 51 Sacks Type I/II Cement)

Mix 51 sx Type I/II cement and spot a balanced plug inside casing to cover the 7 Rivers, Yates, and Base Salt formation tops.

14. Plug 5 (Rustler Formation Top, 2,022'-1,807', 25 Sacks Type I/II Cement)

Mix 25 sx Type I/II cement and spot a balanced plug inside casing to cover the Rustler formation top.

15. Plug 6 (Surface Casing Shoe 456'-Surface, 142 Sacks Type I/II Cement)

Attempt to pressure test the bradenhead annulus to 300 psi; note the volume to load. If BH annulus holds pressure, then establish circulation out casing valve with water. Mix approximately 142 sx cement and spot a balanced plug from 456' to surface, circulate good cement out of casing valve. TOH and LD tubing. Shut well in and WOC. If BH annulus does not test, then perforate at the appropriate depth and attempt to circulate cement to surface filling the casing from 456' and the annulus from the squeeze holes to surface. Shut in well and WOC.

16. ND cementing valves and cut off wellhead. Fill annuli with cement as necessary. Install P&A marker to comply with regulations. Record GPS coordinate for P&A marker on tower report. Photograph P&A marker in place. RD, MOL and restore location per BLM stipulations.

Existing Wellbore Diagram

RIDGEWAY ARIZONA OIL CORP.

KM CHAVEROO SA UNIT #111

API: 30-005-10529

Chaves County, New Mexico

Surface Casing

8.625" 24# @ 406 ft

OH: 12.25'

Estimated Formations

Rustler - 1972 feet

Base Salt - 2225 feet

Yates - 2323 feet

7 Rivers - 2506 feet

Queen - 2992 feet

San Andres - 3506 feet


Perforations

4210 feet - 4332 feet

Production Casing

5.5" 14# @ 4344 feet

OH: 7.875"



Proposed Wellbore Diagram

RIDGEWAY ARIZONA OIL CORP.
KM CHAVEROO SA UNIT #111
API: 30-005-10529
Chaves County, New Mexico

LPCH: YES

Surface Casing

8.625" 24# @ 406 ft
OH: 12.25'

Plug 6

456 feet - surface
456 foot plug
142 Sacks of Type I/II Cement

Plug 5

2022 feet - 1807 feet
215 foot plug
25 Sacks of Type I/II Cement

Plug 4

2556 feet - 2125 feet
431 foot plug
51 Sacks of Type I/II Cement

Plug 3

3042 feet - 2827 feet
215 foot plug
25 Sacks of Type I/II Cement

Plug 2

3556 feet - 3341 feet
215 foot plug
25 Sacks of Type I/II Cement

Plug 1

4160 feet - 3945 feet
215 foot plug
25 sacks of Type I/II Cement

Perforations

4210 feet - 4332 feet


Estimated Formations

Rustler - 1972 feet
Base Salt - 2225 feet
Yates - 2323 feet
7 Rivers - 2506 feet
Queen - 2992 feet
San Andres - 3506 feet

Estimated TOC: 3200'

Retainer @ 4160 feet

Production Casing
5.5" 14# @ 4344 feet



OH: 7.875"



District I
1625 N. French Dr., Hobbs, NM 88240
Phone:(575) 393-6161 Fax:(575) 393-0720
District II
811 S. First St., Artesia, NM 88210
Phone:(575) 748-1283 Fax:(575) 748-9720
District III
1000 Rio Brazos Rd., Aztec, NM 87410
Phone:(505) 334-6178 Fax:(505) 334-6170
District IV
1220 S. St Francis Dr., Santa Fe, NM 87505
Phone:(505) 476-3470 Fax:(505) 476-3462

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 371007

CONDITIONS

Operator: J.A. Drake Well Service Inc. 607 W Pinon Farmington, NM 87401	OGRID: 330485
	Action Number: 371007
	Action Type: [C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
loren.diede	Notify NMOCD 24 hours prior to beginning P&A operations.	8/7/2024
loren.diede	Submit CBL to NMOCD via E Permitting.	8/7/2024
loren.diede	This well is within the LPCH restricted area and a below-ground P&A marker is required.	8/7/2024
loren.diede	Attach a photo of the P&A marker and marker GPS coordinates to the C-103P subsequent report.	8/7/2024