### State of New Mexico

## **Energy, Minerals and Natural Resources Department**Oil Conservation Division Hobbs District Office

		BRADENHEAD TH	EST REPORT					
ATO Somian				30.05.35083				
Porestake Unit				Well No.				
* Surface Location								
UL; Lot Section Township Range Feet from N/S Line			N/S Line Feet I		County			
H 12 2	45 29 E	1980	N lolo	0   E	Eddy			
Well Status								
YES TA'D WELL NO	SHUT-IN YES	NO INJ	SWD OIL PRODUC	GAS ///	7 2024			
OBSERVED DATA								
	(A)Surface	(B)Interm(1)	(C)Interm(2)	(D)Prod Csng	(E)Tubing			
Pressure	0			0	TTA			
Flow Characteristics	~			6	C02			
Puff	Y /(N)	Y / N/	Y/N	Y/N	CO2 WTR_			
Steady Flow	Y/N	Y / X	X / N	Y/N	GAS _			
Surges  Down to nothing	(Y)/ N	Y/N	Y/N	Y/N/N	Type of Fluid Injected for			
Gas or Oil	Y (A)	Y/N	Y/N	Y	Waterfluod #			
Water	YIN	Y/N	Y/N	Y/N	applies			
<u> </u>			<u> </u>					
Remarks - Please state for each		nent information regarding ble	ed down or continuous build u	p if applies.				
Signature:				OIL CONSERVATION DIVISION				
Printed name:				Entered into RBDMS  Re-test				
Title								
E-mail Address:								
Date:	Phone	DE VE	<del>\</del>					
	Witness.	1800 supplied						

INSTRUCTIONS ON BACK OF THIS FORM

#### General Procedure for Bradenhead Test

Identify: All valves prior to testing

Gauges: Install on each casing string to record pressure.

Assure: That all valves are in good working condition and closed at least 24 hours prior

to testing.

Open: Each valve (Bradenhead, intermediate and casing valves) is to be opened

separately.

Check Gauges: Record pressure on each gauge and casing string on BHT form. Open valves to atmosphere and record results on BHT form.

Designate what applies to the result of opening the valves for each string:

Blow or Puff
Bled down to Nothing
Steady Flow
Oil or Gas
Water
Yes or No

Start: Injection or SWD pump so tubing pressure can be read.

Instructions below apply to the District 1 Hobbs office since this must be reported on a form.

#### In case of pressure:

- 1. Record pressure reading on gauge.
- 2. Bleed and note time elapsed to bleed down.
- 3. Leave valve open for additional observation.
- 4. Note any fluids expelled.

#### In absence of Pressure:

- 1. Leave valve open for additional observation.
- 2. Note types of fluids expelled.
- 3. Note if fluids persist throughout test.

Note: Tubing pressure on injection or SWD wells.

Test will be signed by person performing test with a contact phone number.

Sante Fe Main Office Phone: (505) 476-3441

General Information Phone: (505) 629-6116

Online Phone Directory https://www.emnrd.nm.gov/ocd/contact-us

# State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. Santa Fe, NM 87505

CONDITIONS

Action 403882

#### **CONDITIONS**

Operator:	OGRID:	
XTO PERMIAN OPERATING LLC.	373075	
6401 HOLIDAY HILL ROAD	Action Number:	
MIDLAND, TX 79707	403882	
	Action Type:	
	[UF-BHT] Bradenhead Test (BRADENHEAD TEST)	

#### CONDITIONS

Created By	Condition	Condition Date
kfortn	er None	12/3/2024