

U.S. Department of the Interior BUREAU OF LAND MANAGEMENT

Sundry Print Report

Well Name: ANTELOPE RIDGE Well Location: T23S / R34E / SEC 27 / County or Parish/State: LEA /

SWNE / 32.2783061 / -103.4557656

Well Number: 7 Type of Well: CONVENTIONAL GAS Allottee or Tribe Name:

WELL

Lease Number: NMLC071949 Unit or CA Name: Unit or CA Number:

US Well Number: 3002527047 **Operator:** OXY USA INCORPORATED

Notice of Intent

Sundry ID: 2820871

Type of Submission: Notice of Intent

Type of Action: Plug and Abandonment

Date Sundry Submitted: 11/05/2024 Time Sundry Submitted: 11:40

Date proposed operation will begin: 12/05/2024

Procedure Description: OXY PROPOSES TO PA THE SUBJECT WELL. A PREP RIG MIGHT PULL EQUIPMENT BEFORE THE PA JOB STARTS. THE PA PREP RIG PROCEDURE, CURRENT WELLBORE, PROPOSED WELLBORE, AND PA PROCEDURE ARE ATTACHED.

Surface Disturbance

Is any additional surface disturbance proposed?: No

NOI Attachments

Procedure Description

ANTELOPE_RIDGE_07_PA_NOI_SUB_11.5.2024_20241105113926.pdf

Page 1 of 2

eceived by OCD: 1/17/2025 1:33:06 PM
Well Name: ANTELOPE RIDGE

Well Location: T23S / R34E / SEC 27 /

SWNE / 32.2783061 / -103.4557656

County or Parish/State: LEA/ 2 of

Well Number: 7

Type of Well: CONVENTIONAL GAS

Allottee or Tribe Name:

Lease Number: NMLC071949

Unit or CA Name:

Unit or CA Number:

US Well Number: 3002527047

Operator: OXY USA INCORPORATED

Conditions of Approval

Specialist Review

Antelope_Ridge_7___2820871___COA_and_Procedure_20250115103625.pdf

Operator

I certify that the foregoing is true and correct. Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction. Electronic submission of Sundry Notices through this system satisfies regulations requiring a

Operator Electronic Signature: STEPHEN JANACEK Signed on: NOV 05, 2024 11:40 AM

Name: OXY USA INCORPORATED

Title: Regulatory Engineer

Street Address: 5 Greenway Plaza, Suite 110

City: Houston State: TX

Phone: (713) 497-2417

Email address: stephen_janacek@oxy.com

Field

Representative Name:

Street Address:

City: State: Zip:

Phone:

Email address:

BLM Point of Contact

Signature: KEITH IMMATTY

BLM POC Name: KEITH P IMMATTY BLM POC Title: ENGINEER

BLM POC Phone: 5759884722 BLM POC Email Address: KIMMATTY@BLM.GOV

Disposition: Approved **Disposition Date: 01/15/2025**

Form 3160-5 (June 2019)

UNITED STATES DEPARTMENT OF THE INTERIOR

FORM APPROVED
OMB No. 1004-0137
Expires: October 31, 202

BURI	EAU OF LAND MANAGEMEN	Γ	5. Lease Serial No.	
Do not use this f	OTICES AND REPORTS ON Torm for proposals to drill or to USE Form 3160-3 (APD) for su	to re-enter an	6. If Indian, Allottee or Tribe	Name
SUBMIT IN 1	TRIPLICATE - Other instructions on pa	nge 2	7. If Unit of CA/Agreement,	Name and/or No.
1. Type of Well Oil Well Gas W	/ell Other		8. Well Name and No.	
2. Name of Operator			9. API Well No.	
3a. Address	3b. Phone No	o. (include area code)) 10. Field and Pool or Explora	atory Area
4. Location of Well (Footage, Sec., T.,R	.,M., or Survey Description)		11. Country or Parish, State	
12. CHE	CK THE APPROPRIATE BOX(ES) TO I	NDICATE NATURE	OF NOTICE, REPORT OR OT	HER DATA
TYPE OF SUBMISSION		TYP	PE OF ACTION	
Notice of Intent		epen draulic Fracturing	Production (Start/Resume) Reclamation	Water Shut-Off Well Integrity
Subsequent Report	Casing Repair Ne	w Construction	Recomplete	Other
		g and Abandon	Temporarily Abandon	
Final Abandonment Notice	Convert to Injection Plu peration: Clearly state all pertinent details.	g Back	Water Disposal	
is ready for final inspection.) 14. I hereby certify that the foregoing is	true and correct. Name (Printed/Typed)			
14. I hereby certify that the foregoing is	true and correct. Name (Printed/Typea)	Title		
Signature		Date		
	THE SPACE FOR FEI	DERAL OR STA	ATE OFICE USE	
Approved by				
- Approvou of		Title		Date
	ned. Approval of this notice does not warra equitable title to those rights in the subject duct operations thereon.	ant or		
Title 18 U.S.C Section 1001 and Title 43	3 U.S.C Section 1212, make it a crime for	any person knowing	y and willfully to make to any d	epartment or agency of the United States

any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

GENERAL INSTRUCTIONS

This form is designed for submitting proposals to perform certain well operations and reports of such operations when completed as indicated on Federal and Indian lands pursuant to applicable Federal law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local area or regional procedures and practices, are either shown below, will be issued by or may be obtained from the local Federal office.

SPECIFIC INSTRUCTIONS

Item 4 - Locations on Federal or Indian land should be described in accordance with Federal requirements. Consult the local Federal office for specific instructions.

Item 13: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by the local Federal office. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to the top of any tubing left in the hole; method of closing top of well and date well site conditioned for final inspection looking for approval of the abandonment. If the proposal will involve **hydraulic fracturing operations**, you must comply with 43 CFR 3162.3-3, including providing information about the protection of usable water. Operators should provide the best available information about all formations containing water and their depths. This information could include data and interpretation of resistivity logs run on nearby wells. Information may also be obtained from state or tribal regulatory agencies and from local BLM offices.

NOTICES

The privacy Act of 1974 and the regulation in 43 CFR 2.48(d) provide that you be furnished the following information in connection with information required by this application.

AUTHORITY: 30 U.S.C. 181 et seq., 351 et seq., 25 U.S.C. 396; 43 CFR 3160.

PRINCIPAL PURPOSE: The information is used to: (1) Evaluate, when appropriate, approve applications, and report completion of subsequent well operations, on a Federal or Indian lease; and (2) document for administrative use, information for the management, disposal and use of National Resource lands and resources, such as: (a) evaluating the equipment and procedures to be used during a proposed subsequent well operation and reviewing the completed well operations for compliance with the approved plan; (b) requesting and granting approval to perform those actions covered by 43 CFR 3162.3-2, 3162.3-3, and 3162.3-4; (c) reporting the beginning or resumption of production, as required by 43 CFR 3162.4-1(c)and (d) analyzing future applications to drill or modify operations in light of data obtained and methods used.

ROUTINE USES: Information from the record and/or the record will be transferred to appropriate Federal, State, local or foreign agencies, when relevant to civil, criminal or regulatory investigations or prosecutions in connection with congressional inquiries or to consumer reporting agencies to facilitate collection of debts owed the Government.

EFFECT OF NOT PROVIDING THE INFORMATION: Filing of this notice and report and disclosure of the information is mandatory for those subsequent well operations specified in 43 CFR 3162.3-2, 3162.3-3, 3162.3-4.

The Paperwork Reduction Act of 1995 requires us to inform you that:

The BLM collects this information to evaluate proposed and/or completed subsequent well operations on Federal or Indian oil and gas leases.

Response to this request is mandatory.

The BLM would like you to know that you do not have to respond to this or any other Federal agency-sponsored information collection unless it displays a currently valid OMB control number.

BURDEN HOURS STATEMENT: Public reporting burden for this form is estimated to average 8 hours per response, including the time for reviewing instructions, gathering and maintaining data, and completing and reviewing the form. Direct comments regarding the burden estimate or any other aspect of this form to U.S. Department of the Interior, Bureau of Land Management (1004-0137), Bureau Information Collection Clearance Officer (WO-630), 1849 C St., N.W., Mail Stop 401 LS, Washington, D.C. 20240

(Form 3160-5, page 2)

Additional Information

Location of Well

0. SHL: SWNE / 1650 FNL / 1980 FEL / TWSP: 23S / RANGE: 34E / SECTION: 27 / LAT: 32.2783061 / LONG: -103.4557656 (TVD: 0 feet, MD: 0 feet) PPP: SWNE / 1650 FNL / 1980 FEL / TWSP: 23S / RANGE: 34E / SECTION: 27 / LAT: 32.278347 / LONG: -103.455765 (TVD: 0 feet, MD: 0 feet) BHL: SWNE / 1650 FNL / 1980 FEL / TWSP: 23S / RANGE: 34E / SECTION: 27 / LAT: 32.278347 / LONG: -103.455765 (TVD: 0 feet, MD: 0 feet)

PA PREP WORK PROCEDURE

The subject well might be pre-plugged prior to PA rig operations. The plugging rig will come in within 90 days of equipment removal to begin plugging this well.

Prep rig steps

- 1. Notify BLM or OCD prior to rig up.
- 2. MIRU prep rig. Prep equipment to pull pump/rods in the hole (if well has rods).
- 3. LD rods and pump, switchover to pull tbg.
- 4. ND wellhead & NU BOP.
- 5. POOH and LD tbg & BHA.
- 6. RU WL unit. Run and set CIBP.
- 7. If required, run CBL from top of plug to surface and submit to OCD
- 8. RD wireline unit.
- 9. Dump bail cmt as needed on top of CIBP.
- 10. Tag TOC & ensure well control steps followed below prior to rig off.

Well control precautions

- 1. Run official MIT test to ensure pressure holds after CIBP is set.
- 2. Ensure well control prior to rig off by tagging TOC on top of CIBP.
- 3. NU WH flange and ensure all valves are closed when moving prep rig off location, no WS tubing left in hole.

Well Name: ANTELOPE RIDGE 07 API 14: 30-025-27047-0000 PE: Travis Brashear

Date: 10/30/2024

Surface Casing:

Hole Size: 20"

Casing Size: 16" @465'

Casing Weight: 65#

Cement Details: 850 sxs to 0'

Circ @ surf

Intermediate Casing:

Hole Size: 14 3/4"

Casing Size: 10 3/4" @5,060' Casing Weight: 40.5#, 45.5#, & 51#

Cement Details: 1950 sxs to 0'

Circ @ surf

DV Tool 1,138'

Production Casing:

Hole Size: 9 1/2"

Casing Size: 7 5/8" @11,650'

Casing Weight: 33.7#

Cement Details: 800 sxs to XXX'

Circ XXX sxs @ surf

Unknown TOC assuming 8,000'

Liner:

Hole Size: 6 1/2"

Casing Size: 5" @11,435' - 13,574'

Casing Weight: 18#

Cement Details: 285 sxs to 11,435'

Tubing:

Tubing Size: 27/8" Tubing Depth: 11,819'

Packer Depth:

Perforations: 11,879' - 12,027'

CIBP: 12,070' w/30' CMT on Top


Fish: 12,107'

Isolated Perfs: 12,079' - 12,626'

CIBP: 12,900' w/35' CMT on Top

Fish: Packer @ 13,140'

Isolated Perfs: 13,183' - 13,413'



TD:

13,574

Well Name: ANTELOPE RIDGE 07
API 14: 30-025-27047-0000
PE: Travis Brashear
Date: 10/30/2024

Surface Casing:

Hole Size: 20"
Casing Size: 16" @465'
Casing Weight: 65#
Cement Details: 850 sxs to 0'

Circ @ surf

Intermediate Casing:

Hole Size: 14 3/4"
Casing Size: 10 3/4" @5,060'
Casing Weight: 40.5#, 45.5#, & 51#
Cement Details: 1950 sxs to 0'
Circ @ surf

Production Casing:

Hole Size: 9 1/2"
Casing Size: 7 5/8" @11,650'
Casing Weight: 33.7#

DV Tool 1,138'

Cement Details: 800 sxs to XXX'

Circ XXX sxs @ surf

Unknown TOC assuming 8,000'

Liner:

Hole Size: 6 1/2"

Casing Size: 5" @11,435' - 13,574'

Casing Weight: 18#

Cement Details: 285 sxs to 11,435'

Tubing:

Tubing Size: 2 7/8"
Tubing Depth: 11,819'
Packer Depth:

Perforations: 11,879' - 12,027'

CIBP: 12,070' w/30' CMT on Top


Fish: 12,107'

Isolated Perfs: 12,079' - 12,626'

CIBP: 12,900' w/35' CMT on Top

Fish: Packer @ 13,140'

Isolated Perfs: 13,183' - 13,413'



847' Rustler

PERF AND CIRC 436 SXS 1,188' - SURFACE. WOC AND TAG.

5112' Delaware/Lamar

PERF AND SQUEEZE 56 SXS 5,162' - 5,010'. WOC AND TAG.

8630' Bone Spring

SPOT 122 SXS CLASS H CMT 8,680' - 8,162'. WOC AND TAG.

11460' Wolfcamp

SET CIBP @11,829'. SPOT 43 SXS CLASS H CMT 11,829' - 11,410'. WOC AND TAG.

11859' Strawn 12073' Atoka

12892' Morrow

NOTICE OF INTENT TO PLUG AND ABANDON 10/30/2024 ANTELOPE RIDGE 07 30-025-27047-0000

PE: Travis Brashear

PLUGGING PROCEDURE:

- 1. 10# MLF between plugs. Utilize above ground steel tanks.
- 2. POOH with production equipment.
- 3. SET CIBP @11,829'. Pressure Test and Perform Bubble Test.
- 4. RUN CBL 11,829' to Surface.
- 5. SPOT 43 SXS CLASS H CMT 11,829' 11,410'. WOC AND TAG.
- 6. SPOT 122 SXS CLASS H CMT 8,680' 8,162'. WOC AND TAG.
- 7. PERF AND SQUEEZE 56 SXS 5,162' 5,010'. WOC AND TAG.
- 8. PERF AND CIRC 436 SXS 1,188' SURFACE. WOC AND TAG.
- 9. APPROXIMATE TOTAL OF 657 SX OF CEMENT

GEOLOGIC FORMATION INFORMATION:

Summary of Porous Zones Show all important zones tests, including depth inter and recoveries.	of porosity and c	ontents thereof: Co	ored intervals and all drill-stem open, flowing and shut-in pressures	31. Formation (Log) Markers	
Formation	Тор	Bottom	Descriptions, Contents, etc.	Name	Top Meas Depth
				RUSTLER DELAWARE/LAMAR BONE SPRING WOLFCAMP STRAWN ATOKA MORROW	847 5112 8630 11460 11859 12073 12892

PA PREP WORK PROCEDURE

The subject well might be pre-plugged prior to PA rig operations. The plugging rig will come in within 90 days of equipment removal to begin plugging this well.

Prep rig steps

- 1. Notify BLM or OCD prior to rig up.
- 2. MIRU prep rig. Prep equipment to pull pump/rods in the hole (if well has rods).
- 3. LD rods and pump, switchover to pull tbg.
- 4. ND wellhead & NU BOP.
- 5. POOH and LD tbg & BHA.
- 6. RU WL unit. Run and set CIBP.
- 7. If required, run CBL from top of plug to surface and submit to OCD
- 8. RD wireline unit.
- 9. Dump bail cmt as needed on top of CIBP.
- 10. Tag TOC & ensure well control steps followed below prior to rig off.

Well control precautions

- 1. Run official MIT test to ensure pressure holds after CIBP is set.
- 2. Ensure well control prior to rig off by tagging TOC on top of CIBP.
- 3. NU WH flange and ensure all valves are closed when moving prep rig off location, no WS tubing left in hole.

Well Name: ANTELOPE RIDGE 07
API 14: 30-025-27047-0000
PE: Travis Brashear

Date: 10/30/2024

Surface Casing:

Hole Size: 20"

Casing Size: 16" @465'

Casing Weight: 65#

Cement Details: 850 sxs to 0'

Circ @ surf

Intermediate Casing:

Hole Size: 14 3/4"

Casing Size: 10 3/4" @5,060'
Casing Weight: 40.5#, 45.5#, & 51#

Cement Details: 1950 sxs to 0'

Circ @ surf

DV Tool 1,138'

Production Casing:

Hole Size: 9 1/2"

Casing Size: 7 5/8" @11,650'

Casing Weight: 33.7#

Cement Details: 800 sxs to XXX'

Circ XXX sxs @ surf

Unknown TOC assuming 8,000'

Liner:

Hole Size: 6 1/2"

Casing Size: 5" @11,435' - 13,574'

Casing Weight: 18#

Cement Details: 285 sxs to 11,435'

Tubing:

Tubing Size: 2 7/8"

Tubing Depth: 11,819'

Packer Depth:

Perforations: 11,879' - 12,027'

CIBP: 12,070' w/30' CMT on Top


Fish: 12,107'

Isolated Perfs: 12,079' - 12,626'

CIBP: 12,900' w/35' CMT on Top

Fish: Packer @ 13,140'

Isolated Perfs: 13,183' - 13,413'



Well Name: ANTELOPE RIDGE 07 API 14: 30-025-27047-0000 PE: Travis Brashear

Date: 10/30/2024

Surface Casing:

Hole Size: 20" Casing Size: 16" @465' Casing Weight: 65#

Cement Details: 850 sxs to 0'

Circ @ surf

Intermediate Casing:

Hole Size: 14 3/4" Casing Size: 10 3/4" @5,060' Casing Weight: 40.5#, 45.5#, & 51# Cement Details: 1950 sxs to 0' Circ @ surf

DV Tool 1,138'

Production Casing:

Hole Size: 9 1/2" Casing Size: 7 5/8" @11,650'

Casing Weight: 33.7#

Cement Details: 800 sxs to XXX'

Circ XXX sxs @ surf

Unknown TOC assuming 8,000'

Liner:

Hole Size: 6 1/2"

Casing Size: 5" @11,435' - 13,574'

Casing Weight: 18#

Cement Details: 285 sxs to 11,435'

Tubing:

Tubing Size: 27/8" Tubing Depth: 11,819' Packer Depth:

Perforations: 11,879' - 12,027'

CIBP: 12,070' w/30' CMT on Top


Fish: 12,107'

Isolated Perfs: 12,079' - 12,626'

CIBP: 12,900' w/35' CMT on Top

Fish: Packer @ 13,140'

Isolated Perfs: 13,183' - 13,413'



847' Rustler

PERF AND CIRC 436 SXS 1,188' - SURFACE. WOC AND TAG.

5112' Delaware/Lamar

PERF AND SQUEEZE 56 SXS 5,162' - 4960'. WOC AND TAG.

8630' Bone Spring

SPOT 122 SXS CLASS H CMT 8,680' - 8,162'. WOC AND TAG.

11460' Wolfcamp

SET CIBP @11,829'. SPOT 43 SXS CLASS H CMT 11,829' - 11,300'. WOC AND TAG.

11859' Strawn 12073' Atoka

12892' Morrow

NOTICE OF INTENT TO PLUG AND ABANDON 10/30/2024 ANTELOPE RIDGE 07 30-025-27047-0000

PE: Travis Brashear

PLUGGING PROCEDURE:

- 1. 10# MLF between plugs. Utilize above ground steel tanks.
- 2. POOH with production equipment.
- 3. SET CIBP @11,829'. Pressure Test **500PSI, 30MINS** and Perform Bubble Test.
- 4. RUN CBL 11,829' to Surface. Revise procedure as needed. Verify with BLM and OCD
- 5. SPOT 43 SXS CLASS H CMT 11,829' 11,300'. WOC AND TAG.
- 6. SPOT 122 SXS CLASS H CMT 8,680' 8,162'. WOC AND TAG.
- 7. PERF AND SQUEEZE 56 SXS 5,162' 4,960'. WOC AND TAG.
- 8. PERF AND CIRC 436 SXS 1,188' SURFACE. WOC AND TAG.
- 9. APPROXIMATE TOTAL OF 657 SX OF CEMENT

GEOLOGIC FORMATION INFORMATION:

0. Summary of Porous Zones (Include Aquifers):			31. Formation (Log) Markers		
			ored intervals and all drill-stem open, flowing and shut-in pressures		
Formation	Тор	Bottom	Descriptions, Contents, etc.	Name	Top Meas. Depth
				RUSTLER DELAWARE/LAMAR BONE SPRING WOLFCAMP STRAWN ATOKA MORROW	847 5112 8630 11460 11859 12073 12892

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-689-5981.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of water. Minimum nine (9) pounds per gallon.
- 5. Cement Requirement: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours for Class C or accelerated cement (calcium chloride) and 6 hours for Class H. Tagging the plug means running in the hole with a string of tubing or drill pipe and placing sufficient weight on the plug to ensure its integrity. Other methods of tagging the plug may be approved by the BLM authorized officer or BLM field representative.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

Fluid used to mix the cement in R111Q shall be saturated with the salts common to the section penetrated, and in suitable proportions but not less than 1% and not more than 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible.

6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified *BY PHONE* (numbers listed in 2. Notifications) a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds). A weep hole shall be left if a metal plate is welded in place.

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its pre-disturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any/all contaminants, scrap/trash, equipment, pipelines and powerlines (Contact service companies, allowing plenty of time to have the risers and power lines and poles removed prior to reclamation, don't wait till the last day and try to get them to remove infrastructure). Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip (across the slope and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- 1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or

concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos

Supervisory Petroleum Engineering Tech/Environmental Protection Specialist 575-234-5909 (Office), 575-361-2648 (Cell)

Arthur Arias Environmental Protection Specialist 575-234-6230

Crisha Morgan Environmental Protection Specialist 575-234-5987

Jose Martinez-Colon Environmental Protection Specialist 575-234-5951

Mark Mattozzi Environmental Protection Specialist 575-234-5713

Robert Duenas Environmental Protection Specialist 575-234-2229

Doris Lauger Martinez Environmental Protection Specialist 575-234-5926

Jaden Johnston Environmental Protection Asst. (Intern) 575-234-6252

Released to Imaging: 1/29/2025 3:17:43 PM

Sante Fe Main Office Phone: (505) 476-3441

General Information Phone: (505) 629-6116

Online Phone Directory https://www.emnrd.nm.gov/ocd/contact-us

State of New Mexico Energy, Minerals and Natural Resources Oil Conservation Division 1220 S. St Francis Dr. Santa Fe, NM 87505

CONDITIONS

Action 422066

CONDITIONS

Operator:	OGRID:
OXY USA INC	16696
P.O. Box 4294	Action Number:
Houston, TX 772104294	422066
	Action Type:
	[C-103] NOI Plug & Abandon (C-103F)

CONDITIONS

Created By	Condition	Condition Date
gcordero	A Cement Bond Log (CBL) is required to be submitted to electronic permitting.	1/29/2025
gcordero	Submit Cement Bond Logs (CBL) prior to submittal of C-103P.	1/29/2025
gcordero	Adhere to current Plug & Abandon (P&A) Conditions Of Approvals (COA).	1/29/2025