

NEW MEXICO ENERGY, MINERALS and NATURAL RESOURCES DEPARTMENT

BILL RICHARDSON Governor Joanna Prukop Cabinet Secretary Lori Wrotenbery Director Oil Conservation Division

February 2, 2004

OXY USA WTP Limited Partnership P.O. Box 50520 Midland, TX 79710-0250 Attn: David Stewart or To Whom It May Concern

RE: OXY Redemption #1, located 660' FSL & 660' FWL in Unit M of Section 15, Township 22 South-Range 27 East, Eddy County, New Mexico

Dear Mr. Stewart,

Per your request on Friday, January 30th, 2004, I am returning the above application as denied for the above captioned application to drill (APD).

The New Mexico Oil Conservation Division (NMOCD) office in Artesia has determined that Tom Brown, Inc. has submitted an APD at the same location prior to your submittal on January 26, 2004. Respectfully yours

Bryan G. Arrant

PES

BEFORE THE OIL CONSERVATION DIVISION Santa Fe, New Mexico Case No. 13226 Exhibit No. 16 Submitted by: <u>OXY USA WTP LTD. PARTNERSHIP</u> Hearing Date: <u>March 4, 2004</u>

District 1	State of District I Energy Mineral							New Mexico Forr & Natural Resources Revised Mar				
1625 N. French D	r., Hobbs, Ni	M 88240		200163,				3041003	DEST	r	evised March 17, 19	
811 S. 1st Street, Artesia, NM 88210				Oil Conservation Division			RECEIVE	Dit to approp	priate District Offic			
1000 Rio Brazos Rd., Aztec, NM 87410			-	2040 Sou	th Pach	neco		JAN 9 6 2004 State Lease - 6 Cop				
District IV 2040 South Probago, Santa Fr. NM 87505					Santa Fe,	NM 87	7505	((CIA	ree Lease - 5 Copie	
								,			ENDED REPOR	
	A DRI LOATION FOR REPAIR TO DRILL BE							זאי ז מיז	DITCOAC		D A ZONE	
APPLIC	APPLICATION FOR PERMIT TO DRILL, RE-J							uricin,	² OGRID Number			
OXY USA WTP	Limited	Partner	ship	67 (B1(65)					192463			
P.O. Box 50	250 Mic	iland, T	(79710-	0250					30- 015-	3 + DL Number	7	
⁴ Proper	ny Code				⁵ Property	Name		·			ell No.	
					UXY Redem	ption					1	
·	T			T	Surface	Locatio	<u>n</u>	T		T	r	
UL or lot no.	Section	Township	Range	Lot. Ida	Feet from	the 1	North/Sou	uth Line	Feet from the	East/West line	County	
<u>M</u>	15	225	27E	L	660		SOL	ith	660	west	Eddy	
·		·	Proposed	Bottom F	Iole Locat	ion If D	iffere	nt From	n Surface			
UL or lot no.	Section	Township	Range	Lot. Ida	Feet from	the I	North/Sou	ath Line	Feet from the	East/West line	County	
}	L	⁹ Proposed		L		T		l	¹⁰ Proposed Pr	nol 2	L	
Undociona	tad Carl	shad Mor	row South	. 7	3960	1			Topusca T			
Undes rgind	ILEU CALI	SDau noi	IUN, JULI	·	5500	I			<u></u>			
¹¹ Work T	ype Code		12 Well Type C	ode	13 Cabie	Rotary	Rotary ¹⁴ Lease Type Code ¹⁵ Ground Level Elevation				Level Elevation	
L	<u>N</u>		G			R		P		20.0		
³⁶ Mul	uple No		" Proposed Dep 12400	epth '' Form		nation `FOW	Nion 17 NW		Contractor N/A	20 5	pud Date /29/114	
L	<u> </u>		21	Proposed	Casing an	id Cement Program						
Hole Si	72	Ca	ing Size	Casing	weight/foot	Sett	ing Den	th	Sacks of Cemer	ut F	stimated TOC	
17-1/	2"	12	-3/8"		9#				400ex			
17-1/	<u> </u>		-5/8*		16#		500.		1200cv	Surra		
12-1/	4 		1/2"		7#		2400 -		1400ev	Surra		
8-3/4) 		1/2	d	./#		2400		1400SX	EST	100.000	
		+				<u> </u>						
22		1		L		<u> </u>						
²² Describe the p	roposed prog	gram. If this	application is	to DEEPEN	or PLUG BAC	K, give th	e data o	in the presi	ent productive zon	e and proposed i	new productive zone.	
Describe the blow	out preventio	on program,	ii any. Use add	nobal sneets	II necessary.							
											1	
					500 0+	hor Cid	_				-	
					Jee UL		C					
					•	ï						
Opera	Operator to set surface cosime Above Calada @ 400'											
²³ 1 hereby certify	y that the inf	ormation gi	ven above is tr	ue and com	plete to the	A/A			NICEDUATE			
best of my knowl	ledge and be	lief.	,		4	K.			INSERVAII	UN DIVISI		
Signature:	Signature:					Approved	d by:					
Printed name: Da	Printed name: David Stewart					Title:				1840		
Title: Sr	Title Sr. Regulatory Analyst						Date			nization De		
Date:			Phone:			Condition	- Saic a	DIOVAL	EX.			
1/23	104		432	-685-571	7	Attached		Г	high			

ņ

OXY Redemption #1 660 FSL 660 FWL SWSW(M) SEC 15 T22S R27E Eddy County, NM

.

•

I

proposed ti	12400' 7	TVD
BOP PROGRAM	l: 0-625'	None
	625 - 4500′	13-3/8" 3M annular preventer, to be used as divertor only.
	4500-12400 <i>°</i>	11" 5M blind pipe rams with 5M annular preventer and rotating head below 8500'.
CASING:	Surface:	13-3/8" OD 48# H40 ST&C new casing set at 0-625' 17-1/2" hole
	Intermediate:	9-5/8" OD 36# HCK55/K55 ST&C new casing at 0-4500' 12-1/4" hole
	Production:	5-1/2" OD 17# N80-HP110 LT&C new casing at 0-12400' 8-3/4" hole N80-8800' HP110-3500'
CEMENT :	Surface - Circ + 2% CaCl ₂ + .2	ulate cement with 200sx 35:65 POZ/C with 6% Bentonite $5\#/sx$ Cello-Seal followed by 200sx Cl C with 2% CaCl ₂ .
	Intermediate - Bentonite + 2% with 2% CaCl ₂ .	Circulate cement with 1000sx 35:65 POZ/C with 6% CaCl ₂ + $.25$ #/sx Cello-Seal followed by 200sx Cl C
	Production - C + .5% FL-25 + FL-25. Estima	ement with 1200sx 15:61:11 POZ/C/CSE with .5% FL-52 8#/sx Gilsonite followed by 200sx Cl C with .7% ted top of cement is 6000'.
	Note: Cement	volumes may need to be adjusted to hole caliper.
MUD:	0-625′	Fresh water/native mud. Lime for pH control (9-10). Paper for seepage. Wt 8.7-9.2 ppg, Vis 32-34 sec
	625-4500 <i>'</i>	Fresh/*Brine water. Lime for pH control (10.0-10.5). Paper for seepage. Wt 8.3-9.0/10.0-10.1ppg, Vis 28-29 sec *Fresh water will be used unless chlorides in the mud system increases to 20000PPM.
	4500-8300'	Fresh water. Lime for pH control(9-9.5). Paper for seepage. Wt 8.3-8.5 ppg, Vis 28-29 sec
	8300-10000'	Cut brine. Lime for pH control (10-10.5). Wt 9.6-10.0 ppg, Vis 28-29sec
÷	10000-12300'	Mud up with an Duo Vis/Flo Trol mud system. Wt 9.6-10.0ppg, Vis 32-36sec, WL<10cc
	in the second	
an a sa Sina Sina a sa	ing Marine and Angela	

•

					State	of Ne	w Mexico				
DISTRICT I	NM 88241-1	960		Energ	y, Minerala a	nd Natural	Besources Department		1	Form C-10	
DISTRICT II P.O. Drawer DD, Artenia, NM 88211-0719				OIL CONSERVATION DIVISION P.O. Box 2088 Santa Fe, New Mexico 87504-2088						uary 10, 199 District Offic se – 4 Copie se – 3 Copie	
1000 Rio Brazos R	ld., Aztec, N	M 87410			•						
DISTRICT IV P.O. BOX 2000, SANTA	A FE, N.M. 87	504-2088	WELL LO	CATIO	N AND	ACRE	AGE DEDICATI	ON PLAT	AMEND	ED REPOR	
API	Number			Pool Code				Pool Name			
30-01	15-			73960	D	1	Undesignated	Carlsbad Mo	orrow, South	<u>n</u>	
Property C	lode				OXY R	EDEMP	TION		Well Nur	nber	
OGRID No).		····.		 Oper	rator Nam			Elevatio		
192463	3			OX	(Y U.S.	A. W.I	.P., LP		3107'		
·		L		• • <u>•</u> •••••••••••••••••••••••••••••••••	Surfa	ce Loca	ation	·····			
UL or lot No.	Section	Township	Range	Lot Idn	Feet fr	om the	North/South line	Feet from the	East/West line	County	
M	15	22-S	27-E		6	60	SOUTH	660	WEST	EDDY	
			Bottom	Hole L	ocation	If Diffe	erent From Sur	face			
UL or lot No.	Section	Township	Range	Lot idn	Feet fr	om the	North/South line	Feet from the	East/West line	County	
Dedicated Acres	Loint or	r Infill Co	nsolidation (Code (Order No.		l		l	l	
320	N										
		TTT BE A	SSIGNED	1 0 THIS	COMPLE	TION D		PESTS HAVE BE	TEN CONSOLID		
		OR A N	NON-STAN	DARD U	NIT HAS	BEEN	APPROVED BY	THE DIVISION			
							···	OPERATO	R CERTIFICAT	NOL	
						1		/ hereb	a certify the the in	lormation	
						1		contained hereis	n is true and comple	te to the	
	I							best of my know	pledge and belief.	·	
						1		$ $ \land	11		
	1	·						I dai	Here -		
L					<u> </u>			Signature David S	tewart		
	Ģ	EODETIC C	OORDINATE	Ş				Printed Name	e e e e e e e e e e e e e e e e e e e	[]	
	l l	NAD 27	7 NME					Sr. Reg	ulatory Ana	lyst	
	לו	x = 5045	95.5 N 80.9 E					Title	1		
	L	AT. 32'23'	13.77"N			1			3104		
	L.	ONG. 104	11 00.25								
ļ	-			ļ				SURVEYO	R CERTIFICAT	ION	
								I hereby certify on this plat wa actual surveys supervison, and correct to the	that the well locati is plotted from field made by me or d that the same is a best of my belief	on shown notes of under my true and	
	 	<u></u>				 		Jonu Date Surveye Signature & 3 Professional	ary 13, 2004 Seal of Surveyor	AWB	
								Bang B	Eulpon 1/10 4.11.0036	12641	
- 66											







VICINITY MAP



SCALE: 1'' = 2 MILES

SEC. <u>15</u> TWP. <u>22–S</u> RGE. <u>27–E</u>
SURVEY N.M.P.M.
COUNTY EDDY
DESCRIPTION 660' FSL & 660' FWL
ELEVATION 3107'
OPERATOR OXY U.S.A. W.T.P., LP

JOHN WEST SURVEYING HOBBS, NEW MEXICO (505) 393-3117

LOCATION VERIFICATION MAP



OXY USA WTP Limited Partnership PO Box 50250 Midland, TX 79710

Hydrogen Sulfide (H₂S) Contingency Plan

For

OXY Redemption No. 1 660 ft FSL, 660 ft FWL Sec 15, T22S, R27E Eddy County, NM

And

McVay Drilling Co., Rig No. 8

TABLE OF CONTENTS

ITEM	<u>PAGE</u>
PREFACE	3
LOCATION MAP	4
RIG SKETCH	. 5
EMERGENCY RESPONSE ACTIVATION AND GENERAL RESPONSIBILITIES	6
SPECIFIC EMERGENCY GUIDANCE - H2S Release - Well Control	8 10
PUBLIC RELATIONS	13
PHONE CONTACTS - OP DOWNHOLE SERVICES GROUP	14
EMERGENCY PERSONELL NOTIFICATION NUMBERS	13
PHONE CONTACTS - OP PRODUCTION AND PLANT PERSONNEL	15
PHONE CONTACTS - OP HES PERSONNEL	16

۱

ź

PREFACE

An effective and viable Contingency Plan is intended to provide prior planning and guidance in responding to emergency incidents. The primary considerations in its development are protection of personnel, the public, company and public property, and the environment.

Although the plan addresses varied emergency situations which may occur, it recognizes that flexibility and the use of the organization's knowledge and experience is critical to safe resolution of emergency incidents. Response actions outlined in the plan provide a framework, which may be placed into operation without confusion. These actions should promote quick and decisive actions during the critical initial period and immediately following an emergency. As the response progresses, additional guidelines and procedures may need to be implemented as the situation dictates. In addition, all emergency incidents must be properly reported per the Oxy Incident Reporting and Notification Policy, state and federal requirements, etc.

This Contingency Plan is intended for use on Oxy Downhole Services Group projects and the operations within their area of responsibility, such as drilling, critical well work, etc.

į

Oxy Redemption. No. 1 Y = 504595.5 N X = 546280.9 E Lat. 32° 23' 13.77" N Long. 104° 11' 00.25" W





From the intersection of County Road No. 700 (Calvani Rd.) and U.S. HWY 285 Go east on County Rd. 700 for 1.7 miles to ranch road. Turn left and go 0.1 miles north to this location

;

Page 4 of 16



McVay Rig 8

EMERGENCY RESPONSE ACTIVATION AND GENERAL RESPONSIBILITIES

Activation of the Emergency Action Plan

- A. In the event of any emergency situation, all personnel on location should first ensure that the following items are initiated. After that, they should refer to the appropriate Specific Emergency Guidance sections on pages five (5) through nine (10) in this document for further responsibilities:
 - 1. Notify the senior ranking contract representative on site.
 - 2. Notify Oxy representative in charge.
 - 3. Notify civil authorities if the Oxy Representative can not be contacted and the situation dictates.
 - 4. Perform rescue and first aid as required (without jeopardizing additional personnel).

General Responsibilities

Ĵ

Oxy Permian Personnel:

- A. Operations Specialist: The Oxy Drilling/Critical Well Servicing Operations Specialist or contract personnel serving in that capacity will serve as Operations Chief Officer for all emergency incidents. The Operations Chief Officer is responsible for:
 - 1. Notification to the Downhole Services Team Leader of the incident occurrence.
 - 2. Notification to the local RMT/PMT leader of the incident occurrence, and the need for the designated local RMT/PMT Incident Commander to act in that capacity for the response effort.
 - 3. Sole control of all tactical activities directed toward reducing the immediate hazard, establishing situational control and restoring the operations to a non-emergency state.
- B. Local RMT/PMT Designated Incident Commander: The Oxy local RMT/PMT Designated Incident Commander will serve as the overall Incident Commander for the drilling or critical well servicing emergency incident. The Incident Commander is responsible for:
 - 1. Coordinating with the Downhole Services Team Leader for notification to the Oxy Crisis Management team of the incident occurrence.
 - 2. Establishing and managing the overall incident command structure and response from inception through restoration of normal activities in the area.
- C. Downhole Services HES Tech: The Downhole Services HES Tech (or his designate) is responsible for reporting to the incident as soon as reasonably possible, to provide support to the response effort as required by the Operations Chief Officer or the Incident Commander.

Contract Drilling Personnel will immediately report to their assigned stations and perform their duties as outlined in the appropriate Specific Emergency Guidance sections on pages five (5) through nine (9) in this document.

Other Contractor Personnel will report to the safe briefing area to assist Oxy personnel and civil authorities as requested when it is safe to do so and if they have been adequately trained in their assigned duties. Civil Authorities (Law Enforcement, Fire, and EMS) will be responsible for:

- 1. Establishing membership in the Unified Incident Command.
- 2. As directed by the Incident Commander and the Unified Command, control site access, re-route traffic, and provide escort services for response personnel.
- 3. Perform all fire control activities in coordination with the Unified Command.
- 4. Initiate public evacuation plans as instructed by the Incident Commander.
- 5. Perform rescue or recovery activities with coordination from the Unified Command.
- 6. Provide medical assistance as dictated by the situation at hand.

H2S RELEASE

÷

The following procedures and responsibilities will be implemented on activation of the H2S siren and lights.

All Personnel:

1. On alarm, don escape unit (if available) and report to upwind briefing area.

Rig Manager/Tool Pusher:

- 1. Check that all personnel are accounted for and their condition.
- 2. Administer or arrange for first aid treatment, and /or call EMTs as needed.
- 3. Identify two people best suited to secure well and perform rescue, and instruct them to don SCBA.
- 4. Notify Contractor management and Oxy Representative.
- 5. Remain at the briefing area, assess and monitor personnel and overall situation for hazards or conditions that might warrant a change in the action plan.

Two People Responsible For Shut-in and Rescue:

- 1. Don SCBA and acquire tools to secure well and perform rescue, i.e., wrenches, retrieval ropes, etc.
- 2. Utilize the buddy system to secure well and perform rescue(s).
- 3. Return to the briefing area and stand by for further instructions.

All Other Personnel:

 Isolate the area and prevent entry by other persons into the 100 ppm ROE. Additionally the first responder(s) must evacuate any public places encompassed by the 100 ppm ROE. First responder(s) must take care not to injure themselves during this operation. Company and/or local officials must be contacted to aid in this operation. Evacuation of the public should be beyond the 100 ppm ROE.

Oxy Representative:

- 1. Remain at the briefing area, assess and monitor personnel and overall situation for hazards or conditions that might warrant a change in the action plan.
- 2. Notify Operation Specialists or Team Leader and RMT Leader or Local Incident Commander, and Police, Fire Department, or other local emergency services as required.

Training

ŝ

All responders must have training in the detection of H2Sm measures for protection against the gas, equipment used for protection and emergency response. Weekly drills by all crews will be conducted and recorded in the IADC daily log. Additionally, responders must be equipped with H2S monitors at all times

Ignition of Gas Source

Should control of the well be considered lost and ignition considered, take care to protect against exposure to Sulfur Dioxide (SO2). Intentional ignition must be coordinated with the NMOCD and local officials. Additionally the NM State Police shall be the Incident Command of any major release.

Common Name	Chemical Fromula	Specific Gravity	Threshold Limit	Hazardous Limit	Lethal Concentration
Hydrogen Sulfide	H ₂ S	1.189 Air = 1	10 ppm	100 ppm	600 ppm
Sulfur Dioxide	SO2	2.21 Air = 1	2 ppm	N/A	1000 ppm

Characteristics of H2S and SO2

Contacting Authorities

÷

Oxy Permian personnel must liaison with local and state agencies to ensure a proper response to a major release. Additionally, the OCD must be notified of the release as soon as possible but no later than 4 hours. Agencies will ask for information such type and volume of release, wind direction, location of release, etc. Be prepared with all information available. The following call list of essential and potential responders has been prepared for use during a release. This response plan must be in coordination with the State of New Mexico's 'Hazardous Materials Emergency Response Plan' (HMER).

WELL CONTROL

The following procedures will be implemented when a loss of primary control is indicated. Indicators of loss of primary control are flow from the well, an increase in pit volume, or when the drilling fluid used to fill the hole on trips is less than the calculated pipe displacement volume. The emergency signal for well control procedures will be a single long blast of the rig air horn.

Kick While Drilling - Procedures And Responsibilities

Driller:

- 1. Stop the rotary and hoist the kelly above the rotary table.
- 2. Stop the mud pump(s).
- 3. Check for flow.
- 4. If flowing, sound the alarm immediately.
- 5. Ensure that all crew members fill their responsibilities to secure the well.
- 6. Record drill pipe and casing shut-in pressures and pit volume increase and begin kill sheet.

Derrickman:

- 1. Go to BOP/choke manifold area.
- 2. Open choke line valve on BOP.
- 3. Signal to Floorman #1 that the choke line is open.
- 4. Close chokes after annular or pipe rams are closed.
- 5. Record shut-in casing pressure and pit volume increase.
- 6. Report readings and observations to Driller.
- 7. Verify actual mud weight in suction pit and report to Driller.
- 8. Be readily available as required for additional tasks.

Floorman # 1:

- 1. Go to accumulator control station and await signal from Derrickman.
- 2. Close annular preventer and HCR on signal (if available, if not then close pipe rams).
- 3. Record accumulator pressures and check for leaks in the BOP or accumulator system.
- 4. Report to Driller, and be readily available as required for additional tasks.

Floorman # 2:

- 1. Start water on motor exhausts.
- 2. Notify Contractor Tool Pusher or Rig Manager of well control situation.
- 3. Check location for ignition sources and extinguish or turn off, and stop any welding in progress.
- 4. Report to Driller, and be readily available as required for additional tasks.

Floorman # 3:

1. Stand-by with Driller, and be readily available as required for additional tasks.

Tool Pusher/Rig Manager:

- 1. Notify Oxy Representative and report to rig floor.
- 2. Review and verify all pertinent information.
- 3. Communicate information to Oxy Representative, and confer on an action plan.
- 4. Finalize well control worksheets, calculations and preparatory work for action plan.
- 5. Initiate and ensure the action plan is carried out.
- 6. Communicate any changes in well or site conditions, or any indications that the action plan needs to be revised to the Oxy representative.

Oxy Representative:

1. Notify Operation Specialists or Team Leader and RMT Leader or Local Incident Commander, and Police, Fire Department, or other local emergency services as required.

Kick While Tripping - Procedures and Responsibilities

Driller:

- 1. Sound the alarm immediately when pipe displacement volume is less than 75% of calculated.
- 2. Position the upper tool joint just above rotary table and set slips.
- 3. Check for flow.
- 4. Ensure that all crew members fill their responsibilities to secure the well.
- 5. Record drill pipe and casing shut-in pressures and pit volume increase, and begin kill sheets.

Derrickman: (same as while drilling)

Floor Man # 1:

;

- 1. Install full opening valve (with help from Floorman #2) in top drill string connection.
- 2. Tighten valve with make up tongs.
- 3. Go to accumulator control station and await signal from Derrickman.
- 4. Close annular preventer and HCR valve on signal (if available, if not then close pipe rams).
- 5. Record accumulator pressures and check for leaks in the BOP and accumulator system.
- 6. Report to Driller, and be readily available as required for additional tasks.

Floor Man # 2:

÷

- 1. Assist installing full opening valve in drill string.
- 2. Position back-up tongs for valve make-up.
- 3. Start water on motor exhausts.
- 4. Notify Contractor Tool Pusher or Rig Manager of well control situation.
- 5. Check location for ignition sources and extinguish or turn off, and stop any welding in progress.
- 6. Report to Driller, and be readily available as required for additional tasks.

Floorman # 3, Rig Manager/Tool Pusher, and Oxy Representative: (same as while drilling)

PUBLIC RELATIONS

Oxy recognizes that the news media have a legitimate interest in incidents at Oxy facilities that could affect the public. It is to the company's benefit to cooperate with the news media when incidents occur because these media are our best liaison with the public.

Our objective is to see that all reports of any emergency are factual and represent the company's position fairly and accurately. Cooperation with news media representatives is the most reliable guarantee that this objective will be met.

All contract and Oxy employees are instructed <u>NOT</u> to make any statement to the media concerning the emergency incident. If a media representative contacts any employee, they should refer them to the designated Emergency Command Center where they should contact the Incident Commander or his designated relief for any information concerning the incident.

OXY PERMIAN DOWNHOLE SERVICES GROUP

۰.

	LOCATION	OFFICE	HOME	CELL	PAGER
Manager Operations	Support				
Hardesty, Steve	Midland	432-685-5880	432/694-6441	713-560-8095	
Team Leader				••• ••••••••••••••••••••••••••••••••••	
Pennington, Randy	Midland	432-685-5684	432/689-7642	432-556-0207	713-312-818
			Toledo Bend =	318-590-2349	
Operations Specialis	ts				
Fleming, Joe	Midland	432-685-5858	432/699-0875	432-425-6075	432-498-328
Ray, Fred	Midland	432-685-5683	432/362-2857	432-661-3893	432-499-3432
HES Tech			·		
Thompson, Don	Midland	432-685-5719	432/684-3900	432-556-1505	

OXY Permian Production and Plant Personnel OXY Permian Crisis Team Hotline Notification (713) 935-7210

:

:

;

			1	1	r
PERSON	LOCATION	OFFICE	FAX	CELL	PAGER
Asset Management-Operations Area	<u> </u>				
OXY Permian General Manager:	Houston	(281)	(281)	(713)	<u> </u>
Tom Menges		552-1147	552-1484	560-8038	l
South Permian Asset:	Midland	(432)	(432)	(432)	
Matt Hyde		685-5802	685-5930	556-5016	
RMT/PMT Leaders: South Permian As	iset				
Frontier RMT:	Midland	(432)	(432)	(432)	(432)
Tommy Johnson		685-5671	685-4054	238-9343	567-7038
PERSON	LOCATION	OFFICE	FAX	CELL	PAGER
Production Coordinators: S. Permian	Asset				
New Mexico: John Erickson	Hobbs	(505)	(505)	(505)	(505)
		393-2174	397-2671	390-6426	370-6836
OXY Permian	OXY Permian HES Pers Crisis Team Hotiine Notifi	ication (713) 9	35-7210		
	I I I I I I I I I I I I I I I I I I I				

PERSON	LOCATION	OFFICE	FAX	CELL	PAGER
HES Coordinators & Area of Resp	onsibility				•
Frontier:	Midland	(432)	(432)	(432)	(432)
Tom Scott ·		685-5677	685-5742	448-1121	498-1312
HES Techs & Area of Responsibil	ity				
Hobbs RMT:	Hobbs	(505)	(505)	(505)	(877)
Steve Bishop		397-8251	397-8204	390-4784	339-1954-
					1118#
Frontier-New Mexico:	Hobbs	(505)	(505)	(505)	(505)
Rick Kerby		393-2174	393-2671	390-8639	370-6527