George QJ #10 -- Drainage Area

1. Original Oil in Place (stock-tank barrels) is given by the equation

OOIP = 7758*A*h* phi*So/Boi

where h*phi*So is the hydrocarbon pore volume.

- 2. The log calculations for hydrocarbon pore volume yield h*phi*So = 0.795.
- **3.** Boi = 1.28 from the Standing Correlations where the parameters are as follows:

æ	600
=	110 degrees F
=	0.7
-	42 degrees API
	# H H

4. Ultimate Primary Recovery (Np) = Recovery Factor*OOIP
where Recovery Factor (Rf) = 0.25

from 1957 paper entitled

"Estimation of Ultimate Recovery from Solution Gas-Drive Reservoirs" by Wahl, Mullins and Elfrink of Magnolia Petroleum.

5. Then, Np = $Rf^*7758^*A^*h^*phi^*So/Boi$

and, by rearranging, A = Np*Boi/(Rf*7758*h*phi*So) in acres A = 232517*1.32/(0.25*7758*0.795) in acres A = 199 acres is the Drainage Area

> Yates Petroleum Corporation Case 12751 Exhibit **12**