


.

3 Can 4283




PROPOSED PROCEDURE

Pull rods and pump. Tag bottom with tubing and tally out. Clean outcany fill found above 4574' to 4580' (electronically inspect tubing on rack)
Run 2 3/8" OD EUE cement-lined tubing with ret. packer to be set at ± 4510'.

3. Hook up well for injection.

Care 7283 Exhibit NO. 4



PROPOSED PROCEDURE

 Pull rods and pump. Tag bottom with tubing and tally out. (Electronically inspect tubing on rack) Clean out any fill found above 4590' to 4600'.

2. Run 2 3/8" OD EUE cement-lined tubing with ret. packer to be set at + 4540'

3. Hook-up well for injection.

Crise 4.283 Exhibit No. 5

11-19-69