

ATS-12-880

Form 3160-3  
(April 2004)

FORM APPROVED  
OMB No. 1004-0137  
Expires March 31, 2007

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT


APPLICATION FOR PERMIT TO DRILL OR REENTER

1a. Type of work: <input checked="" type="checkbox"/> DRILL <input type="checkbox"/> REENTER		7. If Unit or CA Agreement, Name and No.
1b. Type of Well: <input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other <input checked="" type="checkbox"/> Single Zone <input type="checkbox"/> Multiple Zone		8. Lease Name and Well No. Cedar Canyon 23 #1H C394397
2. Name of Operator OXY USA Inc.		9. API Well No. 30-015 40667
3a. Address P.O. Box 50250 Midland, TX 79710	3b. Phone No. (include area code) 432-685-5717	10. Field and Pool, or Exploratory Corral Draw Bone Spring 962387
4. Location of Well (Report location clearly and in accordance with any State requirements.) At surface 2068 FNL 483 FWL SWNW(E) Sec 23 T24S R29E At proposed prod. zone 1980 FNL 660 FEL SENE(H) Sec 23 T24S R29E		11. Sec., T. R. M. or Blk. and Survey or Area Sec 23 T24S R29E
14. Distance in miles and direction from nearest town or post office* 6 miles northwest from Loving, NM		12. County or Parish Eddy
15. Distance from proposed* location to nearest property or lease line, ft. (Also to nearest drig. unit line, if any) 890'		13. State NM
16. No. of acres in lease 560ac 1040ac		17. Spacing Unit dedicated to this well 160ac
18. Distance from proposed location* to nearest well, drilling, completed, applied for, on this lease, ft. 213'		20. BLM/BIA Bond No. on file ESB000326
21. Elevations (Show whether DF, KDB, RT, GL, etc.) 2953' GL		22. Approximate date work will start* 09/01/2012
		23. Estimated duration 30 days

24. Attachments

The following, completed in accordance with the requirements of Onshore Oil and Gas Order No.1, shall be attached to this form:

- |                                                                                                                                                 |                                                                                                    |
|-------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| 1. Well plat certified by a registered surveyor.                                                                                                | 4. Bond to cover the operations unless covered by an existing bond on file (see Item 20 above).    |
| 2. A Drilling Plan.                                                                                                                             | 5. Operator certification                                                                          |
| 3. A Surface Use Plan (if the location is on National Forest System Lands, the SUPO shall be filed with the appropriate Forest Service Office). | 6. Such other site specific information and/or plans as may be required by the authorized officer. |

25. Signature 	Name (Printed/Typed) David Stewart	Date 6/19/12
Title Regulatory Advisor		david_stewart@oxy.com
Approved by (Signature) /s/ Don Peterson	Name (Printed/Typed) /s/ Don Peterson	Date SEP - 6 2012
Title FIELD MANAGER		Office CARLSBAD FIELD OFFICE

Application approval does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.  
Conditions of approval, if any, are attached.

APPROVAL FOR TWO YEARS

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*(Instructions on page 2)


Carlsbad Controlled Water Basin

SEE ATTACHED FOR  
CONDITIONS OF APPROVAL

Approval Subject to General Requirements  
& Special Stipulations Attached

### OPERATOR CERTIFICATION

I hereby certify that I, or someone under my direct supervision, have inspected the drill site and access route proposed herein; that I am familiar with the conditions that presently exist; that I have full knowledge of State and Federal laws applicable to this operation; that the statements made in this APD package are, to the best of my knowledge, true and correct; and that the work associated with the operations proposed herein will be performed in conformity with this APD package and the terms and conditions under which it is approved. I also certify that I, or the company I represent, am responsible for the operations conducted under this application. These statements are subject to the provisions of 18 U.S.C. 1001 for the filing of false statements. Executed this \_\_\_\_ day of \_\_\_\_\_, 2012.



Name: \_\_\_\_\_ Peter Lawrence \_\_\_\_\_  
Position: \_\_\_\_\_ Reservoir Management Team Leader \_\_\_\_\_  
Address: \_\_\_\_\_ 5 Greenway Plaza, Suite 110, Houston, TX 77046 \_\_\_\_\_  
Telephone: \_\_\_\_\_ 713-215-7644 \_\_\_\_\_  
E-mail: (optional): \_\_\_\_\_ peter\_lawrence@oxy.com \_\_\_\_\_  
Company: \_\_\_\_\_ OXY USA Inc. \_\_\_\_\_  
Field Representative (if not above signatory): \_\_\_\_\_ Dusty Weaver \_\_\_\_\_  
Address (If different from above): \_\_\_\_\_ P.O. Box 50250 Midland, TX 79710 \_\_\_\_\_  
Telephone (if different from above): \_\_\_\_\_ 432-685-5723 \_\_\_\_\_  
E-mail (if different from above): \_\_\_\_\_ calvin\_weaver@oxy.com \_\_\_\_\_

DISTRICT I  
1625 N. French Dr., Hobbs, NM 88240  
Phone: (575) 393-6161 Fax: (575) 393-0720

DISTRICT II  
811 S. First St., Artesia, NM 88210  
Phone: (575) 748-1283 Fax: (575) 748-9720

DISTRICT III  
1000 Rio Brazos Road, Aztec, NM 87410  
Phone: (505) 334-6178 Fax: (505) 334-6170

DISTRICT IV  
1220 S. St. Francis Dr., Santa Fe, NM 87505  
Phone: (505) 476-3460 Fax: (505) 476-3462

State of New Mexico  
Energy, Minerals & Natural Resources Department

OIL CONSERVATION DIVISION

1220 South St.  
Santa Fe, New M

Form C-102  
Revised August 1, 2011  
mit one copy to appropriate  
District Office

OPERATOR: Please do not report  
production under this pool id code  
until OCD confirms perms and  
appropriate pool designation on  
completion and C104 approvals.

AMENDED REPORT

WELL LOCATION AND ACRE

API Number 30-015-40667	Pool Code 96238	Pool Name Connel Draw Bone Spring
Property Code 39439	Property Name CEDAR CANYON 23	Well Number 1H
OGRID No. 16696	Operator Name OXY U.S.A. INC	Elevation 2953'

Surface Location

UL or lot No.	Section	Township	Range	Lot Idn	Feet from the	North/South line	Feet from the	East/West line	County
E	23	24-S	29-E		2068	NORTH	483	WEST	EDDY

Bottom Hole Location If Different From Surface

UL or lot No.	Section	Township	Range	Lot Idn	Feet from the	North/South line	Feet from the	East/West line	County
H	23	24-S	29-E		1980	NORTH	660	EAST	EDDY

Dedicated Acres	Joint or Infill	Consolidation Code	Order No.
160	N		9/6 11742

NO ALLOWABLE WILL BE ASSIGNED TO THIS COMPLETION UNTIL ALL INTERESTS HAVE BEEN CONSOLIDATED OR A NON-STANDARD UNIT HAS BEEN APPROVED BY THE DIVISION

<p><b>DETAIL</b> 2945.1' 2953.4' 600' 2956.2' 2970.4'</p> <p>2068' 1980'</p> <p>483' S.L. SEE DETAIL</p> <p>GRID. AZ.=88°23'23" HORIZ. DIST.=4153.6'</p> <p>B.H. 660'</p> <p><b>Project Area</b> <b>Producing Area</b></p> <p><b>GEODETC COORDINATES</b> NAD 27 NME</p> <p><b>SURFACE LOCATION</b> Y=438289.7 N X=614946.8 E LAT.=32.204429° N LONG.=103.961705° W</p> <p><b>BOTTOM HOLE LOCATION</b> Y=438406.4 N X=619097.8 E LAT.=32.204710° N LONG.=103.948284° W</p> <p><b>CORNER COORDINATES TABLE</b></p> <table border="1"> <tr> <td>Ⓐ</td> <td>Y=439026.8 N, X=614462.0 E</td> </tr> <tr> <td>Ⓑ</td> <td>Y=439063.0 N, X=619754.7 E</td> </tr> <tr> <td>Ⓒ</td> <td>Y=437699.8 N, X=614465.5 E</td> </tr> <tr> <td>Ⓓ</td> <td>Y=437735.4 N, X=619760.8 E</td> </tr> </table>	Ⓐ	Y=439026.8 N, X=614462.0 E	Ⓑ	Y=439063.0 N, X=619754.7 E	Ⓒ	Y=437699.8 N, X=614465.5 E	Ⓓ	Y=437735.4 N, X=619760.8 E	<p><b>OPERATOR CERTIFICATION</b></p> <p>I hereby certify that the information herein is true and complete to the best of my knowledge and belief, and that this organization either owns a working interest or unleased mineral interest in the land including the proposed bottom hole location or has a right to drill this well at this location pursuant to a contract with an owner of such mineral or working interest, or to a voluntary pooling agreement or a compulsory pooling order heretofore entered by the division.</p> <p><i>David Stewart</i> 6/18/12 Signature Date</p> <p>David Stewart - Reg. Adm. Printed Name</p> <p>dw@stewart-oxy.com E-mail Address</p> <p><b>SURVEYOR CERTIFICATION</b></p> <p>I hereby certify that the well location shown on this plat was plotted from field notes of actual surveys made by me or under my supervision, and that the same is true and correct to the best of my belief.</p> <p>JANUARY 6, 2012</p> <p>Date of Survey Signature &amp; Seal of Professional Surveyor:</p> <p><i>Ronald J. Eidson</i> RONALD J. EIDSON NEW MEXICO REGISTERED PROFESSIONAL SURVEYOR 3239 06/13/2012</p> <p>Certificate Number 12641 Professional Surveyor Ronald J. Eidson 3239</p> <p>AF/DSR Ref. W.O. JWSC W.O.: 12.13.1054</p>
Ⓐ	Y=439026.8 N, X=614462.0 E								
Ⓑ	Y=439063.0 N, X=619754.7 E								
Ⓒ	Y=437699.8 N, X=614465.5 E								
Ⓓ	Y=437735.4 N, X=619760.8 E								

**DRILLING PROGRAM**

Operator Name/Number:	OXY USA Inc.	16696
Lease Name/Number:	Cedar Canyon 23 #1H	
Pool Name/Number:	Corral Draw Bone Spring	96238
Surface Location:	2068 FNL 483 FWL SWNW(E) Sec 23 T24S R29E	Federal Lease No. NMNM81586
Bottom Hole Location:	1980 FNL 660 FEL SENE(H) Sec 23 T24S R29E	Federal Lease No. NMNM81586

Proposed TD:	7895' TVD	11742' TMD	Elevation: 2953' GL
SL - Lat: 32.204429	Long: 103.961705	X= 614946.8 Y= 438289.7	NAD - 1927
BH - Lat: 32.204710	Long: 103.948284	X= 619097.8 Y= 438406.4	NAD - 1927

**1. Geologic Name of Surface Formation:**

a. Permian

**2. Estimated Tops of Geological Markers & Depths of Anticipated Fresh Water, Oil or Gas:**

<u>Geological Marker</u>	<u>Depth</u>	<u>Type</u>
a. Rustler	636'	---
b. Top Salt	712'	---
c. Base Salt	2926'	---
d. Delaware	3050'	Oil
e. Bell Canyon	3146'	Oil
f. Cherry Canyon	4096'	Oil
g. Brushy Canyon	5246'	Oil
h. Bone Spring	6836'	Oil
i. 1st Bone Spring	7846'	Oil

*See following page**8/3/12  
WWI***3. Casing Program:**

<u>Hole Size</u>	<u>Interval</u>	<u>OD Csg</u>	<u>Weight</u>	<u>Collar</u>	<u>Grade</u>	<u>Condition</u>	<u>Collapse Design Factor</u>	<u>Burst Design Factor</u>	<u>Tension Design Factor</u>
17-1/2"	550'	13-3/8"	48	ST&C	H-40	New	4.16	9.34	12.2
				Hole filled with 8.9# Mud			770#	1730#	
12-1/4"	3150'	9-5/8"	40	LT&C	J-55	New	1.94	2.99	4.13
				Hole filled with 10# Mud			2570#	3950#	
8-3/4"	11742' M	5-1/2"	17	LT&C	N-80	New	1.63	2.52	1.92
DVT @ 6000' - POST @ 3200'				Hole filled with 9.2# Mud			6280#	7740#	

Collapse and burst loads calculated using Stress Check with anticipated loads

**4. Cement Program**

- a. 13-3/8" Surface Circulate cement to surface w/ 450sx PP cmt w/ 4% Bentonite + .125#/sx Poly-E-Flake + 2% CaCl<sub>2</sub>, 13.5ppg 1.75 yield 589# 24hr CS 165% Excess followed by 200sx PP cmt w/ 2% CaCl<sub>2</sub>, 14.8ppg 1.35 yield 1608# 24hr CS 165% Excess.
- b. 9-5/8" Intermediate Circulate cement to surface w/ 890sx HES light PP cmt w/ 5% Salt + .125#/sx Poly-E-Flake + 3#/sx Kol Seal, 12.9ppg 1.87 yield 840# 24hs CS 105% Excess followed by 200sx PP cmt w/ 1% CaCl<sub>2</sub>, 14.8ppg 1.34 yield 2125# 24hr CS 105% Excess.

Operator Name/Number:	OXY USA Inc.	16696
Lease Name/Number:	Cedar Canyon 23 #1H	
Pool Name/Number:	Corral Draw Bone Spring	96238
Surface Location:	2068 FNL 483 FWL SWNW(E) Sec 23 T24S R29E	Federal Lse No. NMNM81586
Bottom Hole Location:	1980 FNL 660 FEL SENE(H) Sec 23 T24S R29E	Federal Lse No. NMNM81586

## 2. Estimated Tops of Geological Markers & Depths of Anticipated Fresh Water, Oil or Gas:

<u>Geological Marker</u>	<u>Depth</u>	<u>Type</u>
a. Rustler	523'	---
b. Top Salt	659'	---
c. Base Salt	2784'	---
d. Delaware	3017'	Oil
e. Bell Canyon	3074'	Oil
f. Cherry Canyon	3919'	Oil
g. Brushy Canyon	5219'	Oil
h. Bone Spring	6794'	Oil
i. 1st Bone Spring	7794'	Oil

<u>Hole Size</u>	<u>Interval</u>	<u>OD Csg</u>	<u>Weight</u>	<u>Collar</u>	<u>Grade</u>	<u>Condition</u>	<u>Collapse Design Factor</u>	<u>Burst Design Factor</u>	<u>Tension Design Factor</u>
17-1/2"	0-550'	13-3/8"	48	ST&C	H-40	New	4.16	9.34	12.2
				Hole filled with 8.9# Mud			770#	1730#	
12-1/4"	0-3150'	9-5/8"	40	LT&C	J-55	New	1.94	2.99	4.13
				Hole filled with 10# Mud			2570#	3950#	
8-3/4"	0-11742'M	5-1/2"	17	LT&C	N-80	New	1.63	2.52	1.92
DVT @ 6000' - POST @ 3200'				Hole filled with 9.2# Mud			6280#	7740#	

## 5. Pressure Control Equipment:

Surface None

Production 13-5/8" 10M three ram stack w/ 5M annular preventer, 10M Choke Manifold

All BOP's and associated equipment will be tested in accordance with Onshore Order #2 (250/5000 psi on rams for 10 minutes each and 250/3500 for 10 minutes for annular preventer, equal to 70% of working pressure) with a third party BOP testing service before drilling out the 13-3/8" casing shoe. Wellhead pressure rating will support this test and 13-3/8" casing will be protected from high pressure. Since the wellhead system is a multibowl design, this initial test will cover the requirements prior to drilling out the 9-5/8" casing shoe.

Pipe Rams will be operated and checked each 24-hour period and each time the drill pipe is out of the hole. These functional tests will be documented on the daily driller's log. A 2" kill line and 3" choke line will be accommodated on the drilling spool below the ram-type BOP. Other accessory BOP equipment will include a Kelly cock, floor safety valve, choke lines and choke manifold having a 5000 psi WP rating. OXY requests that the entire system be tested as a 5000psi WP rating.

c. 5-1/2" Production Cement 1st stage w/ 430sx HES light PP cmt w/ 3#/sx Kol Seal + 3#/sx salt + .3% HR-601, 12.4ppg 2.08 yield 460# 24hr CS 135% Excess followed by 1610sx Super H w/ 1#/sx salt .5% Halad-344 + .125#/sx Poly-E-Flake + 3#/sx Kol-Seal + .3% HR-601, 13.2ppg 1.61 yield 1372# 24hr CS 135% Excess, Calc TOC-5995'

Cement 2nd stage w/ 960sx HES light PP cmt w/ 3#/sx Kol Seal + 3#/sx salt, 12.4ppg 2.07 yield 610# 24hr CS 200% Excess followed by 100sx PP cmt w/ 1% CaCl<sub>2</sub>, 14.8ppg 1.34 yield 1372# 24hr CS 200% Excess, Calc TOC-3150'

Cement 3rd stage w/ 400sx HES Light PP cmt w/ 3#/sx Salt, 12.4ppg 2.05 yield 511# 24hr CS 85% Excess followed by 100sx PP cmt w/ 2% CaCl<sub>2</sub>, 14.8ppg 1.35 yield 2025# 24hr CS 200% Excess, Circ Surface

The above cement volumes could be revised pending the caliper measurement.

##### 5. Pressure Control Equipment:

*See previous page  
8/3/12 WWI*

Surface None

Production 13-5/8" 10M two ram stack w/ 5M annular preventer, 10M Choke Manifold

All BOP's and associated equipment will be tested in accordance with Onshore Order #2 (250/5000 psi on rams for 10 minutes each and 250/3500 for 10 minutes for annular preventer, equal to 70% of working pressure) with a third party BOP testing service before drilling out the 13-3/8" casing shoe. Wellhead pressure rating will support this test and 13-3/8" casing will be protected from high pressure. Since the wellhead system is a multibowl design, this initial test will cover the requirements prior to drilling out the 9-5/8" casing shoe.

Pipe Rams will be operated and checked each 24-hour period and each time the drill pipe is out of the hole. These functional tests will be documented on the daily driller's log. A 2" kill line and 3" choke line will be accommodated on the drilling spool below the ram-type BOP. Other accessory BOP equipment will include a Kelly cock, floor safety valve, choke lines and choke manifold having a 5000 psi WP rating. OXY requests that the entire system be tested as a 5000psi WP rating.

OXY also requests a variance to connect the BOP outlet to the choke manifold using a co-flex hose that is manufactured by Contitech Rubber Industrial KFT. It is a 3" ID X 35' flexible hose rated to 10000psi working pressure. It has been tested to 15000psi and is built to API Spec 16C. Once the flex line is installed, it will be tied down with safety clamps, see attached for certifications.

##### 6. Proposed Mud Circulation System

<u>Depth</u>	<u>Mud Wt.</u> <u>ppg</u>	<u>Visc</u> <u>sec</u>	<u>Fluid</u> <u>Loss</u>	<u>Type System</u>
0 - 550' <i>See COA</i>	8.4-8.9	32-34	NC	Fresh Water/Spud Mud
550 - 3150'	9.8-10.0	28-29	NC	Brine Water
3150 - 6000'	8.6-8.8	28-29	NC	Fresh Water
6000 - TD'	9.0-9.2	50-50	8-15	LSND

Pump high viscosity sweeps as needed for hole cleaning. The mud system will be monitored visually/manually as well as with an electronic PVT. The necessary mud products for additional weight and fluid loss control will be on location at all times.

##### 7. Auxiliary Well Control and Monitoring Equipment:

- A Kelly cock will be in the drill string at all times.
- A full opening drill pipe stabbing valve having the appropriate connections will be on the rig floor unobstructed and readily accessible at all times.

- c. Hydrogen Sulfide detection equipment will be in operation after drilling out the surface casing shoe until the production casing is cemented. Breathing equipment will be on location upon drilling the surface casing shoe until total depth is reached. If Hydrogen Sulfide is encountered, measured amounts and formations will be reported to the BLM.

#### **8. Logging, Coring and Testing Program:**

- a. Drill stem tests are not anticipated but if done will be based on geological sample shows.
- b. The open hole electrical logging program will consist of a Triple Combo from build section to base of intermediate. GR-Neutron from build section to surface. MWD-GR from kick-off point to TD.
- c. No coring program is planned but if done will be sidewall rotary cores.
- d. Mud logging will be initiated from the base of surface casing to TD.

#### **9. Potential Hazards:**





No abnormal pressures, temperatures or H<sub>2</sub>S gas are expected. The highest anticipated pressure gradient would be 0.44psi/ft or 3500psi. If H<sub>2</sub>S is encountered the operator will comply with the provisions of Onshore Oil & Gas Order No.6. No lost circulation is expected to occur. All personnel will be familiar with all aspects of safe operation of equipment being used to drill this well. Adequate flare lines will be installed off the mud/gas separator where gas may be flared safely.

#### **10. Anticipated Starting Date and Duration of Operations:**

Road and location construction will begin after the BLM has approved the APD. Anticipated spud date will be as soon as possible after BLM approval and as soon as a rig will be available. Move in operations and drilling is expected to take 45 days. If production casing is run, then an additional 30 days will be needed to complete the well and construct surface facilities and/or lay flow lines in order to place well on production.



Cypress 23 #1H  
Eddy Co, New Mexico



LEGEND

1H (1)
Exist POGO RB Fed 7 (1)
Exist RB 23 Fed 14 (1)
Exist Canyon 23 Fed Com 1 (1)
Exist River Bend 23 Fed 16 (1)
1
Plan #1

SITE DETAILS

Cedar Canyon 23 #1H

Site Centre Northing:	438289.70
Easting:	614946.80
Ground Level:	2953.00
Positional Uncertainty:	0.00
Convergence:	0.20

FIELD DETAILS

Eddy Co, NM (Nad 27)

Geodetic System:	US State Plane Coordinate System 1927
Ellipsoid:	NAD27 (Clarke 1866)
Zone:	New Mexico, Eastern Zone
Magnetic Model:	IGRF2010
System Datum:	Mean Sea Level
Local North:	Grid North

WELL DETAILS

Name	+N/-S	+E/-W	Northing	Easting	Latitude	Longitude	Slot
Cedar Canyon 23 #1H	0.00	0.00	438289.70	614946.80	32°12'15.946N	103°57'42.138W	N/A

TARGET DETAILS

Name	TVD	+N/-S	+E/-W	Northing	Easting	Shape
PBHL	7895.00	116.70	4151.00	438406.40	619097.80	Point

SECTION DETAILS

Sec	MD	Inc	Azi	TVD	+N/-S	+E/-W	DLeg	TFace	VSec	Target
1	0.00	0.00	88.39	0.00	0.00	0.00	0.00	0.00	0.00	
2	7262.12	0.00	88.39	7262.12	0.00	0.00	0.00	0.00	0.00	
3	8152.55	89.04	88.39	7835.00	15.83	563.16	10.00	88.39	563.38	
4	11742.31	89.04	88.39	7895.00	116.70	4151.00	0.00	0.00	4152.64	PBHL



Plan: Plan #1 (Cedar Canyon 23 #1H/1)  
Created By: Keith Noack  
Date: 2/1/2012





# Weatherford International Ltd.

## WFT Plan Report - X & Y's



DDP-2

Weatherford

Company: Occidental Permian Ltd	Date: 2/1/2012	Time: 09:51:45	Page: 1
Field: Eddy Co, NM (Nad 27)	Co-ordinate(NE) Reference: Well: Cedar Canyon 23 #1H, Grid North		
Site: Cedar Canyon 23 #1H	Vertical (TVD) Reference: SITE 2977.0		
Well: Cedar Canyon 23 #1H	Section (VS) Reference: Well: (0.00N,0.00E,88.39Azi)		
Wellpath: 1	Survey Calculation Method: Minimum Curvature	Db: Sybase	

Plan: Plan #1	Date Composed: 2/1/2012
Principal: Yes	Version: 1
	Tied-to: From Surface

Field: Eddy Co, NM (Nad 27)	
Map System: US State Plane Coordinate System 1927	Map Zone: New Mexico, Eastern Zone
Geo Datum: NAD27 (Clarke 1866)	Coordinate System: Well Centre
Sys Datum: Mean Sea Level	Geomagnetic Model: IGRF2010

Site: Cedar Canyon 23 #1H	
Site Position: Northing: 438289.70 ft Latitude: 32 12 15.946 N	
From: Map Easting: 614946.80 ft Longitude: 103 57 42.138 W	
Position Uncertainty: 0.00 ft North Reference: Grid	
Ground Level: 2953.00 ft Grid Convergence: 0.20 deg	

Well: Cedar Canyon 23 #1H	Slot Name:
Well Position: +N/-S 0.00 ft Northing: 438289.70 ft Latitude: 32 12 15.946 N	
+E/-W 0.00 ft Easting: 614946.80 ft Longitude: 103 57 42.138 W	
Position Uncertainty: 0.00 ft	

Wellpath: 1	Drilled From: Surface
Current Datum: SITE	Tie-on Depth: 0.00 ft
Magnetic Data: 4/1/2012	Above System Datum: Mean Sea Level
Field Strength: 48507 nT	Declination: 7.67 deg
Vertical Section: Depth From (TVD)	Mag Dip Angle: 60.08 deg
ft	+N/-S ft
0.00	0.00
	+E/-W ft
	0.00
	Direction deg
	88.39

### Plan Section Information

MD ft	Incl deg	Azim deg	TVD ft	+N/-S ft	+E/-W ft	DLS deg/100ft	Build deg/100ft	Turn deg/100ft	TFO deg	Target
0.00	0.00	88.39	0.00	0.00	0.00	0.00	0.00	0.00	0.00	
7262.12	0.00	88.39	7262.12	0.00	0.00	0.00	0.00	0.00	0.00	
8152.55	89.04	88.39	7835.00	15.83	563.16	10.00	10.00	0.00	88.39	
11742.31	89.04	88.39	7895.00	116.70	4151.00	0.00	0.00	0.00	0.00	PBHL

### Survey

MD ft	Incl deg	Azim deg	TVD ft	N/S ft	E/W ft	VS ft	DLS deg/100ft	MapN ft	MapE ft	Comment
7200.00	0.00	88.39	7200.00	0.00	0.00	0.00	0.00	438289.70	614946.80	
7262.12	0.00	88.39	7262.12	0.00	0.00	0.00	0.00	438289.70	614946.80	KOP
7300.00	3.79	88.39	7299.97	0.04	1.25	1.25	10.00	438289.74	614948.05	
7400.00	13.79	88.39	7398.67	0.46	16.50	16.51	10.00	438290.16	614963.30	
7500.00	23.79	88.39	7493.22	1.37	48.66	48.68	10.00	438291.07	614995.46	
7600.00	33.79	88.39	7580.75	2.72	96.73	96.77	10.00	438292.42	615043.53	
7700.00	43.79	88.39	7658.60	4.48	159.27	159.34	10.00	438294.18	615106.07	
7800.00	53.79	88.39	7724.40	6.59	234.37	234.47	10.00	438296.29	615181.17	
7900.00	63.79	88.39	7776.16	8.99	319.76	319.88	10.00	438298.69	615266.56	
8000.00	73.79	88.39	7812.30	11.61	412.83	412.99	10.00	438301.31	615359.63	
8100.00	83.79	88.39	7831.72	14.36	510.76	510.96	10.00	438304.06	615457.56	
8152.55	89.04	88.39	7835.00	15.83	563.16	563.38	10.00	438305.53	615509.96	LP
8200.00	89.04	88.39	7835.79	17.17	610.59	610.83	0.00	438306.87	615557.39	
8300.00	89.04	88.39	7837.46	19.98	710.53	710.82	0.00	438309.68	615657.33	
8400.00	89.04	88.39	7839.14	22.79	810.48	810.80	0.00	438312.49	615757.28	
8500.00	89.04	88.39	7840.81	25.60	910.43	910.79	0.00	438315.30	615857.23	
8600.00	89.04	88.39	7842.48	28.41	1010.37	1010.77	0.00	438318.11	615957.17	



# Weatherford International Ltd.

## WFT Plan Report - X & Y's



DDP-3

Weatherford

Company: Occidental Permian Ltd.  
Field: Eddy Co. NM (Nad:27)  
Site: Cedar Canyon 23 #1H  
Well: Cedar Canyon 23 #1H  
Wellpath: 1

Date: 2/1/2012  
Co-ordinate(NE) Reference: Well: Cedar Canyon 23 #1H, Grid North  
Vertical (TVD) Reference: SITE 2977.0  
Section (VS) Reference: Well: (0.00N, 0.00E, 88.39Azi)  
Survey Calculation Method: Minimum Curvature  
Page: 2  
Db: Sybase

### Survey

MD ft	Incl deg	Azim deg	TVD ft	N/S ft	E/W ft	VS ft	DLS deg/100ft	MapN ft	MapE ft	Comment
8700.00	89.04	88.39	7844.15	31.22	1110.32	1110.76	0.00	438320.92	616057.12	
8800.00	89.04	88.39	7845.82	34.03	1210.27	1210.75	0.00	438323.73	616157.07	
8900.00	89.04	88.39	7847.49	36.83	1310.21	1310.73	0.00	438326.53	616257.01	
9000.00	89.04	88.39	7849.16	39.64	1410.16	1410.72	0.00	438329.34	616356.96	
9100.00	89.04	88.39	7850.84	42.45	1510.11	1510.70	0.00	438332.15	616456.91	
9200.00	89.04	88.39	7852.51	45.26	1610.05	1610.69	0.00	438334.96	616556.85	
9300.00	89.04	88.39	7854.18	48.07	1710.00	1710.68	0.00	438337.77	616656.80	
9400.00	89.04	88.39	7855.85	50.88	1809.95	1810.66	0.00	438340.58	616756.75	
9500.00	89.04	88.39	7857.52	53.69	1909.89	1910.65	0.00	438343.39	616856.69	
9600.00	89.04	88.39	7859.19	56.50	2009.84	2010.63	0.00	438346.20	616956.64	
9700.00	89.04	88.39	7860.86	59.31	2109.79	2110.62	0.00	438349.01	617056.59	
9800.00	89.04	88.39	7862.54	62.12	2209.73	2210.61	0.00	438351.82	617156.53	
9900.00	89.04	88.39	7864.21	64.93	2309.68	2310.59	0.00	438354.63	617256.48	
10000.00	89.04	88.39	7865.88	67.74	2409.63	2410.58	0.00	438357.44	617356.43	
10100.00	89.04	88.39	7867.55	70.55	2509.57	2510.56	0.00	438360.25	617456.37	
10200.00	89.04	88.39	7869.22	73.36	2609.52	2610.55	0.00	438363.06	617556.32	
10300.00	89.04	88.39	7870.89	76.17	2709.47	2710.54	0.00	438365.87	617656.27	
10400.00	89.04	88.39	7872.56	78.98	2809.41	2810.52	0.00	438368.68	617756.21	
10500.00	89.04	88.39	7874.24	81.79	2909.36	2910.51	0.00	438371.49	617856.16	
10600.00	89.04	88.39	7875.91	84.60	3009.31	3010.49	0.00	438374.30	617956.11	
10700.00	89.04	88.39	7877.58	87.41	3109.25	3110.48	0.00	438377.11	618056.05	
10800.00	89.04	88.39	7879.25	90.22	3209.20	3210.47	0.00	438379.92	618156.00	
10900.00	89.04	88.39	7880.92	93.03	3309.14	3310.45	0.00	438382.73	618255.94	
11000.00	89.04	88.39	7882.59	95.84	3409.09	3410.44	0.00	438385.54	618355.89	
11100.00	89.04	88.39	7884.26	98.65	3509.04	3510.42	0.00	438388.35	618455.84	
11200.00	89.04	88.39	7885.94	101.46	3608.98	3610.41	0.00	438391.16	618555.78	
11300.00	89.04	88.39	7887.61	104.27	3708.93	3710.40	0.00	438393.97	618655.73	
11400.00	89.04	88.39	7889.28	107.08	3808.88	3810.38	0.00	438396.78	618755.68	
11500.00	89.04	88.39	7890.95	109.89	3908.82	3910.37	0.00	438399.59	618855.62	
11600.00	89.04	88.39	7892.62	112.70	4008.77	4010.35	0.00	438402.40	618955.57	
11700.00	89.04	88.39	7894.29	115.51	4108.72	4110.34	0.00	438405.21	619055.52	
11742.31	89.04	88.39	7895.00	116.70	4151.00	4152.64	0.00	438406.40	619097.80	PBHL

### Targets

Name	Description	TVD	+N/S	+E/W	Map Northing	Map Easting	Latitude Deg Min Sec	Longitude Deg Min Sec
PBHL		7895.00	116.70	4151.00	438406.40	619097.80	32 12 16.956 N	103 56 53.821 W

### Casing Points

MD ft	TVD ft	Diameter in	Hole Size in	Name
500.00	500.00	0.000	0.000	Sfc Csg
3000.00	3000.00	0.000	0.000	Int Csg

### Annotation

MD ft	TVD ft	
7262.12	7262.12	KOP
8152.55	7835.00	LP
11742.30	7895.00	PBHL



# New Mexico Office of the State Engineer

## Water Column/Average Depth to Water

(A CLW##### in the  
POD suffix indicates the  
POD has been replaced  
& no longer serves a  
water right file.)

(R=POD has  
been replaced,  
O=orphaned,  
C=the file is (quarters are 1=NW 2=NE 3=SW 4=SE)  
closed) (quarters are smallest to largest) (NAD83 UTM in meters) (In feet)

POD Number	POD Code	Subbasin	County	Q 64	Q 16	Q 4	Sec	Tws	Rng	X	Y	Depth Well	Depth Water	Water Column
C 00863			ED	3	3	1	16	24S	29E	594524	3565091*	220		
C 00863 CLW199506	O		ED	3	3	1	16	24S	29E	594524	3565091*	220		
C 02713		C	ED	4	4	1	16	24S	29E	591633	3565944	230	18	212

Average Depth to Water: 18 feet

Minimum Depth: 18 feet

Maximum Depth: 18 feet


**Record Count: 3**

**PLSS Search:**


Section(s): 13, 14, 15, 16, Township: 24S Range: 29E  
21, 22, 23, 24,  
25, 26, 27, 28

\*UTM location was derived from PLSS - see Help


The data is furnished by the NMOSE/ISC and is accepted by the recipient with the expressed understanding that the OSE/ISC make no warranties, expressed or implied, concerning the accuracy, completeness, reliability, usability, or suitability for any particular purpose of the data.



- LEGEND
- ①— 4 1/16"-10M FLANGED END GATE VALVE
  - ②— 4 1/16"-10M FLANGED END GATE VALVE WITH DOUBLE ACTING HYDRAULIC ACTUATOR
  - ③— 2 1/16"-10M FLANGED END GATE VALVE
  - ④— 2 1/16"-10M FLANGED END CHECK VALVE
  - ⑤— DOUBLE STUDDED ADAPTER



13 5/8-10M STACK



**ISSUED FOR FABRICATION**  
December-18-2007  
DRAFTSMAN  
ENGINEER

API 6A MONOGRAMMED CAMERON CHOKE AND KILL WING VALVE ASSEMBLIES ARE NOT SHOWN FOR CLARITY

WEIGHTS DO NOT INCLUDE HOSES, ADAPTER SPOOLS OR QUICK CONNECT FITTINGS

**HELMERICH & PAYNE**  
INTERNATIONAL DRILLING CO

TITLE: 13 5/8"-10M BOP 3 RAM STACK  
FLEXRIG3

ENGINEERING APPROVAL DATE


12/18/07	ADDED SHEET 03	JAV
4-10-07	ORIENTATION REVERSED, DOUBLE STUDDED ADAPTER, VALVES 1, 2, & 3 AND MS CHECK VALVE ADDED	JBG
4-04-07	ADDED TO SPACER ADAPTER SPOOL	JBG
02-07-07	ADDED ADAPTER SPOOL	MWL
08-13-02	CORRECTED BOP STACK	MWL
REV	DATE	DESCRIPTION

CUSTOMER	H&P
PROJECT	FLEXRIG3
DRAWN	MTS
DATE	6-5-02
DWG NO	210-P1-07
SCALE	3/4"=1'
SHEET	1 OF 1
REV	E


PROPRIETARY

THIS DRAWING AND THE IDEAS AND INFORMATION INCLUDED IN THIS DRAWING ARE PROPRIETARY AND ARE NOT TO BE REPRODUCED, DISTRIBUTED OR DISCLOSED IN ANY MANNER WITHOUT THE PRIOR, WRITTEN CONSENT OF A DULY AUTHORIZED OFFICER OF HELMERICH & PAYNE INT'L DRILLING CO

# 10M CHOKE MANIFOLD CONFIGURATION



Chk Manifold-2



**ISSUED FOR  
FABRICATION**  
MARCH 8, 2000  
DRAFTSMAN  
ENGINEER

**HELMERICH & PAYNE**  
INTERNATIONAL DRILLING CO.

CHOKE MANIFOLD


CUSTOMER: H&P  
PROJECT: FLEXINGS  
DRAWN: MTS  
DATE: 2-28-02  
DWS. NO.:  
SCALE: 3/4"=1'  
SHEET: 1 OF 1  
216-P1-05  
REV: A

**PROPRIETARY**


THIS DRAWING AND THE IDEAS AND INFORMATION INCLUDED  
HEREIN ARE PROPRIETARY AND ARE NOT TO BE  
REPRODUCED, DISTRIBUTED OR DISCLOSED IN ANY MANNER  
WITHOUT THE PRIOR WRITTEN CONSENT OF A QUALIFIED  
OFFICER OF HELMERICH & PAYNE INTL DRILLING CO.

ENGINEERING APPROVAL		DATE	TITLE
△			
△			
△			
△			
△	10/15/02	ADJUST DIM TO FIELD CONFIRMED DIM	RAY
REV	DATE	DESCRIPTION	BY


10M REMOTE  
KILL LINE SCHEMATIC



Flex Hose-7



PLAN VIEW



ISSUED FOR  
FABRICATION  
December-19-2007  
DRAFTSMAN  
ENGINEER

PROPRIETARY

THIS DRAWING AND THE IDEAS AND INFORMATION INCLUDED IN THIS DRAWING ARE PROPRIETARY AND ARE NOT TO BE REPRODUCED, DISTRIBUTED OR DISCLOSED IN ANY MANNER, WITHOUT THE PRIOR, WRITTEN CONSENT OF A DULY AUTHORIZED OFFICER OF HELMERICH & PAYNE INT'L DRILLING CO.

ENGINEERING APPROVAL		DATE	TITLE	
[Signature]			HELMERICH & PAYNE INTERNATIONAL DRILLING CO.	
PROJECT		CHOKE LINE SYSTEM FLEXRIG3		
CUSTOMER				
PROJECT				
REV	DATE	DESCRIPTION	BY	SCALE
12/18/07		REMOVED SHEET TOTAL CALLOUT	JAV	3/16"=1'
DRAWN		JBG	DATE	4-10-07
DWC NO		210-P1-07		REV
SHEET 2 OF 3				A



[illegible]

40' = 0° x 10° = 0  
MEETING/CHANGE HOUSE



Fluid Technology

Quality Document

---

CERTIFICATE OF CONFORMITY

**Supplier** : CONTITECH RUBBER INDUSTRIAL KFT.  
**Equipment** : 6 pcs. Choke and Kill Hose with installed couplings  
**Type** : 3" x 10,67 m WP: 10000 psi  
**Supplier File Number** : 412638  
**Date of Shipment** : April. 2008  
**Customer** : Phoenix Beattie Co.  
**Customer P.o.** : 002491  
**Referenced Standards**  
**/ Codes / Specifications** : API Spec 16 C  
**Serial No.:** 52754,52755,52776,52777,52778,52782

## STATEMENT OF CONFORMITY

We hereby certify that the above items/equipment supplied by us are in conformity with the terms, conditions and specifications of the above Purchaser Order and that these items/equipment were fabricated inspected and tested in accordance with the referenced standards, codes and specifications and meet the relevant acceptance criteria and design requirements.

COUNTRY OF ORIGIN HUNGARY/EU

Signed : .....

Position: Q.C. Manager

ContiTech Rubber  
Industrial Kft.  
Quality Control Dept.  
(1)

Date: 04. April. 2008





## Phoenix Beattie Corp

11535 Britton Park Drive  
Houston, TX 77041  
Tel: (832) 327-0141  
Fax: (832) 327-0148  
E-mail: mail@phoenixbeattie.com  
www.phoenixbeattie.com

## Delivery Note

<b>Customer Order Number</b>	370-369-001	<b>Delivery Note Number</b>	003078	<b>Page</b>	1
<b>Customer / Invoice Address</b> HELMERICH & PAYNE INT'L DRILLING CO 1437 SOUTH BOULDER TULSA, OK 74119		<b>Delivery / Address</b> HELMERICH & PAYNE IDC ATTN: JOE STEPHENSON - RIG 370 13609 INDUSTRIAL ROAD HOUSTON, TX 77015			

<b>Customer Acc No</b>	<b>Phoenix Beattie Contract Manager</b>	<b>Phoenix Beattie Reference</b>	<b>Date</b>
H01	JJL	006330	05/23/2008

Item No	Beattie Part Number / Description	Qty Ordered	Qty Sent	Qty To Follow
1	HP10CK3A-35-4F1 3" 10K 16C C&K HOSE x 35ft OAL CW 4.1/16" API SPEC FLANGE E/ End 1: 4.1/16" 10Kpsi API Spec 6A Type 6BX Flange End 2: 4.1/16" 10Kpsi API Spec 6A Type 6BX Flange c/w BX155 Standard ring groove at each end Suitable for H2S Service Working pressure: 10,000psi Test pressure: 15,000psi Standard: API 16C Full specification Armor Guarding: Included Fire Rating: Not Included. Temperature rating: -20 Deg C to +100 Deg C	1	1	0
2	SECK3-HPF3 LIFTING & SAFETY EQUIPMENT TO SUIT HP10CK3-35-F1 2 x 160mm ID Safety Clamps 2 x 244mm ID Lifting Collars & element C's 2 x 7ft Stainless Steel wire rope 3/4" OD 4 x 7.75t Shackles	1	1	0
3	SC725-200CS SAFETY CLAMP 200MM 7.25T C/S GALVANISED	1	1	0

Continued...

All goods remain the property of Phoenix Beattie until paid for in full. Any damage or shortage on this delivery must be advised within 5 days. Returns may be subject to a handling charge.

Flex Hose-5  
Form No 100/12

## Phoenix Beattie Corp

11635 Brittadore Park Drive  
Houston, TX 77041  
Tel: (832) 327-0141  
Fax: (832) 327-0149  
E-mail: mail@phoenixbeattie.com  
www.phoenixbeattie.com

## Delivery Note

Customer Order Number	370-369-001	Delivery Note Number	003078	Page	2
Customer / Invoice Address HELMERICH & PAYNE INT'L DRILLING CO 1437 SOUTH BOULDER TULSA, OK 74119		Delivery / Address HELMERICH & PAYNE IDC ATTN: JOE STEPHENSON - RIG 370 13609 INDUSTRIAL ROAD HOUSTON, TX 77015			

Customer Acc No	Phoenix Beattie Contract Manager	Phoenix Beattie Reference	Date
H01	JJL	006330	05/23/2008

Item No	Beattie Part Number / Description	Qty Ordered	Qty Sent	Qty To Follow
4	SC725-132CS SAFETY CLAMP 132MM 7.25T C/S GALVANIZED C/W BOLTS	1	1	0
5	00CERT-HYDRO HYDROSTATIC PRESSURE TEST CERTIFICATE	1	1	0
6	00CERT-LOAD LOAD TEST CERTIFICATES	1	1	0
7	00FREIGHT INBOUND / OUTBOUND FREIGHT PRE-PAY & ADD TO FINAL INVOICE NOTE: MATERIAL MUST BE ACCOMPANIED BY PAPERWORK INCLUDING THE PURCHASE ORDER, RIG NUMBER TO ENSURE PROPER PAYMENT	1	1	0



Phoenix Beattie Inspection Signature : 

Received in Good Condition : Signature

Print Name


Date

All goods remain the property of Phoenix Beattie until paid for in full. Any damage or shortage on this delivery must be advised within 5 days.  
Returns may be subject to a handling charge.

QUALITY CONTROL INSPECTION AND TEST CERTIFICATE				CERT. N°: 746	
PURCHASER: Phoenix Beattie Co.				P.O. N°: 002491	
CONTITECH ORDER N°: 412638		HOSE TYPE: 3" ID Choke and Kill Hose			
HOSE SERIAL N°: 52777		NOMINAL / ACTUAL LENGTH: 10,67 m			
W.P. 68,96 MPa 10000 psi		T.P. 103,4 MPa 15000 psi		Duration: 60 ~ min.	
<p>Pressure test with water at ambient temperature</p> <p style="text-align: center;">See attachment. (1 page)</p> <p>↑ 10 mm = 10 Min. → 10 mm = 25 MPa</p>					
COUPLINGS					
Type	Serial N°		Quality	Heat N°	
3" coupling with 4 1/16" Flange end	917	913	AISI 4130	T7998A	
			AISI 4130	26984	
INFOCHIP INSTALLED				API Spec 16 C Temperature rate: "B"	
All metal parts are flawless					
WE CERTIFY THAT THE ABOVE HOSE HAS BEEN MANUFACTURED IN ACCORDANCE WITH THE TERMS OF THE ORDER AND PRESSURE TESTED AS ABOVE WITH SATISFACTORY RESULT.					
Date:  04. April. 2008	Inspector		Quality Control   <p>ContiTech Rubber Industrial Kit Quality Control Dept. (1)</p>		




1

[illegible]



RL-CL-3

Level Area-No Caliche-For Offices and Living Quarters



Clear all brush +  
20' off pad to  
allow Drk truck  
to drive off pad  
& maneuver drk  
into position




## **Permian Drilling Hydrogen Sulfide Drilling Operations Plan Cedar Canyon 23 Federal #1H**


Open drill site. No homes or buildings are near the proposed location.


### **1. Escape**

Personnel shall escape upwind of wellbore in the event of an emergency gas release.  
Escape can take place through the lease road on the Southeast side of the location.  
Personnel need to move to a safe distance and block the entrance to location.


# Rig Layout

 H2S Detectors. At least three detectors will be installed: bell nipple, rig floor and Shakers.

 Briefing Areas. At least two briefing areas will be placed, 90 deg off.

 Wind direction indicators. Visible from rig floor and from the mud pits area.

A gas buster is connected to both the choke manifold and flowline outlets.





## **Permian Drilling Hydrogen Sulfide Drilling Operations Plan New Mexico**

### **Scope**

This contingency plan establishes guidelines for the public, all company employees, and contract employees who's work activities may involve exposure to hydrogen sulfide (H<sub>2</sub>S) gas.

While drilling this well, it is possible to encounter H<sub>2</sub>S bearing formations. At all times, the first barrier to control H<sub>2</sub>S emissions will be the drilling fluid, which will have a density high enough to control influx.

### **Objective**

1. Provide an immediate and predetermined response plan to any condition when H<sub>2</sub>S is detected. All H<sub>2</sub>S detections in excess of 10 parts per million (ppm) concentration are considered an Emergency.
2. Prevent any and all accidents, and prevent the uncontrolled release of hydrogen sulfide into the atmosphere.
3. Provide proper evacuation procedures to cope with emergencies.
4. Provide immediate and adequate medical attention should an injury occur.

## **Discussion**

Implementation:	This plan with all details is to be fully implemented before drilling to <u>commence</u> .
Emergency response Procedure:	This section outlines the conditions and denotes steps to be taken in the event of an emergency.
Emergency equipment Procedure:	This section outlines the safety and emergency equipment that will be required for the drilling of this well.
Training provisions:	This section outlines the training provisions that must be adhered to prior to drilling.
Drilling emergency call lists:	Included are the telephone numbers of all persons to be contacted should an emergency exist.
Briefing:	This section deals with the briefing of all people involved in the drilling operation.
Public safety:	Public safety personnel will be made aware of any potential evacuation and any additional support needed.
Check lists:	Status check lists and procedural check lists have been included to insure adherence to the plan.
General information:	A general information section has been included to supply support information.

## **Hydrogen Sulfide Training**

All personnel, whether regularly assigned, contracted, or employed on an unscheduled basis, will receive training from a qualified instructor in the following areas prior to commencing drilling operations on the well:

1. The hazards and characteristics of H<sub>2</sub>S.
2. Proper use and maintenance of personal protective equipment and life support systems.
3. H<sub>2</sub>S detection.
4. Proper use of H<sub>2</sub>S detectors, alarms, warning systems, briefing areas, evacuation procedures and prevailing winds.
5. Proper techniques for first aid and rescue procedures.
6. Physical effects of hydrogen sulfide on the human body.
7. Toxicity of hydrogen sulfide and sulfur dioxide.
8. Use of SCBA and supplied air equipment.
9. First aid and artificial respiration.
10. Emergency rescue.

In addition, supervisory personnel will be trained in the following areas:

1. The effects of H<sub>2</sub>S on metal components. If high tensile strength tubular is to be used, personnel will be trained in their special maintenance requirements.
2. Corrective action and shut-in procedures when drilling a well, blowout prevention and well control procedures.
3. The contents and requirements of the H<sub>2</sub>S Drilling Operations Plan.

H<sub>2</sub>S training refresher must have been taken within one year prior to drilling the well. Specifics on the well to be drilled will be discussed during the pre-spud meeting. H<sub>2</sub>S and well control (choke) drills will be performed while drilling the well, at least on a weekly basis. This plan shall be available in the well site. All personnel will be required to carry the documentation proving that the H<sub>2</sub>S training has been taken.

### **Service company and visiting personnel**

- A. Each service company that will be on this well will be notified if the zone contains H<sub>2</sub>S.
- B. Each service company must provide for the training and equipment of their employees before they arrive at the well site.
- C. Each service company will be expected to attend a well site briefing

## **Emergency Equipment Requirements**

### 1. **Well control equipment**

The well shall have hydraulic BOP equipment for the anticipated pressures. Equipment is to be tested on installation and follow Oxy Well Control standard, as well as BLM Onshore Order #2.

*Special control equipment:*

- A. Hydraulic BOP equipment with remote control on ground.
- B. Rotating head
- C. Gas buster equipment shall be installed before drilling out of surface pipe.

### 2. **Protective equipment for personnel**

- A. Four (4) 30-minute positive pressure air packs (2 at each briefing area) on location.
- B. Adequate fire extinguishers shall be located at strategic locations.
- C. Radio / cell telephone communication will be available at the rig.
  - Rig floor and trailers.
  - Vehicle.

### 3. **Hydrogen sulfide sensors and alarms**

- A. H2S sensor with alarms will be located on the rig floor, at the bell nipple, and at the flow line. These monitors will be set to alarm at 10 ppm with strobe light, and audible alarm.
- B. Hand operated detectors with tubes.
- C. H2S monitor tester (to be provided by contract Safety Company.)
- D. There shall be one combustible gas detector on location at all times.

### 4. **Visual Warning Systems**

- A. One sign located at each location entrance with the following language:

**Caution – potential poison gas  
Hydrogen sulfide  
No admittance without authorization**

*Wind sock – wind streamers:*

- A. One 36" (in length) wind sock located at protection center, at height visible from rig floor.
- B. One 36" (in length) wind sock located at height visible from pit areas.

*Condition flags*

- A. One each condition flag to be displayed to denote conditions.

**green – normal conditions**

**yellow – potential danger**

**red – danger, H2S present**

- B. Condition flag shall be posted at each location sign entrance.

5. Mud Program

The mud program is designed to minimize the risk of having H2S and other formation fluids at surface. Proper mud weight and safe drilling practices will be applied. H2S scavengers will be used to minimize the hazards while drilling. Below is a summary of the drilling program.

*Mud inspection devices:*

Garrett gas train or hatch tester for inspection of sulfide concentration in mud system.

6. Metallurgy

- A. Drill string, casing, tubing, wellhead, blowout preventers, drilling spools or adapters, kill lines, choke manifold, lines and valves shall be suitable for the H2S service.
- B. All the elastomers, packing, seals and ring gaskets shall be suitable for H2S service.

7. Well Testing

No drill stem test will be performed on this well.

8. Evacuation plan



Evacuation routes should be established prior to well spud for each well and discussed with all rig personnel.

9. Designated area

- A. Parking and visitor area: all vehicles are to be parked at a predetermined safe distance from the wellhead.
- B. There will be a designated smoking area.
- C. Two briefing areas on either side of the location at the maximum allowable distance from the well bore so they offset prevailing winds perpendicularly, or at a 45-degree angle if wind direction tends to shift in the area.

**Emergency procedures**

- A. In the event of any evidence of H<sub>2</sub>S level above 10 ppm, take the following steps:
  - 1. The Driller will pick up off bottom, shut down the pumps, slow down the pipe rotation.
  - 2. Secure and don escape breathing equipment, report to the upwind designated safe briefing / muster area.
  - 3. All personnel on location will be accounted for and emergency search should begin for any missing, the Buddy System will be implemented.
  - 4. Order non-essential personnel to leave the well site, order all essential personnel out of the danger zone and upwind to the nearest designated safe briefing / muster area.
  - 5. Entrance to the location will be secured to a higher level than our usual "Meet and Greet" requirement, and the proper condition flag will be displayed at the entrance to the location.
  - 6. Take steps to determine if the H<sub>2</sub>S level can be corrected or suppressed and, if so, proceed as required.
- B. If uncontrollable conditions occur:
  - 1. Take steps to protect and/or remove any public in the down-wind area from the rig – partial evacuation and isolation. Notify necessary public safety personnel and appropriate regulatory entities (i.e. BLM) of the situation.

2. Remove all personnel to the nearest upwind designated safe briefing / muster area or off location.
3. Notify public safety personnel of safe briefing / muster area.
4. An assigned crew member will blockade the entrance to the location. No unauthorized personnel will be allowed entry to the location.
5. Proceed with best plan (at the time) to regain control of the well. Maintain tight security and safety procedures.

C. Responsibility:

1. Designated personnel.
  - a. Shall be responsible for the total implementation of this plan.
  - b. Shall be in complete command during any emergency.
  - c. Shall designate a back-up.

- |                     |                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| All personnel:      | <ol style="list-style-type: none"> <li>1. On alarm, don escape unit and report to the nearest upwind designated safe briefing / muster area upw</li> <li>2. Check status of personnel (buddy system).</li> <li>3. Secure breathing equipment.</li> <li>4. Await orders from supervisor.</li> </ol>                                                                                               |
| Drill site manager: | <ol style="list-style-type: none"> <li>1. Don escape unit if necessary and report to nearest upwind designated safe briefing / muster area.</li> <li>2. Coordinate preparations of individuals to return to point of release with tool pusher and driller (using the buddy system).</li> <li>3. Determine H2S concentrations.</li> <li>4. Assess situation and take control measures.</li> </ol> |
| Tool pusher:        | <ol style="list-style-type: none"> <li>1. Don escape unit Report to up nearest upwind designated safe briefing / muster area.</li> <li>2. Coordinate preparation of individuals to return to point of release with tool pusher drill site manager (using the buddy system).</li> <li>3. Determine H2S concentration.</li> <li>4. Assess situation and take control measures.</li> </ol>          |
| Driller:            | <ol style="list-style-type: none"> <li>1. Don escape unit, shut down pumps, continue rotating DP.</li> </ol>                                                                                                                                                                                                                                                                                     |

2. Check monitor for point of release.
3. Report to nearest upwind designated safe briefing / muster area.
4. Check status of personnel (in an attempt to rescue, use the buddy system).
5. Assigns least essential person to notify Drill Site Manager and tool pusher by quickest means in case of their absence.
6. Assumes the responsibilities of the Drill Site Manager and tool pusher until they arrive should they be absent.

Derrick man  
Floor man #1  
Floor man #2

1. Will remain in briefing / muster area until instructed by supervisor.

Mud engineer:

1. Report to nearest upwind designated safe briefing / muster area.
2. When instructed, begin check of mud for ph and H2S level. (Garett gas train.)

Safety personnel:

1. Mask up and check status of all personnel and secure operations as instructed by drill site manager.

### **Taking a kick**

When taking a kick during an H2S emergency, all personnel will follow standard Well control procedures after reporting to briefing area and masking up.

### **Open-hole logging**

All unnecessary personnel off floor. Drill Site Manager and safety personnel should monitor condition, advise status and determine need for use of air equipment.

### **Running casing or plugging**

Following the same “tripping” procedure as above. Drill Site Manager and safety personnel should determine if all personnel have access to protective equipment.

### **Ignition procedures**

The decision to ignite the well is the responsibility of the operator (Oxy Drilling Management). The decision should be made only as a last resort and in a situation where it is clear that:

1. Human life and property are endangered.
2. There is no hope controlling the blowout under the prevailing conditions at the well.

#### **Instructions for igniting the well**

1. Two people are required for the actual igniting operation. They must wear self-contained breathing units and have a safety rope attached. One man (tool pusher or safety engineer) will check the atmosphere for explosive gases with the gas monitor. The other man is responsible for igniting the well.
2. Primary method to ignite: 25 mm flare gun with range of approximately 500 feet.
3. Ignite upwind and do not approach any closer than is warranted.
4. Select the ignition site best for protection, and which offers an easy escape route.
5. Before firing, check for presence of combustible gas.
6. After lighting, continue emergency action and procedure as before.
7. All unassigned personnel will remain in briefing area until instructed by supervisor or directed by the Drill Site Manager.

**Remember:** After well is ignited, burning hydrogen sulfide will convert to sulfur dioxide, which is also highly toxic. **Do not assume the area is safe after the well is ignited.**

### **Status check list**

Note: All items on this list must be completed before drilling to production casing point.

1. H2S sign at location entrance.
2. Two (2) wind socks located as required.
3. Four (4) 30-minute positive pressure air packs (2 at each Briefing area) on location for all rig personnel and mud loggers.
4. Air packs inspected and ready for use.
5. Cascade system and hose line hook-up as needed.
6. Cascade system for refilling air bottles as needed.
7. Condition flag on location and ready for use.
8. H2S detection system hooked up and tested.
9. H2S alarm system hooked up and tested.
10. Hand operated H2S detector with tubes on location.
11. 1 – 100' length of nylon rope on location.
12. All rig crew and supervisors trained as required.
13. All outside service contractors advised of potential H2S hazard on well.
14. No smoking sign posted and a designated smoking area identified.
15. Calibration of all H2S equipment shall be noted on the IADC report.

Checked by: \_\_\_\_\_ Date: \_\_\_\_\_

### **Procedural check list during H2S events**

#### **Perform each tour:**

1. Check fire extinguishers to see that they have the proper charge.
2. Check breathing equipment to ensure that it is in proper working order.
3. Make sure all the H2S detection system is operative.

#### **Perform each week:**

1. Check each piece of breathing equipment to make sure that demand or forced air regulator is working. This requires that the bottle be opened and the mask assembly be put on tight enough so that when you inhale, you receive air or feel air flow.
2. BOP skills (well control drills).
3. Check supply pressure on BOP accumulator stand by source.
4. Check breathing equipment mask assembly to see that straps are loosened and turned back, ready to put on.
5. Check pressure on breathing equipment air bottles to make sure they are charged to full volume. ( Air quality checked for proper air grade "D" before bringing to location)
6. Confirm pressure on all supply air bottles.
7. Perform breathing equipment drills with on-site personnel.
8. Check the following supplies for availability.
  - A. Emergency telephone list.
  - B. Hand operated H2S detectors and tubes.

### **General evacuation plan**

1. When the company approved supervisor (Drill Site Manager, consultant, rig pusher, or driller) determines the H<sub>2</sub>S gas cannot be limited to the well location and the public will be involved, he will activate the evacuation plan.
2. Drill Site Manager or designee will notify local government agency that a hazardous condition exists and evacuation needs to be implemented.
3. Company or contractor safety personnel that have been trained in the use of H<sub>2</sub>S detection equipment and self-contained breathing equipment will monitor H<sub>2</sub>S concentrations, wind directions, and area of exposure. They will delineate the outer perimeter of the hazardous gas area. Extension to the evacuation area will be determined from information gathered.
4. Law enforcement personnel (state police, police dept., fire dept., and sheriff's dept.) Will be called to aid in setting up and maintaining road blocks. Also, they will aid in evacuation of the public if necessary.
5. After the discharge of gas has been controlled, company safety personnel will determine when the area is safe for re-entry.

**Important: Law enforcement personnel will not be asked to come into a contaminated area. Their assistance will be limited to uncontaminated areas. Constant radio contact will be maintained with them.**

### **Emergency actions**

#### **Well blowout – if emergency**

1. Evacuate all personnel to “Safe Briefing / Muster Areas” or off location if needed.
2. If sour gas – evacuate rig personnel.
3. If sour gas – evacuate public within 3000 ft radius of exposure.
4. Don SCBA and shut well in if possible using the buddy system.
5. Notify Drilling Superintendent and call 911 for emergency help (fire dept and ambulance) if needed.
6. Implement the Blowout Contingency Plan, and Drilling Emergency Action Plan.
6. Give first aid as needed.

#### **Person down location/facility**

1. If immediately possible, contact 911. Give location and wait for confirmation.
2. Don SCBA and perform rescue operation using buddy system.



### **Toxic effects of hydrogen sulfide**

Hydrogen sulfide is extremely toxic. The acceptable ceiling concentration for eight-hour exposure is 10 ppm, which is .001% by volume. Hydrogen sulfide is heavier than air (specific gravity – 1.192) and colorless. It forms an explosive mixture with air between 4.3 and 46.0 percent by volume. Hydrogen sulfide is almost as toxic as hydrogen cyanide and is between five and six times more toxic than carbon monoxide. Toxicity data for hydrogen sulfide and various other gases are compared in table i. Physical effects at various hydrogen sulfide exposure levels are shown in table ii.

Table i  
Toxicity of various gases

Common name	Chemical formula	Specific gravity (sc=1)	Threshold limit (1)	Hazardous limit (2)	Lethal concentration (3)
Hydrogen Cyanide	Hcn	0.94	10 ppm	150 ppm/hr	300 ppm
Hydrogen Sulfide	H2S	1.18	10 ppm	250 ppm/hr	600 ppm
Sulfur Dioxide	So2	2.21	5 ppm	-	1000 ppm
Chlorine	Cl2	2.45	1 ppm	4 ppm/hr	1000 ppm
Carbon Monoxide	Co	0.97	50 ppm	400 ppm/hr	1000 ppm
Carbon Dioxide	Co2	1.52	5000 ppm	5%	10%
Methane	Ch4	0.55	90,000 ppm	Combustible above 5% in air	

- 1) threshold limit – concentration at which it is believed that all workers may be repeatedly exposed day after day without adverse effects.
- 2) hazardous limit – concentration that will cause death with short-term exposure.
- 3) lethal concentration – concentration that will cause death with short-term exposure.

### **Toxic effects of hydrogen sulfide**

Table ii  
Physical effects of hydrogen sulfide

<u>Percent (%)</u>	<u>Ppm</u>	<u>Concentration</u> Grains <u>100 std. Ft3*</u>	<u>Physical effects</u>
0.001	<10	00.65	Obvious and unpleasant odor.

0.002	10	01.30	Safe for 8 hours of exposure.
0.010	100	06.48	Kill smell in 3 – 15 minutes. May sting eyes and throat.
0.020	200	12.96	Kills smell shortly; stings eyes and throat.
0.050	500	32.96	Dizziness; breathing ceases in a few minutes; needs prompt artificial respiration.
0.070	700	45.36	Unconscious quickly; death will result if not rescued promptly.
0.100	1000	64.30	Unconscious at once; followed by death within minutes.

\*at 15.00 psia and 60'f.

### **Use of self-contained breathing equipment (SCBA)**

1. Written procedures shall be prepared covering safe use of SCBA's in dangerous atmosphere, which might be encountered in normal operations or in emergencies. Personnel shall be familiar with these procedures and the available SCBA.
2. SCBA's shall be inspected frequently at random to insure that they are properly used, cleaned, and maintained.
3. Anyone who may use the SCBA's shall be trained in how to insure proper face-piece to face seal. They shall wear SCBA's in normal air and then wear them in a test atmosphere. (note: such items as facial hair {beard or sideburns} and eyeglasses will not allow proper seal.) Anyone that may be reasonably expected to wear SCBA's should have these items removed before entering a toxic atmosphere. A special mask must be obtained for anyone who must wear eyeglasses or contact lenses.
4. Maintenance and care of SCBA's:
  - a. A program for maintenance and care of SCBA's shall include the following:
    1. Inspection for defects, including leak checks.
    2. Cleaning and disinfecting.
    3. Repair.
    4. Storage.
  - b. Inspection, self-contained breathing apparatus for emergency use shall be inspected monthly.
    1. Fully charged cylinders.
    2. Regulator and warning device operation.
    3. Condition of face piece and connections.
    4. Rubber parts shall be maintained to keep them pliable and prevent deterioration.
  - c. Routinely used SCBA's shall be collected, cleaned and disinfected as frequently as necessary to insure proper protection is provided.
5. Persons assigned tasks that requires use of self-contained breathing equipment shall be certified physically fit (medically cleared) for breathing equipment usage at least annually.
6. SCBA's should be worn when:
  - A. Any employee works near the top or on top of any tank unless test reveals less than 10 ppm of H<sub>2</sub>S.

- B. When breaking out any line where H<sub>2</sub>S can reasonably be expected.
- C. When sampling air in areas to determine if toxic concentrations of H<sub>2</sub>S exists.
- D. When working in areas where over 10 ppm H<sub>2</sub>S has been detected.
- E. At any time there is a doubt as to the H<sub>2</sub>S level in the area to be entered.

**Rescue**  
**First aid for H<sub>2</sub>S poisoning**

Do not panic!

Remain calm – think!

1. Don SCBA breathing equipment.
2. Remove victim(s) utilizing buddy system to fresh air as quickly as possible. (go up-wind from source or at right angle to the wind. Not down wind.)
3. Briefly apply chest pressure – arm lift method of artificial respiration to clean the victim's lungs and to avoid inhaling any toxic gas directly from the victim's lungs.
4. Provide for prompt transportation to the hospital, and continue giving artificial respiration if needed.
5. Hospital(s) or medical facilities need to be informed, before-hand, of the possibility of H<sub>2</sub>S gas poisoning – no matter how remote the possibility is.
6. Notify emergency room personnel that the victim(s) has been exposed to H<sub>2</sub>S gas.

Besides basic first aid, everyone on location should have a good working knowledge of artificial respiration.

Revised CM 6/27/2012

**OXY USA Inc.**

**EMERGENCY ACTION PLAN**

**Cedar Canyon 22 #1H**

**Cedar Canyon 23 #1H**

**DRILLING/WORKOVER**

**DRILLING AND CRITICAL WELL OPERATIONS**

**DRILLING/WORKOVER  
DRILLING AND CRITICAL WELL OPERATIONS  
EMERGENCY ACTION PLAN**

**TABLE OF CONTENTS**

<b><u>ITEM</u></b>	<b><u>PAGE</u></b>
PREFACE .....	3
EMERGENCY RESPONSE ACTIVATION AND GENERAL RESPONSIBILITIES .....	4
SPECIFIC EMERGENCY GUIDANCE	
- Well Control.....	5
- H2S Release .....	6
- Personal Injury or Death.....	7
- Fire or Explosion .....	7
- Spills.....	7
- Hydrocarbon Vapor Cloud Release.....	7
- Bomb Threat .....	8
- Natural Disasters – Tornadoes and Thunderstorms .....	9
PUBLIC RELATIONS .....	9
PHONE CONTACTS – OP DRILLING/WORKOVER .....	10
PHONE CONTACTS – OP PRODUCTION AND PLANT PERSONNEL .....	11
PHONE CONTACTS – OP HES PERSONNEL .....	13
MAP.....	22

## **PREFACE**

An effective and viable Emergency Action Plan (EAP) is intended to provide prior planning and guidance in responding to emergency incidents. The primary considerations in its development are protection of personnel, the public, company and public property, and the environment.

Although the plan addresses varied emergency situations that may occur, it recognizes that flexibility and the use of the organization's knowledge and experience is critical to safe resolution of emergency incidents. Response actions outlined in the plan provide a framework, which may be placed into operation without confusion. These actions should promote quick and decisive actions during the critical initial period and immediately following an emergency. As the response progresses, additional guidelines and procedures may need to be implemented as the situation dictates. In addition, all emergency incidents must be properly reported per the Oxy Incident Reporting and Notification Policy, state and federal requirements, etc.

The following procedures are provided as Oxy Permian's minimum expectations. The Contractor's own procedures may be utilized in lieu of Oxy Permian's, provided that it meets or exceeds the minimum deliverables. It should be understood that this list is not all-inclusive, but the overall plan should assist in lateral application to similar incidents.

This EAP is intended for use on Oxy Drilling/Workover projects and the operations within their area of responsibility, such as drilling, critical well work, etc.

## **EMERGENCY RESPONSE ACTIVATION AND GENERAL RESPONSIBILITIES**

### ***Activation of the Emergency Action Plan***

- A. In the event of any emergency situation, all personnel on location should first ensure that the following items are initiated. After that, they should refer to the appropriate Specific Emergency Guidance sections on pages five (5) through nine (9) in this document for further responsibilities:
1. Notify the senior ranking contract representative on site.
  2. Notify Oxy representative in charge.
  3. Notify civil authorities if the Oxy Representative cannot be contacted and the situation dictates.
  4. Perform rescue and first aid as required (without jeopardizing additional personnel).

### ***General Responsibilities***

#### **Oxy Permian Personnel:**

- A. Drill Site Manager: The Oxy Drilling/Critical Well Servicing Operations Specialist or contract personnel serving in that capacity will serve as Operations Chief Officer for all emergency incidents. The Operations Chief Officer is responsible for:
1. Notification to the Drilling/Workover Team Leader of the incident occurrence.
  2. Notification to the local RMT/PMT leader of the incident occurrence, and the need for the designated local RMT/PMT Incident Commander to act in that capacity for the response effort.
  3. Sole control of all tactical activities directed toward reducing the immediate hazard, establishing situational control and restoring the operations to a non-emergency state.
- B. Local RMT/PMT Designated Incident Commander: The Oxy local RMT/PMT Designated Incident Commander will serve as the overall Incident Commander for the drilling or critical well servicing emergency incident. The Incident Commander is responsible for:
1. Coordinating with the Drilling Manager for notification to the Oxy Crisis Management team of the incident occurrence.
  2. Establishing and managing the overall incident command structure and response from inception through restoration of normal activities in the area.
- C. Drilling/Workover HES Tech: The Drilling/Workover HES Tech (or his designate) is responsible for reporting to the incident as soon as reasonably possible, to provide support to the response effort as required by the Operations Chief Officer or the Incident Commander.

**Contract Drilling Personnel** will immediately report to their assigned stations and perform their duties as outlined in the appropriate Specific Emergency Guidance sections on pages five (5) through nine (9) in this document.

**Other Contractor Personnel** will report to the safe briefing area to assist Oxy personnel and civil authorities as requested when it is safe to do so and if they have been adequately trained in their assigned duties.

**Civil Authorities** (Law Enforcement, Fire, and EMS) will be responsible for:

1. Establishing membership in the Unified Incident Command.
2. As directed by the Incident Commander and the Unified Command, control site access, re-route traffic, and provide escort services for response personnel.
3. Perform all fire control activities in coordination with the Unified Command.
4. Initiate public evacuation plans as instructed by the Incident Commander.
5. Perform rescue or recovery activities with coordination from the Unified Command.
6. Provide medical assistance as dictated by the situation at hand.



## **WELL CONTROL**

The following procedures will be implemented when a loss of primary control is indicated. Indicators of loss of primary control are flow from the well, an increase in pit volume, or when the drilling fluid used to fill the hole on trips is less than the calculated pipe displacement volume. The emergency signal for well control procedures will be a single long blast of the rig air horn.

### **Kick While Drilling - Procedures And Responsibilities**

#### Driller:

1. Stop the rotary and hoist the kelly above the rotary table.
2. Stop the mud pump(s).
3. Check for flow.
4. If flowing, sound the alarm immediately.
5. Ensure that all crew members fill their responsibilities to secure the well.
6. Record drill pipe and casing shut-in pressures and pit volume increase and begin kill sheet.

#### Derrickman:

1. Go to BOP/choke manifold area.
2. Open choke line valve on BOP.
3. Signal to Floorman #1 that the choke line is open.
4. Close chokes after annular or pipe rams are closed.
5. Record shut-in casing pressure and pit volume increase.
6. Report readings and observations to Driller.
7. Verify actual mud weight in suction pit and report to Driller.
8. Be readily available as required for additional tasks.

#### Floorman # 1:

1. Go to accumulator control station and await signal from Derrickman.
2. Close annular preventer and HCR on signal (if available, if not then close pipe rams).
3. Record accumulator pressures and check for leaks in the BOP or accumulator system.
4. Report to Driller, and be readily available as required for additional tasks.

#### Floorman # 2:

1. Start water on motor exhausts.
2. Notify Contractor Tool Pusher or Rig Manager of well control situation.
3. Check location for ignition sources and extinguish or turn off, and stop any welding in progress.
4. Report to Driller, and be readily available as required for additional tasks.

#### Floorman # 3:

1. Stand-by with Driller, and be readily available as required for additional tasks.

#### Tool Pusher/Rig Manager:

1. Notify Oxy Representative and report to rig floor.
2. Review and verify all pertinent information.
3. Communicate information to Oxy Representative, and confer on an action plan.
4. Finalize well control worksheets, calculations and preparatory work for action plan.
5. Initiate and ensure the action plan is carried out.
6. Communicate any changes in well or site conditions, or any indications that the action plan needs to be revised to the Oxy representative.

#### Oxy Representative:

1. Notify Drilling Superintendent or Drilling Manager and RMT Leader or Local Incident Commander, and Police, Fire Department, or other local emergency services as required.

## **WELL CONTROL (continued)**

### **Kick While Tripping - Procedures and Responsibilities**

#### Driller:

1. Sound the alarm immediately when pipe displacement volume is less than 75% of calculated.
2. Position the upper tool joint just above rotary table and set slips.
3. Check for flow.
4. Ensure that all crew members fill their responsibilities to secure the well.
5. Record drill pipe and casing shut-in pressures and pit volume increase, and begin kill sheets.

#### Derrickman: (same as while drilling)

#### Floor Man # 1:

1. Install full opening valve (with help from Floorman #2) in top drill string connection.
2. Tighten valve with make up tongs.
3. Go to accumulator control station and await signal from Derrickman.
4. Close annular preventer and HCR valve on signal (if available, if not then close pipe rams).
5. Record accumulator pressures and check for leaks in the BOP and accumulator system.
6. Report to Driller, and be readily available as required for additional tasks.

#### Floor Man # 2:

1. Assist installing full opening valve in drill string.
2. Position back-up tongs for valve make-up.
3. Start water on motor exhausts.
4. Notify Contractor Tool Pusher or Rig Manager of well control situation.
5. Check location for ignition sources and extinguish or turn off, and stop any welding in progress.
6. Report to Driller, and be readily available as required for additional tasks.

#### Floorman # 3, Rig Manager/Tool Pusher, and Oxy Representative: (same as while drilling)

### **H2S RELEASE**

The following procedures and responsibilities will be implemented on activation of the H2S siren and lights.

#### All Personnel:

1. On alarm, don escape unit (if available) and report to upwind briefing area.

#### Rig Manager/Tool Pusher:

1. Check that all personnel are accounted for and their condition.
2. Administer or arrange for first aid treatment, and /or call EMTs as needed.
3. Identify two people best suited to secure well and perform rescue, and instruct them to don SCBA.
4. Notify Contractor management and Oxy Representative.
5. Remain at the briefing area, assess and monitor personnel and overall situation for hazards or conditions that might warrant a change in the action plan.

#### Two People Responsible For Shut-in and Rescue:

1. Don SCBA and acquire tools to secure well and perform rescue, i.e., wrenches, retrieval ropes, etc.
2. Utilize the buddy system to secure well and perform rescue(s).
3. Return to the briefing area and stand by for further instructions.

#### All Other Personnel:

1. Remain at the briefing area and await further instructions - do not leave unless instructed.

#### Oxy Representative:

1. Remain at the briefing area, assess and monitor personnel and overall situation for hazards or conditions that might warrant a change in the action plan.
2. Notify Drilling Superintendent or Drilling Manager and RMT Leader or Local Incident Commander, and Police, Fire Department, or other local emergency services as required.

## ***PERSONAL INJURY OR DEATH***

Call for assistance, and then administer first aid for the injured. Treatment should be prioritized by life-threatening conditions.

- A. Do not move injured personnel unless they are in imminent danger. An ambulance should be summoned for any injury that appears to be serious.

## ***FIRE OR EXPLOSION***

### Fire Fighting Philosophy

It is Oxy Permian's intent that Oxy and contract personnel will only extinguish incipient or beginning stage fires and perform or assist in initial non-threatening rescue operations. The responding fire department will be given primacy when they arrive to control a fire on any Oxy property. Any Oxy or contract employee who participates in a fire response must be fully trained and qualified as such, and must be utilizing appropriate Personal Protective Equipment.

### Contract and Oxy Personnel Deployment

In the event of a fire or explosion all personnel will report to the safe briefing area. The Senior Contract Representative on site will designate personnel for rescue as appropriate depending on their qualifications and the risks of the rescue. Any rescue which involves significant risk to those performing the rescue should be deferred to professional response personnel.

No personnel will leave the area without direction / permission from the Senior Contract Representative on-site.

The Senior Contract Representative on site will notify local emergency response personnel as required, along with the Contract Company management and the Oxy Representative as soon as reasonably possible.

## ***SPILLS***

In the event of a significant spill of any substance, the person discovering it should immediately notify the rig supervisor and the Oxy Representative. Personnel onsite should **NOT** attempt identification, control or containment unless they are absolutely sure of the product spilled, are fully aware of the hazard characteristics, and are equipped with the appropriate personal protective equipment.

## ***HYDROCARBON VAPOR CLOUD RELEASE***

Upon discovery of a Hydrocarbon Vapor Cloud (NGL) release, take immediate safety precautions to protect any company personnel or others that might be in the area. Other emergency actions should be initiated only by trained expert personnel from the appropriate pipeline company.

### **The following guidelines should be followed:**

1. Immediately notify the rig supervisor and the Oxy Representative.
2. Determine wind direction, and evacuate upwind or at 90 degrees to the release.
3. Maintain a safe distance from the cloud.
4. Render first aid and call for an ambulance as necessary.
5. Attempt to warn approaching individuals of the hazard.

## **BOMB THREAT**

In the event of a bomb threat, the person receiving the call, on or off site, should try to get as much information as possible from the caller. The person receiving the call should immediately contact the supervisor in charge. Evacuation of the field should be considered at this time. Roadblocks may need to be installed. The supervisor in charge should make all appropriate contacts.

### **The Supervisor contacted should:**

- a. Realize that every bomb threat is serious.
- b. Notify Corporate Security
- c. Inform Police/Sheriff's Department and Fire Department
- d. Contact RMT Leader or his designated relief to coordinate search efforts with the assistance of the local law enforcement agencies.

## **BOMB THREAT CHECKLIST**

Date \_\_\_\_\_ Name of person taking call \_\_\_\_\_ Phone # call came on \_\_\_\_\_

### **FILL OUT COMPLETELY IMMEDIATELY AFTER BOMB THREAT**

1. When is the bomb set to explode? \_\_\_\_\_
2. Where is the bomb located? \_\_\_\_\_
3. What does the bomb look like? \_\_\_\_\_
4. What type of bomb is it? \_\_\_\_\_
5. What will cause the bomb to explode? \_\_\_\_\_
6. Did the caller place the bomb? \_\_\_\_\_
7. Why did the caller place the bomb? \_\_\_\_\_
8. What is the caller's name and address? \_\_\_\_\_

Callers: Sex \_\_\_\_\_ Age \_\_\_\_\_ Race \_\_\_\_\_ Length of call \_\_\_\_\_

### **DESCRIPTION OF CALLER'S VOICE (Check all that apply)**

<input type="checkbox"/> Calm	<input type="checkbox"/> Rapid	<input type="checkbox"/> Laughing	<input type="checkbox"/> Lisp	<input type="checkbox"/> Disguised
<input type="checkbox"/> Angry	<input type="checkbox"/> Crying	<input type="checkbox"/> Raspy	<input type="checkbox"/> Accent	<input type="checkbox"/> Familiar? Who did
<input type="checkbox"/> Excited	<input type="checkbox"/> Normal	<input type="checkbox"/> Deep	<input type="checkbox"/> Stutter	it sound like?
<input type="checkbox"/> Slow	<input type="checkbox"/> Distinct	<input type="checkbox"/> Ragged	<input type="checkbox"/> Deep	<input type="checkbox"/> Deep Breathing
<input type="checkbox"/> Loud	<input type="checkbox"/> Slurred	<input type="checkbox"/> Nasal	<input type="checkbox"/> Clearing Throat	

### **BACKGROUND SOUNDS:**

<input type="checkbox"/> Street	<input type="checkbox"/> House	<input type="checkbox"/> Factory	<input type="checkbox"/> Music	<input type="checkbox"/> Local Call
<input type="checkbox"/> Noises	<input type="checkbox"/> Noises	<input type="checkbox"/> Machinery	<input type="checkbox"/> Static	<input type="checkbox"/> Long Distance
<input type="checkbox"/> Voices	<input type="checkbox"/> Motor	<input type="checkbox"/> Animals	<input type="checkbox"/> PA System	<input type="checkbox"/> Phone Booth
<input type="checkbox"/> Office	<input type="checkbox"/> Clear	<input type="checkbox"/> Other		

### **THREAT LANGUAGE:**

<input type="checkbox"/> Well-Spoken	<input type="checkbox"/> Foul	<input type="checkbox"/> Incoherent	<input type="checkbox"/> Irrational	<input type="checkbox"/> Taped
<input type="checkbox"/> Message Read by Threat Maker				

### **REMARKS:**

## ***NATURAL DISASTERS***

### **Tornadoes**

These general procedures should be followed by everyone seeking shelter from a severe storm or tornado:

#### **Indoors:**

1. Protect yourself from flying glass and debris.
2. Take refuge near the core of the building for maximum protection.
3. Do not smoke while taking shelter.
4. Shut all doors to offices, if time permits.

#### **In the field:**

1. Seek cover in a low-lying area, such as a culvert, ditch, pit, or water injection valve box.
2. Get out of and away from your vehicle.
3. Stay away from power lines.
4. Cover your head with your arms and clothing.

### **Thunderstorms**

#### **Indoors:**

1. Avoid water pipes, sinks, showers, tubs, etc.
2. Stay away from doors and windows.
3. Do not use the telephone.
4. Take off head sets.
5. Turn off, unplug, and stay away from appliances, computers, power tools, & TV sets.

#### **In the field:**

1. Avoid water.
2. Avoid high ground and open spaces.
3. Avoid all metal objects including electric wires, fences, machinery, motors, power tools, etc. Unsafe places include underneath canopies, small picnic or rain shelters, or near trees. Where possible, find shelter in a substantial building or in a fully enclosed metal vehicle such as a car, truck or a van with the windows completely shut. If lightning is striking nearby when you are outside, you should:
  - a. Crouch down, feet together, hands over ears
  - b. Avoid proximity (minimum of 15 ft.) to other people.
4. SUSPEND ACTIVITIES for 30 minutes after the last observed lightning or thunder.

## ***PUBLIC RELATIONS***

Oxy recognizes that the news media have a legitimate interest in incidents at Oxy facilities that could affect the public. It is to the company's benefit to cooperate with the news media when incidents occur because these media are our best liaison with the public.

Our objective is to see that all reports of any emergency are factual and represent the company's position fairly and accurately. Cooperation with news media representatives is the most reliable guarantee that this objective will be met.

All contract and Oxy employees are instructed **NOT** to make any statement to the media concerning the emergency incident. If a media representative contacts any employee, they should refer them to the designated Emergency Command Center where they should contact the Incident Commander or his designated relief for any information concerning the incident.

# **Drilling Dept. Emergency Contact list**

**Drilling Manager                      Douglas Chester   713-366-9124 office  
713-918-9124 cell**

**Drilling Superintendent   Chad Frazier   713-215-7357 office  
806-891-9473 cell**

**Drilling Superintendent   Robert Lovelady 432-685-5630 office  
432-813-6332 cell**

**Drilling Engr Supervisor   Juan Pinzon   713-366-5058 office  
713-503-3962 cell**

**Drilling Engr Supervisor   Luis Tarazona   713-366-5771 office  
713-628-9526 cell**

**HES Specialist-Drilling   Charles Bullard 432-685-5719 office  
432-894-3769 cell**

**Construction Specialist   Dusty Weaver   432-685-5723 office  
806-893-3067 cell**

**OXY Permian Incident Reporting Phone List****OXY Permian Crisis Team Hotline Notification****(713) 935-7210**

<b>Person</b>	<b>Location</b>	<b>Office Phone</b>	<b>Cell/Mobile Phone</b>
<b>Asset Management-Operations Areas</b>			
OXY Permian Primary President & General Manager: Michael Land	Houston	(310) 443-6255	
Asset Development Manager-Denise Woods	Houston	(713) 215-7154	(832) 830-5273
Operations Manager-Keith Sevin	Houston	(713) 366-5979	(432) 661-4121
OXY Permian CO2 President & General Manager: Vicki Hollub	Houston	(713)-215-7332	(713) 885-6347
Asset Development Manager-Andrew Falls	Houston	(713) 366-5148	(713) 918-9096
Operations Manager-Bob Barnes	Houston	(713) 215-7906	(832) 433-0763

**Operations CO2-Primary**

RMT Lead North-David Schellstede	Houston	(713) 366-5013	(713) 560-8061
RMT Lead South-Peter Lawrence	Houston	(713) 215-7644	(832) 830-5273
Well Oper Manager CO2-Bill Elliott	Midland	(432) 685-5845	(432) 557-6736
Well Oper Manager Primary-Charles Wagner	Carlsbad	(575) 628-4151	(575) 725-8306
Well Servicing Manager-Brit Meadows	Midland	(432) 685-5840	(432) 661-0387
WST Coord CO2-Terrell Rowe	Midland	(432) 685-5821	(432) 664-8888
WST Coord Primary-Dalton Dean	Midland	(432) 685-5816	(806) 215-0103
NM Frontier Oper Coord -Kim Moore	Hobbs	(575) 397-8236	(575) 706-1219
NM Frontier Oper Coord -Van Barton	Carlsbad	(575) 628-4111	(575) 706-7671

**HES Staff&Areas of First Contact Support**

HES Manager: John Kirby	Houston	(713) 366-5460	(281) 974-9523
Environmental Consultant: Douglas Lowrie	Midland	(432) 685-5824	(432) 208-0958
Administrative Assistant: Debbie Robertson	Midland	(432) 685 5812	(432) 556-7495
Pipeline Safety: Steven Bishop	Midland	(432) 685-5614	(432) 238-4079
HES Lead CO2-Pete Maciula	Midland	(432) 685-5667	(432) 557-2450
HES Lead Primary-Nicholas Edwards	Midland	(432) 685-5843	(432) 777-2615
HES Advisor: Marty Bryant	Midland	(432) 685-5929	(432) 634-3964
HES Specialist-Drilling: Charles Bullard	Midland	(432) 685-5719	(432) 894-3769

**HES Tech & Area of Responsibility**

Hobbs RMT: Raymond Aguilarl	Hobbs	(575) 397-8251	(575) 390-6312
Primary-New Mexico: Mark Richards	Carlsbad	(575) 628-4120	(806) 111-2615
CO2-New Mexico-CJ Summers	Hobbs	(575) 397-8236	(575) 390-9228

**Regulatory Affairs**

Lead CO2 - Karen Sinard	Houston	(713) 366-5485	(713) 857-6068
Lead Primary - Keith Barton	Houston	(713) 350-4959	(713) 876-1457
Regulatory Advisor-David Stewart	Midland	(432) 685-5717	(432) 638-5688
Sr, Regulatory Analyst-Mark Stephens	Houston	(713) 366-5158	
Staff Regulatory Analyst-Jennifer Duarte	Houston	(713) 513-6640	

**DOT-Pipeline Response Numbers**

N. Hobbs Unit: Steve Bishop	Hobbs	(575) 397-8251	(575) 390-4784
Wasson PMT: Todd King	Denver City	(806) 592-6274	(806) 215-0183
Bravo/Slaughter PMT: Gary Polk	Levelland	(806) 229-9708	(806) 638-2425
Cogdell RMT: Dean Peevy	Cogdell	(325) 573-7272	(325) 207-3367
Sharon Ridge: Carl Morales	Sharon Ridge	(325) 573-6341	(325) 207-3374

**OOGC HES Contacts**

Manager HES: Wes Scott	OOGC – Houston	(713) 215-7171	(713) 203-4050
Worldwide Safety Mgr: Greg Hardin alternate	OOGC – Houston	(713) 366-5324	(713) 560-8037
Worldwide Environ. Mgr: Ravi Ravishankar	OOGC – Houston	(713) 366-5039	(832) 863-2240

**OOGC Risk Management**

Jim Garrett	Los Angeles	(310) 443-6588	(310) 710-3233
Greg LaSalle, alternate	Los Angeles	(310) 443-6542	(310) 710-2255

**OSI**

Workers Comp. Claim Manager: Steve Jones	Dallas	(972) 404-3542	
Workers Comp. Claims: Mark Ryan	Dallas	(972) 404-3974	
Auto Claims: Steve Jones	Dallas	(972) 404-3542	

**Gallagher Bassett**

Workers Comp. & Property Damage Claims-OXY Permian Ltd.: Danny Ross		(972) 728-3600 X252	(800) 349-8492
---------------------------------------------------------------------	--	------------------------	----------------

**Axiom Medical Consulting**

Medical Case Management		(877) 502-9466	
-------------------------	--	----------------	--

**OXY Permian Legal**

Tom Janiszewski	Houston	(713) 366-5529	(713) 560-8049
-----------------	---------	----------------	----------------

**Human Resources**

H.R. Manager: Barbara Bernhard	Houston	(713) 215-7150	(713) 702-7949
H.R. Consultant: Amy Thompson	Houston	(713) 215-7863	(281) 799-7348
H.R. Consultant: Laura Matthews	Houston	(713) 366-5137	(713) 569-0386
H.R. Consultant: Jill Williams	Midland	(432) 685-5818	(432) 661-4581

**Corporate Security**

Frank Zapalac	Houston	(713) 215-7157	(713) 829-5753
Hugh Moreno, alternate	Houston	(713) 215-7162	(713) 817-3322

**Regulatory Agencies**

Bureau of Land Management	Carlsbad, NM	(575) 887-6544	
Bureau of Land Management	Hobbs, NM	(575) 393-3612	
Bureau of Land Management	Roswell, NM	(575) 393-3612	
Bureau of Land Management	Santa Fe, NM	(505) 988-6030	



DOT Juisdictional Pipelines-Incident Reporting New Mexico Public Regulation Commission	Santa Fe, NM	(505) 827-3549 (505) 490-2375	
DOT Juisdictional Pipelines-Incident Reporting Texas Railroad Commission	Austin, TX	(512) 463-6788	
EPA Hot Line	Dallas, Texas	(214) 665-6444	
Federal OSHA, Area Office	Lubbock, Texas	(806) 472-7681	
National Response Center	Washington, D. C.	(800) 424-8802	
National Infrastructure Coordinator Center		(202) 282-9201	
New Mexico Air Quality Bureau	Santa Fe, NM	(505) 827-1494	
New Mexico Oil Conservation Division	Artesia, NM	(575) 748-1283	
New Mexico Oil Conservation Division	Hobbs, NM	(575) 393-6161	
New Mexico Oil Conservation Division	Santa Fe, NM	(505) 471-1068	
New Mexico OCD Environmental Bureau	Santa Fe, NM	(505) 827-7152 (505) 476-3470	
New Mexico Environmental Department	Hobbs, NM	(575) 827-9329	
NM State Emergency Response Center	Santa Fe, NM	(505) 827-9222	
Railroad Commission of TX	District 8, 8A Midland, TX	(432) 684-5581	
Texas Emergency Response Center	Austin, TX	(512) 463-7727	
TCEQ Air	Region 2 Lubbock, TX	(806) 796-3494	
TCEQ Water/Waste/Air	Region 7 Midland, TX	(432) 570-1359	

#### Medical Facilities

Artesia General Hospital	Artesia, NM	(575) 748-3333	
Guadalupe Medical Center	Carlsbad, NM	(575) 887-6633	
Lea Regional Hospital	Hobbs, NM	(575) 492-5000	
Medical Arts Hospital	Lamesa, TX	(806) 872-2183	
Medical Center Hospital	Odessa, TX	(432) 640-4000	
Memorial Hospital	Seminole, TX	(432) 758-5811	
Midland Memorial Hospital	Midland, TX	(432) 685-1111	
Nor-Lea General Hospital	Lovington, NM	(575) 396-6611	
Odessa Regional Hospital	Odessa, TX	(432) 334-8200	
St. Mary's Hospital	Lubbock, TX	(806) 796-6000	
Union County General Hospital	Clayton, NM	(575) 374-2585	
University Medical Center	Lubbock, TX	(806) 743-3111	

#### Local Emergency Planning Comm.

Richard H. Dolgener	Andrews County, TX	(432) 524-1401	
Joel Arnwine	Eddy County, NM	(575) 887-9511	
County Judge Judy House	Gaines County, TX	(432) 758-5411	
Myra Sande	Harding County, NM	(575) 673-2231	
Jerry Reynolds	Lea County, NM	(575) 396-8600	(575) 399-2376
Royce Creager	Loving County, TX	(432) 377-2231	
Mike Cherry	Quay County, NM	(575) 461-2476	
Della Wetsel	Union County, NM	(575) 374-8896	
Bonnie Leck	Winkler County, TX	(432) 586-6658	

Carl Whitaker	Yoakum County, TX	(806) 456-7491	
---------------	-------------------	----------------	--

#### **Law Enforcement - Sheriff**

Andrews Cty Sheriff's Department	Andrews County	(432) 523-5545	
Eddy Cty Sheriff's Department	Eddy County (Artesia)	(575) 746-2704	
Eddy Cty Sheriff's Department	Eddy County (Carlsbad)	(575) 887-7551	
Gaines Cty Sheriff's Department	Gaines County (Seminole)	(432) 758-9871	
Lea Cty Sheriff's Department	Lea County (Eunice)	(575) 384-2020	
Lea Cty Sheriff's Department	Lea County (Hobbs)	(575) 393-2515	
Lea Cty Sheriff's Department	Lea County (Lovington)	(575) 396-3611	
Union Cty Sheriff's Department	Union County (Clayton)	(505) 374-2583	
Yoakum City Sheriff's Department	Yoakum Co.	(806) 456-2377	

#### **Law Enforcement - Police**

Andrews City Police	Andrews, TX	(432) 523-5675	
Artesia City Police	Artesia, NM	(575) 746-2704	
Carlsbad City Police	Carlsbad, NM	(575) 885-2111	
Clayton City Police	Clayton, NM	(575) 374-2504	
Denver City Police	Denver City, TX	(806) 592-3516	
Eunice City Police	Eunice, NM	(575) 394-2112	
Hobbs City Police	Hobbs, NM	(575) 397-9265 (575) 393-2677	
Jal City Police	Jal, NM	(575) 395-2501	
Lovington City Police	Lovington, NM	(575) 396-2811	
Seminole City Police	Seminole, TX	(432) 758-9871	

#### **Law Enforcement - FBI**

FBI	Albuquerque, NM	(505) 224-2000	
FBI	Midland, TX	(432) 570-0255	

#### **Law Enforcement - DPS**

NM State Police	Artesia, NM	(575) 746-2704	
NM State Police	Carlsbad, NM	(575) 885-3137	
NM State Police	Eunice, NM	(575) 392-5588	
NM State Police	Hobbs, NM	(575) 392-5588	
NM State Police	Clayton, NM	(575) 374-2473; 911	
TX Dept of Public Safety	Andrews, TX	(432) 524-1443	
TX Dept of Public Safety	Seminole, TX	(432) 758-4041	
TX Dept of Public Safety	Yoakum County TX	(806) 456-2377	

#### **Firefighting & Rescue**

Amistad/Rosebud	Amistad/Rosebud, NM	(505) 633-9113	
Andrews	Andrews, TX	(432) 523-4820 (432) 523-3111	
Artesia	Artesia, NM	(575) 746-5051	
Carlsbad	Carlsbad, NM	(575) 885-3125	

Clayton	Clayton, NM	(575) 374-2435	
Denver City	Denver City, TX	(806) 592-5426	
Eunice	Eunice, NM	(575) 394-2111	
Hobbs	Hobbs, NM	(575) 397-9308	
Jal	Jal, NM	(575) 395-2221	
Kermit	Kermit, TX	(432) 586-3468	
Lovington	Lovington, NM	(575) 396-2359	
Maljamar	Maljamar, NM	(575) 676-4100	
Monahans	Monahans, TX	(432) 943-4343	
Nara Visa	Nara Visa, NM	(575) 461-3300	
Pecos	Pecos, TX	(432) 445-2421	
Seminole	Seminole, TX	(432) 758-3676 (432) 758-9871	

#### **Ambulance**

Amistad/Rosebud	Amistad/Rosebud, NM	(575) 633-9113	
Andrews Ambulance	Andrews, TX	(432) 523-5675	
Artesia Ambulance	Artesia, NM	(575) 746-2701	
Carlsbad Ambulance	Carlsbad, NM	(575) 885-2111; 911	
Clayton, NM	Clayton, NM	(575) 374-2501	
Denver City Ambulance	Denver City, TX	(806) 592-3516	
Eunice Ambulance	Eunice, NM	(575) 394-3258	
Hobbs, NM	Hobbs, NM	(575) 397-9308	
Jal, NM	Jal, NM	(575) 395-2501	
Lovington Ambulance	Lovington, NM	(575) 396-2811	
Nara Visa, NM	Nara Visa, NM	(575) 461-3300	
Pecos Ambulance	Pecos, TX	(432) 445-4444	
Seminole Ambulance	Seminole, TX	(432) 758-8816 (432) 758-9871	

#### **Medical Air Ambulance Service**

AEROCARE - Methodist Hospital	Lubbock, TX	(800) 627-2376	
San Angelo Med-Vac Air Ambulance	San Angelo, TX	(800) 277-4354	
Southwest Air Ambulance Service	Stanford, TX	(800) 242-6199	
Southwest MediVac	Snyder, TX	(800) 242-6199	
Southwest MediVac	Hobbs, NM	(800) 242-6199	
Odessa Care Star	Odessa, TX	(888) 624-3571	
NWTH Medivac	Amarillo, TX	(800) 692-1331	

## PECOS DISTRICT CONDITIONS OF APPROVAL

OPERATOR'S NAME:	OXY USA INC
LEASE NO.:	NM81586
WELL NAME & NO.:	1H-CEDAR CANYON 23
SURFACE HOLE FOOTAGE:	2068'/N. & 483'/W.
BOTTOM HOLE FOOTAGE:	1980'/N. & 660'/E.
LOCATION:	Section 23, T. 24 S., R. 29 E., NMPM
COUNTY:	Eddy County, New Mexico

### TABLE OF CONTENTS

Standard Conditions of Approval (COA) apply to this APD. If any deviations to these standards exist or special COAs are required, the section with the deviation or requirement will be checked below.

- ☐ **General Provisions**
- ☐ **Permit Expiration**
- ☐ **Archaeology, Paleontology, and Historical Sites**
- ☐ **Noxious Weeds**
- ☒ **Special Requirements**
  - Cave/Karst
- ☐ **Construction**
  - Notification
  - Topsoil
  - Closed Loop System
  - Federal Mineral Material Pits
  - Well Pads
  - Roads
- ☐ **Road Section Diagram**
- ☒ **Drilling**
  - Logging requirements
  - Medium cave/karst
  - Casing depth
  - Waste Material and Fluids
- ☐ **Production (Post Drilling)**
  - Well Structures & Facilities
  - Pipelines
  - Electric Lines
- ☐ **Interim Reclamation**
- ☐ **Final Abandonment & Reclamation**