

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
May 27, 2004

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-21815
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No. -

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		7. Lease Name or Unit Agreement Name Mesa Grande
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other <input type="checkbox"/>	RECEIVED	8. Well Number 1
2. Name of Operator Kaiser-Francis Oil Company	SEP 24 2005	9. OGRID Number 012361
3. Address of Operator P. O. Box 21468, Tulsa, OK 74121-1468	OCU-ARTESIA	10. Pool name or Wildcat Carlsbad, S. Morrow (Pro Gas)
4. Well Location Unit Letter F : 1980 feet from the North line and 1980 feet from the West line Section 11 Township 22S Range 26E NMPM Eddy County		
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3152 GR		
Pit or Below-grade Tank Application <input type="checkbox"/> or Closure <input type="checkbox"/>		
Pit type _____ Depth to Groundwater _____ Distance from nearest fresh water well _____ Distance from nearest surface water _____		
Pit Liner Thickness: _____ mil Below-Grade Tank: Volume _____ bbls; Construction Material _____		

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
OTHER: Frac well <input checked="" type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

See attached proposed workover.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE Jan T. Kenney TITLE Technical Coordinator DATE 9/21/05

Type of permit name Charlotte Walker e-mail address: Charlotv@KFOC.net Telephone No. 918-491-4314

For State Use Only

APPROVED BY District II Supervisor TITLE _____

SEP 26 2005

DATE _____

Conditions of Approval (if any):

**Mesa Grande 1-11
11-22S-26E
Eddy Co., NM.**

Proposed Workover

Frac Morrow

DOWNHOLE INFORMATION:

13 3/8" at 318' w/300 sxs

9 5/8" at 2760' w/350 sxs. DV tool at 2000' w/1745 sxs

5 1/2" 17# at 11,550' w/500 sxs. (TOC 9220')

2 3/8" tubing at 10,940'

Model R packer at 10,940'

FISH IN HOLE:

Guiberson Uni-VI packer at 11,025' w/2 3/8" tubing stub to 10,956'

PERFORATIONS:

11,107'-11'; 13'-17'; 66'-70'; 86'-89'; 96'-99'; 1128'-33'; 43'-46' (43 holes)

CIBP at 11,420'

PROPOSED WORKOVER PROGRAM:

- MIRU WSU. Install BOP. Release Model "R" packer. POOH.
- GIH and fish Guiberson Uni-VI packer at 11,025'. POOH LD Packer
- PU Packer, X nipple (for plug for 2 3/8" tbg), On-off tool, 3 1/2" workstring and GIH. Set packer at 11,000'.
- Frac well as directed.
- Open well and flowback load. Test.
- GIH and set plug in "X" nipple for 2 3/8" tubing
- Release 3 1/2" from on-off tool.
- Come out of hole laying down the 3 1/2" tubing.
- RIH w/2 3/8" tbg. Latch onto on/off tool. Load tubing w/4% KCL water
- GIH and fish plug from "X" nipple.
- Open well to tank. Flow back and put well on line. Swab if needed.
- RDMO WSU.
- Test and report.