
Submit 1 Copy To Appropriate District						
	Sta	ite of New Me	exico		Form C	C-103
* ² Office District I – (575) 393-6161	Energy, Mir	nerals and Natu	ral Resources		Revised August	1, 2011
1625 N. French Dr., Hobbs, NM 88240				WELL API N		
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CON	SERVATION	DIVISION	30-015-2113 5. Indicate T		
<u>District III</u> – (505) 334-6178	1220	South St. Fran	ncis Dr.	S. Indicate T		1
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460	Sa	nta Fe, NM 87	7505		& Gas Lease No.	
1220 S. St. Francis Dr., Santa Fe, NM						
87505 SUNDRY NOT	CES AND REPOR	TS ON WELLS		7 Lease Nat	ne or Unit Agreement N	ame
(DO NOT USE THIS FORM FOR PROPO	SALS TO DRILL OR T	O DEEPEN OR PLU	UG BACK TO A	J Lazy J	ne en enne rigieennent ri	
DIFFERENT RESERVOIR. USE "APPLIC	CATION FOR PERMIT	(FORM C-101) FC	DR SUCH	8. Well Num	iber	
PROPOSALS.) 1. Type of Well: Oil Well	Gas Well	 Other		7		
2. Name of Operator			··· ··· ··	9. OGRID N	lumber	
Yates Petroleum Corporation				025575		
3. Address of Operator					ne or Wildcat	
105 South Fourth Street, Artesia, N	M 88210			Eagle Creek;	San Andres	
4. Well Location	1700 fratfrom	the North	line and	1020 from	from the Foot	line a
	1700 feet from				from the <u>East</u>	line
Section 22	Township		nge 25E	NMPM	Eddy County	100000000000000000000000000000000000000
	II. Elevation (S)	how whether DR, 3502	, RKB, RT, GR, e CCP	tc.)		
		5502	UK			
12 Check	Appropriate Box	to Indicate N	ature of Notic	e Report or Ot	ther Data	
	Appropriate Dox				inci Data	
NOTICE OF IN	ITENTION TO		SU	IBSEQUENT	REPORT OF:	
PERFORM REMEDIAL WORK	PLUG AND ABA	1	REMEDIAL WO		ALTERING CASIN	G 🔲
TEMPORARILY ABANDON	CHANGE PLAN			RILLING OPNS.	P AND A	
	MULTIPLE CON		CASING/CEME	ENT JOB		
OTHER:			OTHER:			
13. Describe proposed or comp						ed date
of starting any proposed we		9.15.7.14 NMAC	C. For Multiple (
proposed completion or rec	completion.				OCD 24 hrs. pl	
Yates Petroleum Corporation plans	to plug and abando	n this well as foll	lows:	TO C	My work corre-	:
Yates Petroleum Corporation plans	to plug and abando	n this well as fol	lows:	To c	ny work done.	:
1. MIRU any safety equipment as n	eeded. NU BOP.	TOH with produ	ction equipment.			
 MIRU any safety equipment as n RIH with bit and scraper to just b 	eeded. NU BOP. below perfs at 1480	TOH with produ ' and circulate C	ction equipment. lass "C" cement	to 500' with 115 s	x. NOTE: If fill is tagg	
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH 	eeded. NU BOP. below perfs at 1480 and set a CIBP abo	TOH with produ and circulate C ve perfs at 1230	ction equipment. lass "C" cement t ' before circulati	to 500' with 115 s ng cement to 500	sx. NOTE: If fill is tagg (90 sx).	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to 	eeded. NU BOP. below perfs at 1480 and set a CIBP abo there is cement beh	TOH with produ and circulate C ve perfs at 1230 ind all casing str	ction equipment. lass "C" cement ' before circulati ings at surface. I	to 500' with 115 s ng cement to 500 f so, cement to su	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH 	eeded. NU BOP. below perfs at 1480 and set a CIBP abo there is cement beh face behind each c	TOH with produ and circulate C ve perfs at 1230 ind all casing str	ction equipment. lass "C" cement ' before circulati ings at surface. I	to 500' with 115 s ng cement to 500 f so, cement to su	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that a perforate and circulate cement to sur Install dry hole marker and clean 	eeded. NU BOP. below perfs at 1480 and set a CIBP abo there is cement beh face behind each c	TOH with produ and circulate C ve perfs at 1230 ind all casing str	ction equipment. lass "C" cement ' before circulati ings at surface. I	to 500' with 115 s ng cement to 500 f so, cement to su	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to sur 	eeded. NU BOP. below perfs at 1480 and set a CIBP abo there is cement beh face behind each c	TOH with produ and circulate C ve perfs at 1230 ind all casing str	ction equipment. lass "C" cement ' before circulati ings at surface. I	to 500' with 115 s ng cement to 500 f so, cement to su	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that a perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached 	eeded. NU BOP. below perfs at 1480 and set a CIBP abor there is cement beh face behind each c location.	TOH with produ and circulate C ve perfs at 1230 ind all casing str asing string befo	ction equipment. lass "C" cement t ' before circulati ings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su	SX. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing.	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that a perforate and circulate cement to sur Install dry hole marker and clean 	eeded. NU BOP. below perfs at 1480 and set a CIBP abor there is cement beh face behind each c location.	TOH with produ and circulate C ve perfs at 1230 ind all casing str asing string befo	ction equipment. lass "C" cement t ' before circulati ings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su	SX. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing.	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that a perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached 	eeded. NU BOP. below perfs at 1480 and set a CIBP abor there is cement beh face behind each c location.	TOH with produ and circulate C ve perfs at 1230 ind all casing str asing string befo	ction equipment. lass "C" cement t ' before circulati ings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation 	eeded. NU BOP. below perfs at 1480 and set a CIBP abor there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi	ction equipment. lass "C" cement f ' before circulatiings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that a perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached 	eeded. NU BOP. below perfs at 1480 and set a CIBP abor there is cement beh face behind each c location.	TOH with produ and circulate C ve perfs at 1230 ind all casing str asing string befo	ction equipment. lass "C" cement f ' before circulatiings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod	SX. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing.	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation 	eeded. NU BOP. below perfs at 1480 and set a CIBP abor there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi	ction equipment. lass "C" cement f ' before circulatiings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation Spud Date: 	eeded. NU BOP. below perfs at 1480 and set a CIBP abort there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi Rig Release Da	ction equipment. lass "C" cement r ' before circulatiings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation 	eeded. NU BOP. below perfs at 1480 and set a CIBP abort there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi Rig Release Da	ction equipment. lass "C" cement r ' before circulatiings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation Spud Date: 	eeded. NU BOP. below perfs at 1480 and set a CIBP abort there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi Rig Release Da	ction equipment. lass "C" cement r ' before circulatiings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation Spud Date: 	eeded. NU BOP. below perfs at 1480 and set a CIBP abort there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi Rig Release Da	ction equipment. lass "C" cement r ' before circulatiings at surface. I re cementing to s	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod Nf dge and belief.	sx. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013	ed and
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to suid Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation Spud Date: 	eeded. NU BOP. below perfs at 1480 and set a CIBP abo there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi Rig Release Da complete to the be	ction equipment. lass "C" cement i ' before circulatii ings at surface. I re cementing to s its ate:	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod MI dge and belief.	SX. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013 MOCD ARTESIA	ed and hen
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation Spud Date: I hereby certify that the information SIGNATURE Type or print name	eeded. NU BOP. below perfs at 1480 and set a CIBP abo there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi Rig Release Da complete to the be	ction equipment. lass "C" cement to ' before circulation ings at surface. If re cementing to so its	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod MI dge and belief.	EX. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013 MOCD ARTESIA	ed and hen
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to suid Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation Spud Date: 	eeded. NU BOP. below perfs at 1480 and set a CIBP abo there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi Rig Release Da complete to the be 	ction equipment. lass "C" cement i ' before circulatii ings at surface. I re cementing to s its ate:	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod dge and belief. g Supervisor Da eum.com PH	SX. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013 MOCD ARTESIA	ed and hen
 MIRU any safety equipment as n RIH with bit and scraper to just b unable to get below perfs then TOH Cut off wellhead and verify that to perforate and circulate cement to sur Install dry hole marker and clean Wellbore schematics attached NOTE: Yates Petroleum Corporation Spud Date: I hereby certify that the information SIGNATURE Type or print name	eeded. NU BOP. below perfs at 1480 and set a CIBP abo there is cement beh face behind each c location.	TOH with produ and circulate C ove perfs at 1230 ind all casing str asing string befo ts and no earth pi Rig Release Da complete to the be 	ction equipment. lass "C" cement i ' before circulatii ings at surface. I re cementing to s its ate: est of my knowle ulatory Reporting nah@yatespetrole	to 500' with 115 s ng cement to 500 f so, cement to su surface inside prod dge and belief. g Supervisor Da eum.com PH	SX. NOTE: If fill is tagg (90 sx). rface with 60 sx. If not duction casing. RECEIVED JAN 2 8 2013 MOCD ARTESIA	ed and hen





Ω.

Casing Program	ı
Size/Wt/Grade	Depth Set
10 ¾ " 32# K-55	308'
7" 23# K-55	1,151'
4 ½" 9.5# & 5 ½" 15.5# K-55	1,500'

SKETCH NOT TO SCALE

DATE: 12/13/2012





ı
Depth Set
308'
1,151'
1,500'

DATE: 12/13/2012

NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

CONDITIONS OF APPROVAL FOR PLUGGING & ABANDONMENT

Operator:	Vates Petroleum Corp.
	e & Number: JLazy J # 7
API #:	30-015-21139

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- 3. Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- 6. If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.

8. Cement Retainers may not be used.

9. Squeeze pressures not to exceed 500 psi., unless approval is given by NMOCD Plugging Supervisor.

10. Plugs may be combined after consulting with NMOCD P & A Supervisor.

11. Minimum WOC time for tag plugs will be 4 hrs.

DG Date: 1/ 30/ 2013